



Digital Storage Oscilloscope SPO «Sensitive Phosphor Oscilloscopes»


DOX3104

4-voies - 100 MHz - 2 GSPS - 28MPts
WaveGenerator - Serial Bus Decode

DOX3304

4-voies - 300 MHz - 2 GSPS - 28MPts
WaveGenerator - Serial Bus Decode
8-Channel Logic Analyzer

User's Manual



Pôle Test et Mesure de CHAUVIN-ARNOUX

Content

General Instructions

Introduction	6
Precautions and safety measures	6
Symbols on instrument	7
Guarantee, Repair, Servicing	7

Instrument Description

Front panel	8
Rear panel	9
User display interface	10
Menu and Control buttons	11
Front panel Inputs and Outputs	13
Rear panel Connectors	13
Universal knob	13

Getting Started

Function Checking	14
Probe	15
Probe compensation	16

Function Description

AUTO Config/Default Config	17
Auto Setup	17
Default Configuration	18
I - Vertical System	19
Channels CH1 - CH2 - CH3 - CH4	19
Channel configuration	20
Input coupling	21
Bandwidth Limit	21
Vertical Sensitivity	22
Probe Factor	23
Invert function	23
Input impedance	24
Vertical Unit	25
Vertical knobs	26
Vertical Position knob	26
Vertical Sensitivity knob	26
Storing and Displaying Reference waveforms	27
REF Menu	27
Mathematical Functions	28
MATH Menu	28
Mathematical operations	28
Fast Fourier Transform FFT	29
FFT Menu	29
How to use the FFT	29
Displaying the FFT spectrum	30
Selecting the FFT window	31
FFT : Vertical and Horizontal scales	32
Vertical and Horizontal Position	32
Cursors Measurements	32
Amplitude	32
Frequency	33
FFT of « Cal 3V 1kHz » signal	34

II - HORIZONTAL System	35
Horizontal menu	35
HORIZONTAL Pad	36
Horizontal Position	37
Time Base Coefficient S/div	37
Horizontal Zoom	37
III - TRIGGER System	38
Trigger Menu	38
Tigger Source	39
Trigger Type	40
Edge	40
Pulse	41
Video	43
Slope	44
Window	46
Interval	47
DropOut	48
Runt	49
Pattern	50
Serial 1-2	53
I2C	53
SPI	54
UART/RS232	55
CAN	56
LIN	57
Trigger Coupling	58
Horizontal Position	58
Slope&Level	58
Holdoff	59
IV - ACQUISITION System	61
Acquisition menu	61
Acquisition Configuration	62
Acquisition modes	63
Normal	63
Peak detect	63
Average	64
High Res	64
Sequence	65
Memory Depth setting	67
Time Base	68
Under-Sampling - Aliasing	68
Sequence Mode	70
Run/Stop, Single, Auto, Normal	71

Content (cont'd)

V - Display System	72
Display	72
SPO : Color ON - Color Off	73
X-Y Format.....	75
VI - Measurement System	77
Scale measurements.....	78
Cursors measurement	77
<i>Manual Cursors</i>	77
<i>Track Mode</i>	79
Automatic measurements	81
<i>Automatic Measurements menu</i>	81
<i>Voltage Measurements</i>	81
<i>Time Measurements</i>	81
<i>Delay Measurements</i>	81
<i>All Measurements</i>	82
<i>Measurement Types</i>	83
VII - SAVE/RECALL System	87
Save/Recall	87
<i>Saving Setup files in Internal and External memory</i>	89
<i>Recall a Setup file</i>	90
<i>Rename a Setup file</i>	91
<i>Delete » a Setup file</i>	91
Save/Recall Waveforms	92
Save/Recall Picture	95
Save .CSV file	96
Recall Default Setup	98
VIII - UTILITY System	101
Utility Menu.....	101
Utility page 1/3	102
Utility page 2/3	103
Utility page 3/3	105
System Status	107
Language	107
Print.....	108
Do Self Cal	111
Do Self Test	111
Screen Test	111
Keyboard Test	112
LED Test	112
Firmware Update	113
Pass/Fail	113
History	119
Options.....	122
Date/Time	124
I/O.....	125

IX - Arbitrary Waveform Generator	126
Creating an arbitrary waveform with EasyWave.....	126
Auto-Calibrating the arbitrary waveform generator	129
X - DECODE option for Decoding Serial Bus	130
I2C serial bus	130
Setting I2C Trigger	131
Decoding I2C	134
Reading I2C decoding.....	135
SPI serial bus	136
Setting SPI Trigger	138
Decoding SPI	139
Reading SPI decoding.....	140
UART/RS232 serial bus	141
Setting UART/RS232 Trigger	142
Decoding UART/RS232	144
Reading UART/RS232 decoding	145
CAN serial bus	146
Setting CAN Trigger	151
Decoding CAN	157
Reading CAN decoding	158
LIN serial bus	157
Setting LIN Trigger	158
Decoding LIN	159
Reading LIN decoding.....	160
XI - DIGITAL Option Logic Analyzer	160
XII - Power Analysis Option	167
XIII - Remote Control	172
<hr/>	
Messages	178
Help	178
Messages	179
Diagnostic	180
<hr/>	
Technical Specifications	181
<hr/>	
Appendix	188

General Instructions

Introduction

You have just acquired a 4-channel SPO Digital oscilloscope:

- **DOX3104**, 4-channel, 100 MHz, 2 GSPS, 28Mpts, Arbitrary Waveform Generator, Serial Bus Decode or
- **DOX3304**, 4-channel, 300 MHz, 2 GSPS, 28 Mpts, Arbitrary Waveform Generator, Serial Bus Decode, 8-channel Logic Analyzer.

This 2-4-channel oscilloscope provides a set of powerful features for a wide range of applications such as production, education, maintenance, service, research and development.

Congratulations for your choice and thank you for your trust in the quality of our products.

This instrument conforms to safety standard NF EN 61010-1, single insulation, and relative to electronic measurement instruments. This is a class 1 device which must be connected to the protective earth by its power cord.

To obtain optimum service, read these instructions with care and comply with the precautions for use.

Failure to comply with these warnings and/or user instructions is liable to cause damage to equipment to the equipment and/or components. This could be dangerous to the user.

Précautions and safety measures

- This instrument has been designed for use:
 - indoors,
 - in a pollution degree 2 environment,
 - at an altitude of less than 2000 m,
 - at a temperature in the range of 0°C to 40°C
 - at a relative humidity below 80 % up to 31°C.
- It can be used for measurements on 300V CAT I circuits and can be powered by a 300V CAT II network.

Définition of installation categories

Overvoltage Category I : Is applicable to instruments and equipment which are not intended to be connected to the mains supply. Because the available energy is very limited this category is normally not marked on the equipment. CAT I is for connection to circuits in which measures are taken to limit transient over-voltages to an appropriately low level. Examples: Protected electronic circuits.

Overvoltage Category II : is for equipment intended to be supplied from building wiring. It applies to both equipments plug-connected or permanently connected.

E.g.: Measurements on the network circuits of household appliances, portables tools and other similar appliances.


Overvoltage Category III : is for equipment intended to be incorporated into the building wiring. Such equipment includes socket outlets, fuse panels, and some mains installation control equipment. *E.g.: Measurements on distribution panels (including secondary meters) circuits breakers, cabling including cables, busbars, junction boxes, disconnecting switches, power outlets in the fixed installation, and industrial appliances and other equipment, such as motors permanently connected to the fixed installation.*

La catégorie de surtension IV : is for equipment installed at or near the origin of electrical supply to a building, between the building entrance and the main distribution board. Such equipment may include electricity tariff meters and primary overcurrent protection devices. *E.g.: Measurements on systems installed before the main fuse or the circuit breaker of the building's installation.*

before use

- Comply with environment and storage conditions.

during use

- Read carefully all the notes preceded by the symbol .
- Connect the instrument to an outlet with a protective ground pin.
- Be sure not to obstruct the aeration points.
- As a safety measure, use only suitable cords and accessories supplied with the instrument or type approved by the manufacturer.
- When the instrument is connected to the measurement circuits, never touch an unused terminal.

General Instructions (cont'd)

Symbols on instrument



Warning: Risk of danger.
Refer to the operating manual to find out the nature of the potential hazards and the action necessary to avoid such hazards.



Selective sorting of waste for recycling electric and electronic materials.
In accordance with the WEEE 2002/96/CE directive: must not be treated as household waste.



Earth symbol




On/Off switch



LAN symbol



USB symbol



Fuse symbol



European Conformity



Hazardous voltage



Alternative Current

Guarantee

This equipment is guaranteed for **3 years** against any material defect or manufacturing faults, in conformity with the general conditions of sale.

During this period, only the manufacturer may repair the equipment and it reserves the right to carry out repair or replacement of all or part of the equipment. If the equipment is returned to the manufacturer, forward transport is at the expense of the customer.

The guarantee does not apply in the event of :

- Improper use of the equipment or by association with incompatible equipment
- Modification of the equipment without the explicit authorization of the manufacturer technical services
- Equipment repaired by a person not authorized by the manufacturer
- Equipment used in a particular application not suitable for the device or not described in the user manual
- Shock, fall or flooding.

Repair

For repairs under or out of warranty, please contact our nearest « CHAUVIN-ARNOUX » sales office or our “MANUMESURE” regional technical center, which will establish a feedback file and will communicate the procedure to be followed.

Contact information on our website : <http://www.chauvin-arnoux.com> or by phone at the following numbers:

02 31 64 51 43 (**MANUMESURE Technical Center**)

01 44 85 44 85 (Chauvin Arnoux).


For repairs outside metropolitan France, return the instrument to our “Chauvin-Arnoux” local agency or distributor.

Servicing

- Turn the instrument off.
- Clean it with a damp cloth and soap.
- Never use abrasive products or solvents.
- Dry it before any further use.

Instrument Description


Front Panel



No.	Description	No.	Description
1	Universal Knob	12	Trigger Control
2	Horizontal Controls	13	Common Functions Keys
3	Auto Setup	14	Vertical Controls
4	« Default » Configuration	15	Six menu buttons
5	Run/Stop	16	«Up » Menu button
6	Generator set button « Wave Gen »	17	On/Off button
7	« DECODE » set button	18	Analog Inputs BNCs
8	« Digital » set button	19	Logic Analyzer Inputs
9	« Math » set button	20	« USB Host » connector
10	« Ref » set button	21	Probe Adjust Output
11	Vertical Controls for (Decode/Digital/Math/Ref)	22	Arbitrary Waveform Generator Output

Instrument Description (cont'd)


Rear Panel






1. **Handle**
To transport the oscilloscope turn the handle upright.
2. **EXT TRIG**
External trig input BNC “EXT TRIG”.
3. **« PASS/FAIL » output or trigger output « TRIG OUT » :**
The oscilloscope delivers either a square signal whose frequency is the number of waveforms acquired per second (Aux Output=Trig Out) or the number of “Fail” tests (Aux Output = Pass/Fail).
4. **LAN**
RJ45 connector for a remote control of the oscilloscope (VXI11).
5. **USB Device**
USB connector for « PictBridge » printer (printer) or PC control (USBTMC).
6. **Kensington Lock**
The Kensington cable is not supplied with the unit
7. **Power cord connector**
The supply voltage range is 100-240 Vac, 45-440 Hz. Use the power cord supplied with the unit.
8. **Fuse**
Slow blow fuse 5x20mm 250V, 1.25A.

Instrument Description (cont'd)


User
display
interface



1. **Trigger status:**
Arm: The oscilloscope is acquiring pre-trigger data. All triggers are ignored in this state.
Ready: All pre-trigger data has been acquired and the oscilloscope is ready to accept a trigger event.
Trig'd: The oscilloscope has detected a trigger event and is acquiring the post-trigger data.
Stop: The oscilloscope has stopped acquiring waveform data.
Auto: In trigger « Auto » mode, the oscilloscope refreshes the trace even in absence of a trigger event.
2. **Time Base coefficient : S/div.**
3. Indicates the horizontal trigger position relative to the screen center, use the horizontal Position knob to adjust it.
4. "Zoom" Time Base coefficient : S/div
5. **Awg : High-Z** Arbitrary waveform Generator output impedance: High-Z or 50Ω
6.  USB flash plugged-in
7. Indicates whether the back USB option is set to : Computer or Printer
 "back USB" option is set to "Computer"
 "back USB" option is set to "Printer"
8. Shows the Channel vertical position symbol
9. Shows the CHi active Menu (CH 1)
10. Input Coupling symbol
11. Indicates whether the bandwidth limit is « 20MHz » or « Full Bandwidth ».
12. Vertical Scale Adjust : « Coarse » or « Fine »
13. Probe Factor Selection : .1X .2X .5X 10X 20X 50X 100X 200X 500X 1000X 2000X 5000X 10000X
14. Input impedance : 1MΩ - 50Ω
15. Next page Menu CHi (CANAL i)
16. Display for each of the active channels:
 Channel number, Probe factor, Input Impedance, « B » for the 20MHz bandwidth limit if enabled, Input Coupling, Vertical Sensitivity V/div
17. Indicates the trigger type, the trigger source, the trigger slope, the trigger coupling and the trigger level in Volt.
18. Indicates the sample rate and the current memory depth.
19. Indicates the frequency of the trigger source signal (hardware counter)

Instrument Description (cont'd)

Menu and Control buttons and knobs



Channel buttons CH1, CH2, CH3, CH4

Press the CH1 (or CH2 or CH3 or CH4) button to enable (**ON**) or disable (**OFF**) the channel and to open the CHi configuration menu. When the channel is "On" the button is lit.

Run/Stop

Run : The traces are refreshed continuously, **Stop**: acquisition is Stopped.
Note: In « Stop », use the S/div knob to zoom or compress the trace.

Auto Setup

Automatically sets the oscilloscope controls to produce a suitable display of the input signals.

Wave Gen


Press this button to enable the « **Arbitrary Waveform Generator** »

Default	Press this button to reset the oscilloscope settings to the « Default » configuration
Decode	Press this button to enable and configure the serial bus « Decode » option
Math	Press this button to enable and configure the « MATH » function.
Digital	Press this button to enable and configure the 8 channel « Digital » bus option
Ref	Press this button to open the REF WAVE menu. Use this menu to Save or Recall reference waveforms (REFA REFB REFC REFD) in the internal memory. When a reference waveform is displayed the “Ref” button is lit.
Horiz	Press this button to open the horizontal menu to select the horizontal format : YT, XY or Roll.
Setup TRIG	Press this button to open the TRIGGER menu to select the trigger type : Edge, Slope, Pulse, Video, Window, Interval, DropOut, Runt, Pattern, Serial1, Serial 2 and to configure it.
50%	Push the « Level » knob to obtain a stable trace. The oscilloscope automatically sets the trigger level to be halfway between the minimum and maximum voltage level of the trigger source signal. This is particularly useful when the trigger source is a “non displayed” signal like “EXT TRIG”.
« Auto »	Press this button to enable the Auto mode. In this mode the traces are refreshed in the presence or absence of a trigger event.
Normal	Press this button to enable the Normal mode. In this mode the traces are refreshed only in the presence of a trigger event.
Single	Press this button to enable the « Single » mode trigger. In this mode the oscilloscope performs a single acquisition and then « STOP ».
Utility	Press this button to open the « Utility » menu. The utility menu allows to configure the oscilloscope options such as: Sound, Language, Printer, Date/Hour etc. The Utility menu allows to display the « System Status » and to update the firmware.
Display	Press this button to open the « Display » menu. The display menu allows to configure the display Type, Color, Grid, Persistence, Intensity, Brightness, etc..
Cursors	Press this button to open the « CURSORS » menu. Use the « Universal » knob to position the active cursor. The sliders are displayed after leaving the « CURSORS » menu (except if mode = Off) but can not be adjusted.
Help	Press this button to open the access to the internal Help.
Print	Press this button to open the « Print » menu. The back USB connector must be set on « Printer ».
Measure	Press this button to open the « MEASURE » menu.
Acquire	Press this button to open the « Acquire » menu. The Acquire menu allows to configure the sampling mode : Normal , Peak Detect , Average , High Resolution .
Save / Recall	Press this button to open the « Save/Recall » menu. This menu allows to Save (or Recall) “Setups” in the internal or external memory and “Pictures”, “Waveforms”, “CSV files” in external memory.
Soft Keys	Six soft keys and the « Up » key provide access to submenus.



Instrument Description (cont'd)

Input BNCs , Logic Analyzer Probe Connector, USB host, Probe adjust Output, Arbitrary Waveform Generator Output BNC



Channel input BNC :
CH1, CH2, CH3, CH4

4 BNCs connectors for input signals.

Logic Analyzer

8-channel logic analyzer input connector

USB A

USB host connector

Cal Probe Adjust Output

The « Cal » Output allows compensation of 1/10 attenuating probes.



Arbitrary Waveform Generator Output

Arbitrary Waveform Generator BNC output

Rear Panel Connectors



→ 2 BNCs

1 Aux Output BNC : « PASS/FAIL OUT » or « TRIG OUT » according to setting

1 « EXT TRIG » BNC: External Trig Input

→ USB Device

USB type B Connector : to connect the oscilloscope to a PC or to a « Pictbridge » printer

→ LAN

RJ45 Connector : to connect the oscilloscope to Ethernet LAN



→ Main Supply Socket

Main Supply Input Connector

Universal Knob



You can use it with many functions, such as adjusting the holdoff time, moving cursors, setting the pulse width, setting the video line, adjusting X and Y masks when using the pass/fail function etc. The “Universal” knob allows to adjust the storage location of setups, waveforms, pictures when saving/recalling and to select menu options. When the “Universal” button is active the “Select LED” is lit.

Getting started

Verification of instrument operation

To check the operation of the oscilloscope, perform the following steps:


- Steps** 1. Turn on the oscilloscope.

Press the « **Default** » button of the « **RUN CONTROL** » pad to load the « **default** » configuration of the oscilloscope. Note : The default value for the attenuation compensation coefficient of the probe is 1X.





« Default Setup »

2. Switch the attenuation of the “probe” to the « 1X » position, plug it on CH1 and turn clockwise to block. Connect the probe tip and the ground alligator clip to the terminals “Cal 3V 1kHz” and “Ground” of the probe adjust output.



3. Press the "**Auto Setup**" button to display the “3Vpp, 1kHz” Cal square wave.




4. Press the "**CH1**" button to disable CH1. Then press the "**CH2**" button to enable CH2 and repeat steps 2 and 3 to display the Cal signal on CH2. Repeat the previous steps with the channels CH3 and CH4.

Getting started (cont'd)

Oscilloscope Probe

A guard around the probe body protects fingers from electric shocks.



Before performing a measurement :

Plug the probe in the “BNC” input of the oscilloscope and then connect the alligator clip of the probe to the ground reference potential of the circuit under test.

Note:

- **To avoid electric shock when using the probe, keep fingers behind the probe guard.**
- **To avoid electric shock when using the probe, do not touch the metal parts of the head of the probe when it is connected to a voltage source. Connect the probe to the oscilloscope input and then connect the probe ground lead to the ground reference of the “circuit under test “before performing any measurement.**

Probe Attenuation

The probes can have different attenuation factors that affect the vertical scale of the oscilloscope. Press the corresponding channel button (CH 1 or CH2 or CH3 or CH4), and select the factor that matches the attenuation factor of your probe.

Note : The default value of the probe factor is 1X.

Be sure that the attenuation switch on the probe matches the probe factor in the oscilloscope. The probes supplied with the oscilloscope have two attenuation coefficients : X1 et X10.

Note :


When the attenuation switch is in the X1 position, the probe limits the bandwidth of the oscilloscope to about 6MHz (depending on the characteristics of the probe). To use the full bandwidth of the oscilloscope, be sure that the position of the probe switch is set to X10.

Getting Started (cont'd)

Probe Adjust Warning : The DOX3000 series have a switchable input impedance: $1\text{M}\Omega$ - 50Ω . When using a « **1/10** » probe of $10\text{M}\Omega$ input impedance (= $9\text{M}\Omega$ for the probe + $1\text{M}\Omega$ oscilloscope input) it is imperative to set the oscilloscope input impedance to **$1\text{M}\Omega$** . If we visualize the « **Cal 3V 1kHz** » signal with a 1/10 probe and the oscilloscope input impedance is set to 50Ω , we will see on the screen a near zero amplitude signal because instead of having an attenuation of 1/10, we have an attenuation of 1/180000 (50/9000050).

Manual method of compensating the frequency response of a « 1/10 » probe connected to one channel of the oscilloscope.

- Operation Steps**
1. Open the CH1 menu and set the Probe attenuation factor to 10X and the oscilloscope input impedance to $1\text{M}\Omega$. Set the probe switch to X10 and connect the probe to CH1. If you use the probe hook-tip, insure a proper connection by firmly inserting the tip onto the probe.
 2. Attach the probe tip to the “**Cal 3V 1kHz**” output and the reference lead to the GND connector.
Set CH1 « On » (button lit) and then press the "Auto Setup" button.
 3. Check the shape of the displayed waveform :



4. If necessary, adjust the probe variable capacitor with the supplied screwdriver to get a « **Correctly Compensated** » signal. Repeat when you connect the probe to a different channel or when using another probe.

Note : For more information consult the manual of the probes supplied with the oscilloscope.

Functional Description

AUTO SETUP


Auto Setup








« Auto Setup » button on « RUN CONTROL » block

DOX3000 digital oscilloscopes have an « Auto Setup » function that configures automatically the device to produce a display adapted to the signals at the channel inputs.

After launching an “Auto Setup”, select, if necessary, the type of signal displayed among the four proposed : Several periods, One period, Rising or Falling edge at the center of the screen.



Auto Setup Function

Option	Description
 Multi-cycle	Autoset and displays several cycle signal.
 Single-cycle	Autoset and displays single cycle signal.
 Rising edge	Autoset and displays the Rising edge.
 Falling edge	Autoset and displays the Falling edge.
 Undo config.	The oscilloscope recalls the previous Setup.

The “Auto Setup” sets the trigger source and displays the channels according to the following criteria :

- If multiple channels have an input signal, channel with the lowest frequency signal has the priority.
- If no channel is « On » and no signal is found, no channels are displayed.
- If one or more channels are « On » and no signal is found, only the « On » channels remains active.

Functional Description

AUTO SETUP (cont'd)

« Auto setup » function

Function	Value
Sampling Mode	unchanged
Display Format	Y-T
Display Type	Vectors
Input Coupling	AC
Bandwidth limit	Unchanged
V/div	Set
V/div adjust	Coarse (séquence 1 2 5)
Invert Signal	unchanged
Horizontal Position	Centered
S/div	Set
Trigger Type	Edge
Trigger Source	Auto detection of the signals on the input channels and selection of the proper trigger source.
Trigger Slope	Rising
Trigger Mode	Auto
Trigger Coupling	DC
Holdoff	unchanged
Trigger Level	Adjusted to 50%

« Default » Setup



The oscilloscope is set up for normal operation when it is shipped from the factory. This is the « Default Setup ». To recall this setup, press the « Default » button. Settings may change for options, buttons and controls when you press the « Default » button, refer to appendix B.


The « **Default** » setup does not change the following settings :

- Language option
- Saved reference waveform files
- Saved setup files
- Display settings
- Calibration data

Functional Description

I - VERTICAL System

Vertical knobs and buttons allow to display waveforms and to modify sensitivity and vertical position.



Channels: CH1
CH2 CH3 CH4
page 1

Option	Value	Description
Coupling	DC	DC: passes the AC and DC components of the input signal.
	AC	AC: blocks the DC component of the input signal and attenuates AC components below 10Hz.
	GND	GND: disconnects the input signal.
Bandwidth limit	ON	Limits the channel bandwidth to 20 MHz and reduces high frequency noise.
	OFF	Full bandwidth
Volts/Div	Coarse	Selects the resolution of the Volts/div knob : « Coarse » : defines a 1-2-5 sequence.
	Fine	« Fine » : small steps continuous ajustement.
Probe	.1x, .2x, .5x, 1x , 5x, 10x, 20x, 50x, 100x, 200x, 500x, 1000x, 2000x, 5000x, 10000x	Set to match the attenuation of the probe you are using to ensure correct vertical readouts.
Input Impedance	1MΩ	Selects the channel input impedance. « 1MΩ » : for use with 10MΩ input impedance «1/10» probes.
	50Ω	« 50Ω » : for use with 50Ω cable and 50Ω output impedance Generator to preserve impedance matching which is necessary when working with high frequency signals.
Next Page	Page 1/2	To access page 2/2

page 2

Option	Values	Description
Unit	V A	Vertical unit : Volts or Ampères.
Invert	ON OFF	To invert the channel. To disable inversion.
Next Page	Page 2/2	To access page 1/2.

Functional Description

I - VERTICAL System (cont'd)


**Setting up:
CH1, CH2,
CH3, CH4
channels**

Press the CH1 (CH2, CH3 or CH4) button to open the corresponding channel menu.



**Selecting the
channel Input
Coupling**

- Pressing “CH1” → “Coupling”→ “AC”, Set to AC the CH1 input coupling: The DC component of input signal is blocked.
 - Pressing “CH1”→ “Coupling”→ “DC”, Set to DC the CH1 input coupling: Both DC and AC components of input signal pass.
 - Pressing “CH1”→ “Coupling”→ “GND”, Set the input coupling to GROUND : The input signal is disconnected.
- The CH1 input signal is a positive square wave displayed with DC input coupling:



Proceed similarly to select the input coupling of CH2 - CH3 - CH4

**Bandwidth
Limit**

- Pressing “CH1”→“BW Limit”→ “20M” to enable the channel “Bandwidth Limit”.



« 20M » channel BW limited to 20MHz

The sinusoidal signals ($F > 20\text{MHz}$) are attenuated.

- Pressing “CH1”→ “BW Limit”→ “Off” disable the channel “Bandwidth Limit” : The channel has « full » bandwidth.

Injecting a “<1ns” rise time “1MHz” square wave on channels CH1 and CH2 .

The picture below shows a “1MHz” square wave displayed with the bandwidth limit “20M” on CH2 and with the “full” bandwidth on CH1:



The measured rise time is **1.8ns** on CH1 and **17.20ns** on CH2, the presence of the « **bandwidth limit** » on CH2 leads to a slower rise time.

Functional Description

I - VERTICAL System (cont'd)

Adjusting vertical sensitivity V/div



Vertical scale adjusting has « Coarse » and « Fine » mode, vertical sensitivity range is 2mV/div to 10V/div.


For example, for CH1:

- Pressing “CH1” → “Volts/Div” → “Coarse” → sets “V/div” adjust to “coarse” default value.

Vertical sensitivity can be adjusted in a 1-2-5 sequence from 2mV/div, 5mV/div, 10mV/div to 10V/div.

- Pressing “CH1” → “Volts/Div” → “Fine” → sets “V/div” adjust to “fine” This setting allows a continuous adjustment of the vertical sensitivity between coarse steps.

Note : Pressing the vertical sensitivity button also toggles the setting from « Coarse » to « Fine ».



Bandwidth Limit
« 20M » on CH2

Fine adjust
sensitivity

For example : Use the « Fine » vertical sensitivity adjust to determine the channel bandwidth when the bandwidth limit is « On »:

1° Set the bandwidth limit to 20MHz on CH2 and “Full” bandwidth on CH1

2° Inject on CH1 and CH2 the same “300mVpp, 1kHz” sinusoidal signal

3° Adjust the CH1 vertical sensitivity to 50mV/div (coarse) and CH2 (Fine) to 35mV/div (35mV= 0.7x50mV).

4° Increase the frequency of the generator to obtain a « 6 divisions amplitude » signal on both channels, the frequency measured by the oscilloscope (21.6MHz in our example) is the CH2 cutoff frequency with the bandwidth limit to 20M.


Probe attenuation factor

In the CHi menu, select the probe « factor » that matches the attenuation coefficient of the probe used.

To compensate an attenuation coefficient of 1/10, the probe factor must be set to 10X to integrate the attenuation coefficient of the probe in the vertical sensitivity.

For example if you are using a « 1/100 » probe, the probe factor must be set to 100X :

- Press “CH1” → “Probe” → and select the “100X” factor
- Then the vertical sensitivity range will cover : 200mV/div to 1kV/div



Maximum sensitivity 1kV/div

Probe Factor “100X” to compensate a “1/100” probe

Functional Description


I - VERTICAL System (cont'd)

Inverting Waveforms

For example, on CH1:

- Press “CH1” → “Page Suiv” (“Next Page”) “page 2/2” → “Invert” → “On”:

We show below, the same positive square wave on CH1 with invert « On » and on CH2 with invert « Off »



Input Impedance

- Press “CH1” → « Impedance » → and select the channel input impedance « 1MΩ » or « 50Ω ».

- 1MΩ input impedance is necessary when using 1/10 probes:

The “1MΩ” impedance allows to compensate the « 1/10 » probes by adjusting its variable capacitor : « 9MΩ/Var. Cap ».


The « 1MΩ » impedance is particularly well suited to « low frequency » and “high voltage” signals.

- « 50Ω » impedance : for use with 50Ω cable and 50Ω output impedance Generators to preserve impedance matching .

“50Ω » impedance is particularly well suited to « High Frequency » and « Low voltage » signals.


- In the example below we show a fast rising edge (<1ns) square wave on CH1 with an impedance of 50Ω and 1MΩ

1° CH1 input impedance « 50Ω » :



The rise time = **1.5ns** and the amplitude = **286mV**

2° CH1 input impedance « **1MΩ** » :



The rise time = **2.2ns** and the amplitude = **576mV** (twice that obtain with « **50Ω** »)

Conclusion : The « **50Ω** » input impedance is best suited to observe fast rising edge waves provided by 50Ω output impedance generators.

**Vertical Unit
V ou A**

- Press “**CH1**” → “Next Page page2/2” → “Unit” → and select the vertical unit : **Volt** or **Ampere**.

Functional Description

I - VERTICAL System (cont'd)

2. Vertical Knobs

Vertical Position knobs



1. Use the vertical "Position" knobs to move traces up and down the screen. The vertical position variation range is :

+/- 1V for vertical sensitivities from 2mV/div to 100mV/div

+/- 10V for vertical sensitivities from 102mV/div to 1V/div

+/- 100V for vertical sensitivities from 1.02V/div to 10V/div

2. While you adjust the trace vertical position the "Volts Pos=" value is displayed on the screen.

3. Push the vertical "Position" knob to set the vertical position to zero (= screen center).

Vertical Sensitivity Volts/div



1. Use the "Volt/div" knob to adjust the vertical sensitivity. When you turn clockwise or counter-clockwise the sensitivity increases or decreases.

2. Push the "Volt/div" knob, to toggle between **Coarse** and **Fine** adjust.


"Coarse" Vertical sensitivity can be adjusted in a 1-2-5 sequence from **2mV/div, 5mV/div, 10mV/div to 10V/div** (12 steps).

"Fine" a continuous adjustment of the vertical sensitivity from **2mV/div to 10V/div**.

3. Save and Recall Reference Waveform

The REF menu allows to save (or recall) reference waveforms in four internal memorie locations : REFA - REFB - REFC and REFD.

Press the « **Ref** » button to open the REF menu :




REF Menu

Option	Value	Description
Source	CH1 CH2 CH3 CH4 Math	Select the waveform to save
REFA REFB REFC REFD		Select the REF memory location.
Save		Save the waveform in the selected memory location
REFA/REFB/ REFC/REFD	On Off	Recall and Display the selected REF. Clear the displayed REF waveform.



Operation Steps

1. Press the "Ref" button to open the REF menu.
2. Press the "Source" button to select the reference source : **CH1** or **CH2** or **CH3** or **CH4** or **Math**.
3. Use the "Position" and "V/div" knobs to set the vertical position and the sensitivity to the proper values.
4. Press the "REF A" (or **REF B** or **REFC** or **REFD**) button to select the REF memory location.
5. Press the « **Save** » button to save the REF waveform.
6. Select **REF A** (ou **REF B** ou **REFC** ou **REFD**) Display "**ON**" to display the REF waveform

 **The reference trace is displayed in blue color.**


Functional Description

I - VERTICAL System / MATH Functions

Menu MATH

The « **MATH** » menu displays the results of mathematical operations: +, -, *, /, FFT, d/dt, ∫dt and √ on channels CH1, CH2, CH3, CH4 and REFA, REFB, REFC, REFD waveforms.

Press the « **Math** » button to open the **MATH** menu.



MATH Menu

Function	Value	Description
Operation	+, -, *, FFT, d/dt, ∫dt and √	Select the mathematical function.
Source A	CH1, CH2, CH3, CH4, REFA, REFB, REFC, REFD	Select the Math source
Source B		
Invert	On Off	Invert the MATH waveform. “Invert” is disable.
Vertical Position		Use the vertical « Position » knob to adjust the MATH waveform vertical position.
Vertical Scale		Use the « Variable » knob to adjust the MATH vertical scale.

Mathematical operations

Opération	Value	Description
+	CHi+CHj	CHi added to CHj.
-	CHi-CHj	CHj subtracted from CHi.
*	CHi*CHj	CHi multiplied by CHj.
/	CHi/CHj	CHi divided by CHj.
FFT	Fast Fourier Transform.	
d/dt	Derivative	
∫dt	Integral	
√	Square Root	

Example of Math function: CH1+CH2



Functional Description

I - VERTICAL System / MATH Funtion (Cont'd)

« Fast Fourier Transform »

The “Fast Fourier Transform « FFT » process” mathematically converts à time domain signal into its components in the frequency domain.

Two measurements are available on the FFT spectrum : Magnitude (in Vrms or dBVrms) and Frequency (in Hz).

Menu FFT

FFT Option	Setting	Description
Operation	FFT	
Source	CH1, CH2, CH3, CH4, REFA, REFB, REFC, REFD	Select the FFT source channel.
Window	Hanning, Hamming Rectangulaire Blackman	Select the FFT window type.
FFT ZOOM	1X, 2X 5X,10X	Changes the horizontal magnification of FFT display.
Vertical « Scale »	Vrms, dBVrms	FFT vertical scale
FFT « Display »	Split Full Screen	Displays the FFT spectrum on half screen Displays the FFT spectrum on full screen

How to use FFT To use the FFT Math function, select the time domain signal source Y(t):

- Press « **Auto Setup** » button to display the Y(t) signal and select Multi cycles.
- Push the vertical “**Position**” knob to reset the vertical position to zero divisions (screen center).
- Use the horizontal “**Position**” knob to position the Y(t) signal portion to be analyzed with the FFT, in the center of the screen.
The oscilloscope calculates the FFT spectrum using the center 1024 points of the time-domain waveform.
- Turn the “**V/div**” knob to ensure that the entire waveform remains on the screen.
- Turn the “**S/div**” knob to provide the resolution you want in the FFT spectrum.

Operation Sequence To display the FFT correctly:

1. Push the “**Math**” button.
2. Set the “**Opération**” option to « **FFT** ».
3. Press the “**Source**” button and select the channel “**CH1**” or “**CH2**” or “**CH3**” or “**CH4**” or “**REFA**” or “**REFB**” or “**REFC**” or “**REFD**”.
4. To comply with the Nyquist-Shanon theorem turn the “**S/div**” knob to adjust the sampling rate (displayed on top righth of the screen) at least twice the frequency of the input signal.
5. To determine the appropriate value for the “**S/div**” coefficient, compare the FFT horizontal scale to the frequency displayed by the hardware counter, on the top righth of the screen.

Functional Description

I - VERTICAL System / MATH Function (cont'd)

2) Displaying the FFT Spectrum

Press the « **Math** » button to display the MATH menu. Use the options to select: the Source channel, the Window, and the FFT Zoom Factor. You can display only one FFT spectrum at a time. You can select "**Full Screen**" or "**Split**" in the **Display** option to display the waveform and its FFT spectrum on full screen, or the waveform and the FFT on half screen at a time.


With « Split » display and « Cursors » Off, you can display simultaneously: The entire Waveform, a Zoom portion and the FFT spectrum.




FFT Menu: Source - Window - FFT Zoom - Scale - Display

We inject on CH1 a sine wave: frequency = 21.7MHz and amplitude=896mVpp

We will use the « **Hanning** » window to calculate the FFT, to determine the frequency and the amplitude of the fundamental :



Using the "X1" manual cursor we can determine the frequency (**X1=21.8MHz**) of the fundamental



And using the “Y1” manual cursor we can determine the amplitude (Vrms)
Y1=316mVrms $\approx (896\text{mV}/2) \times 0,707 = 316,7\text{mVrms}$

3) Selecting the FFT window

The FFT window reduces spectral leakage in the FFT spectrum. The **FFT** assumes that the Y(t) waveform repeats indefinitely. With an integer number of cycles, the Y(t) waveform starts and ends at the same amplitude and there are no discontinuities in the signal shape. A non-integer number of cycles in the Y(t) waveform causes the signal start and end to be at different amplitudes. The transition between the start and end points causes discontinuities in the signal that introduce high frequency transients.

Window	Speciality	Adapted to
Rectangular	Best frequency resolution, worst magnitude resolution. This is essentially the same as no window.	Symmetric transients or bursts. Equal amplitude sine waves with fixed frequency. Broadband random noise with relatively slowly varying spectrum.
Hanning Hamming	Better frequency resolution and poorer magnitude accuracy than Rectangular. Hamming has slightly better frequency resolution than Hanning.	Sine, periodic, and narrow-band random noise. Asymmetric transient or bursts.
Blackman	Best magnitude and worst frequency resolution.	Single frequency waveforms, to find higher order harmonics

Functional Description

I - VERTICAL System/ MATH Function (cont'd)

FFT:Vertical and Horizontal Scale, Vertical and Horizontal Position

You can magnify and use cursors to take measurements on the FFT spectrum.

The oscilloscope includes an **"FFT Zoom"** option to magnify horizontally, press this button to select : "1X", "2X", "5X", or "10X".

The FFT spectrum can be moved horizontally using the horizontal « **Position** » knob.

The FFT spectrum can be moved vertically using the Math « **Vertical** » knob.

The Math « **Variable** » knob allows to adjust the FFT vertical scale.

5) Measuring the FFT spectrum with Cursors

Amplitude

Two types of measurements are possible on the FFT spectrum :

Amplitude : in dBVrms or Vrms and

Frequency : in Hz

1. Input a sine wave to CH1 and press the **"Auto Setup"** button then select the "Multi cycles" option.
2. Press the **"Math"** button to open the "MATH" menu.
3. Press the **"Opération"** button and select **"FFT"**
4. Press the **"Source"** button and select **"CH1"**
5. Press the **"CH1"** button to open the CH1 menu.
6. Turn the **"S/div"** knob to adjust the sample rate (at least the double than the input signal frequency).
7. If the FFT display is on full screen, press CH1 button again to remove CH1 waveform from display.
8. Press the **"Cursors"** button to open the CURSORS menu.
9. Press the cursor **"Mode"** button and select **"Manual"**.
10. Select the « **Yi** » cursor type
11. Press the **"Source"** button and select **"MATH"**
12. Select the **"Y1"** cursor, and use the "Universal" knob to move "Y1" to the highest amplitude component of the FFT spectrum.
13. Select the **"Y2"** cursor, and use the "Universal" knob to move "Y2" to the lowest amplitude component of FFT spectrum.
14. The amplitude (ΔV) displays on the top left of the screen.

In the following example we will consider a composite periodic signal :
fundamental frequency **5MHz** and 20MHz - 35.6MHz spectral components

The FFT displays the fundamental (F=5MHz Amplitude =2.66 Vrms) and two spectral components at 20MHz and 35.6MHz of Amplitude=0.4Vrms

Using Yi horizontal cursors to measure the amplitude of spectral components




Functional Description

I - MATH Function (cont'd)


Measure frequency with « Xi » Vertical Cursors

1. Press the « **Cursors** » button
2. Press cursor "**Mode**" button and select "**Manual**".
3. Select "**Xi**" vertical cursor type
4. Press the "**Source**" button and select "MATH".
5. Select the "**X1**" cursor, and use the "Universal" knob to move "X1" to the highest amplitude component of the FFT spectrum.
6. The value "**X1=5.00MHz**" displayed on the top left of the screen is the frequency of the fundamental of the CH1 input signal.

Use vertical cursors to measure the frequency of the spectral components



Fundamental frequency X1=5MHz and the harmonic X2=35.6MHz



Frequency of the two harmonics: X1=20MHz and X2=35.6MHz

FFT of « Cal 3V 1kHz »

- 1° Enter the « **CAL 3V 1kHz** » signal on CH4 with a 1/1 probe
- 2° Channel CH4 coupling = DC
- 3° Select 1.4Mpts memory depth and a 500ms/div Time Base
- 4° Select the FFT Math function with a « **Blackman** » window (highest amplitude resolution) and FFT Zoom = « **X10** » so that the horizontal scale is 1kHz/div.
- 5° Set the FFT vertical scale to Vrms
- 6° Use the manual cursors to measure the amplitude of the fundamental (1kHz) and the first harmonic (3kHz) :



The fundamental (1kHz) amplitude is $Y1=1.12V_{rms}$ (close to $1.06V_{rms} = 1.5V / 1.414$)

Note : The « Cal 3V 1kHz » output provides a positive square wave, if the input coupling is « DC » we observe a **DC component in the FFT spectrum**.

Set the input coupling to « **AC** » to block the DC component of the « CAL 3V 1kHz » signal to obtain a FFT spectrum **without DC component** :



Warning : The presence of a DC component can hinder the observation of low-frequency components of the signal.


With FFT math function, the use of AC input coupling is recommended.

Functional Description

II - HORIZONTAL System

HORIZONTAL Menu

The "HORIZONTAL" pad contains two buttons (**Horiz** and **Zoom**) and two knobs (**S/div** and **Horizontal Position**).




HORIZONTAL Menu



« Horiz » button of the HORIZONTAL pad

Option	Setting	Description
Format	YT	«YT» : Displays the voltage (on the vertical axis) versus time (on the horizontal axis).
	XY	«XY» : To display in « XY » mode the two channel couples [CH1(X), CH2(Y)] and [CH3(X), CH4(Y)]
	ROLL	Time Base coefficient >100ms. The traces scroll from the right to the left of the screen as in a recorder, the "Roll" format is suitable for slow signals. In « ROLL » there is no trigger or horizontal position control. Warning : When working with very low frequency signals (<10Hz) the DC input coupling is not recommended.

ROLL mode example



Note : The hardware frequency counter does not work for frequencies <10Hz

Functional Description

II - HORIZONTAL System (cont'd)

HORIZONTAL pad



The "HORIZONTAL pad" knobs allow to adjust the Time Base coefficient « S/div » and the traces horizontal Position.

The two buttons allow to open the HORIZONTAL menu ("Horiz") and to activate the "Zoom" function.

Horizontal "POSITION" knob



1. Adjusts the trace horizontal position (the trigger position relative to the center of the screen). The time resolution of this command depends on the selected Time Base coefficient.

2. To reset to zero the horizontal position, push the "Position" knob.

S/div knob



1. Adjusts the Time Base coefficient. When the acquisition is stopped (with "RUN/STOP" button or in "SINGLE" mode), turn the « S/div » knob to expand or compress the waveform.

2. « S/div » knob adjusts the coefficient of the « Main » or « Zoom » Time Bases. In **Zoom** mode, changing the Time Base coefficient (S/div) modifies the width of the « Zoom » window.


Horizontal Zoom




Use the horizontal "Zoom" function to define the portion of the waveform to be observed in details. The slowest « zoom » time base coefficient may not be lower than the "main" time base coefficient.


Use the horizontal « **Position** » knob to move the « zoom window » position and the « **S/div** » knob to magnify or compress the "zoom window".


"M" stands for « Main » time base, "Z" stands for "Zoom" time base.

The vertical « **blue** » arrows  indicate the horizontal position of the trigger event in the Main time base and in the "Zoom" window.

The horizontal « **yellow** » arrow  indicate the vertical position of the trigger level.

Note: The display of the « Trigger Position » symbol in the "zoomed window" is only possible if the position of the "zoomed window" includes the trigger event.

If the trigger event is outside the "zoomed window" the horizontal blue arrow  indicates the direction in which to move the "zoomed window" to display the trigger.




Operation Steps

To display in details a portion of the waveform:

1. Press the "**Horiz**" button to open the HORIZONTAL menu.
2. Turn the "**S/div**" knob to adjust the main timebase.
3. Press the « **Zoom** » button to activate the horizontal Zoom.
4. Turn the « **S/div** » knob to adjust the "Zoom" time base.
5. Turn the horizontal "**Position**" knob to move the zoom window.

In the example below, we display in « Zoom » mode, a detail (a 0.24µs wide window with a resolution of 0.5ns situated at 235µs from the trig event) of a signal acquired at 2GSPS sample rate with a memory depth of 28Mpoints. The oscilloscope has recorded the evolution of the signal during a lapse of time of 14ms with an elementary time step of 0.5ns :

The arrows indicates the delay value (Delay=235µs) relative to the trigger event and the signal value for this delay :



We can « Stop » the trace refresh (« **Run/Stop** » button) to observe it in detail.

For example we can determine the value that the signal has 74ns before the trigger event by moving the zoomed window (Horizontal « Position » knob):

The red arrows indicate the value of the signal at the trigger event and 74ns before :




Functional Description


III - Trigger System

TRIGGER Menu


The DOX3000 oscilloscope series have a **digital** trigger system that has the following advantages:

Precise Trigger - Low « Jitter » - High Sensitivity
Precise Trigger timing < 1ns - Configurable noise reject
High stability with temperature

A hardware counter allows to display the frequency of the trigger source signal in the top right of the screen 


The « **Setup** » button gives access to the « Trigger » setting menu. The trigger symbol  indicates when the “trigger event” has occurred. The “trigger event” divides the acquisition memory in two parts:

- The « Pre-Trig Buffer » before the trigger event and
- The « Post-Trig Buffer » after the trigger event




The DOX3000 oscilloscope series have eleven trigger modes: Edge, Slope, Pulse, Video (HDTV), Window, Interval, Dropout, Runt, Pattern, Serial 1, Serial 2 (Serial bus: I2C, UART, SPI, CAN, LIN)

TRIGGER pad



- « **Setup** » : Press the « **Setup** » button to open the TRIGGER menu.
- “**Level**” knob: Use the LEVEL knob to adjust the trigger level. Push the “**Level**” knob to set the trigger level to **50%** of the peak to peak amplitude of the signal. This function is very useful in “Single” or “Normal” trigger modes.
- “**Auto**” button : The waveform is refreshed even in the absence of a trigger event.
- « **Normal** » button: in « Normal » mode the trace is refreshed only if a trigger event occur.

- **"Single"** button: Press the **"Single"** button to activate the SINGLE mode. In this mode only one acquisition is allowed at a time.
- **Pre-trig/Post-trig/Trig-Delay:** Datas before and after the trigger event . If the trigger symbol  is at the center of the screen, the portion of the traces corresponding to the first 7 divisions represent the pre-trig and the 7 following divisions the post-trig.
This function is very useful because you can observe the samples that occur before and after the trigger event. Everithing that is to the right of the trigger event corresponds to the post-trig.

Trigger SOURCE

In « **Edge** » mode : the trigger source may be the signal to the following inputs : CH1, CH2, CH3, CH4, EXT, EXT/5 or AC line.

For the other trigger modes (**Slope, Pulse, Vidéo, Window, Interval, DropOut, Runt, Pattern** and **Serial 1 & 2**) the 4 possible trigger sources are: CH1, CH2, CH3 and CH4.





Functional Description

III - TRIGGER System (cont'd)

1. Edge

Trigger
« Edge »

Option	Settings	Description
Type	Edge	The rising or falling edge of the signal source is used to trigger. 
Source	CH1 CH2 CH3 CH4	Note : The trigger source is active even if the channel is off.
	EXT	The EXT TRIG source signal is not displayed. The EXT source is the signal to the "EXT TRIG" input BNC in the back of the oscilloscope. The trigger level adjustment range is: -1,6V to +1,6V.
	EXT/5	Same as EXT option, but the signal is attenuated by a factor of 5. The trigger level range is multiplied by 5 : -8V to +8V.
	AC line	The trigger source signal is the AC line. The trigger coupling is set to « DC » and the trigger level to 0V.
Slope		Trigger on the rising edge of the source signal. Trigger on the falling edge of the source signal. Trigger on the rising and falling edges of the source signal.
Holdoff	Adjustable Fixed	Use the « Universal » knob to adjust the « holdoff ». The « holdoff » is fixed to the latest set value
Coupling	DC	All components of the signal source passes
	AC	Blocks the DC component and attenuates the AC signal below 5.8Hz.
	Low Pass Filter HF reject	Attenuates « high frequency » components above 1.27MHz.
	High Pass Filter LF reject	Blocks the DC component and attenuates the « low frequency » components below 2.08MHz.
Noise Reject	On Off	Enable or Disable the Noise Reject

Operation Steps

1. Set the trigger type

- 1) Press the "Setup" button to open the TRIGGER menu.
- 2) Press the "Type" button and select "Edge".

2. Set the trigger Source

Press the "Source" button and select the trigger source: "CH1", "CH2", "CH3", "CH4", "EXT", "EXT/5" or "AC Line".

3. Set the trigger slope

Press the « Slope » button and select the trigger slope "  ", "  " or "  ".

4. Set the Holdoff

Press the « Holdoff close » button → « Holdoff time » and use the "Universal" knob to adjust the « Holdoff » time.

5. Set the Trigger coupling

- a. Press the "Set Up" button to open the trigger settings menu.
- b. Press the "Coupling" button and select the coupling type: "DC", "AC", "HF Reject" or "LF Reject".


Functional Description

III - TRIGGER System (cont'd)

2. «Pulse»

Use the **Pulse** type to trigger on a particular “pulse width” with respect to the entire signal.

Pulse Trigger
page 1

Option	Settings	Description
Type	Pulse	Select the trigger pulse type and width.
Source	CH1, CH2, CH3, CH4	Select the trigger source.
Polarity		Select the pulse polarity : Positive or Negative
Limite Range	< (Pulse width less than pulse width setting) > (Pulse width larger than pulse width setting) <> (Pulse width outside the range of set values) >> (Pulse width in the range of set values)	Select the condition that the pulse width must meet to obtain a trigger event.
Set the width	2,0ns to 4,2s	Use the « Universal » knob to set the pulse width.
Next page 1/2		Press this button open page 2/2




Functional Description

III - TRIGGER System (cont'd)

Pulse Trigger
page 2

Option	Settings	Description
Type	Pulse	
Coupling	DC AC LF Reject HF Reject	Select the trigger coupling.
Noise Reject	On	Noise Reject enable
	Off	Noise Reject disable
Next Page 2/2		Press this button to open the page 1/2



Operation Steps 1. Select the type

- 1) Press the « **Setup** » button to open the “TRIGGER” menu.
- 2) Press the “**Type**” button and select “**Pulse**”

2. Set the condition

Polarity :  ,  ,

Press the “**Limit Range**” to select the condition

“<”, “>”, “<>” or “><”

3. Set the pulse width

Use the “Universal” knob to set the pulse width limit.


Functional Description

III - TRIGGER System (cont'd)

«VIDEO» Trigger To trigger on « Lines » or « Frames » of standard video signals.

Video Trigger

Option	Settings	Description
Type	Video	To trig on video signals: NTSC, PAL/SECAM, HDTV and custom.
Source	CH1, CH2, CH3, CH4	Select the trigger source.
Standard	NTSC - PAL/SECAM 720p/50 - 720p/60 1080p/50 - 1080p/60 1080i/50 - 1080i/60 Custom	Select the video standard
Sync	Any line Line Number Field	Choose the appropriate video trigger: Any line - Line Number - Field 1 - 2



Operation Steps

1. Set the type

- 1) Press the “**Setup**” button to open the TRIGGER menu.
- 2) Press the “**Type**” button and select “**Video**”

2. Set the Sync

- 1) Press the “**Sync**” button to select “Any line”, or “Line Number” (select), Field 1 or 2.
- 2) If you choose « Select », use the “Universal” knob to set the line number.

3. Set the Standard

- 1) Press the “Standard” button and select “PAL/SECAM” or “NTSC” or




Functional Description


III - TRIGGER System (cont'd)

« Slope »

« Slope » Trigger
page 1

Trigger on a positive or negative slope whose duration is specified.

Option	Settings	Description
Type	Slope	Trigger on a positive or negative slope of specific duration.
Source	CH1, CH2 CH3, CH4	Select the trigger source.
Slope	 	Positive slope Negative slope
Limit Range	< , > < > > <	Select the trigger condition on slope duration. < Less than > Greater than < > Outside the limited range > < Inside the limited range
Duration		Use the "Universal" knob to adjust the slope duration in the range: 2 ns to 4.20s.
Next Page	1/2	



Functional Description

III - TRIGGER System (cont'd)

Slope Trigger
page 2

Option	Settings	Description
Type	Slope	
Level	Lower Upper	Select the level (L1 or L2) to adjust with the trigger "Level" knob. You can adjust the two levels 'L1' & "L 2" that define the slope.
Coupling	DC - AC LF Reject HF Reject	Select the trigger coupling
Noise Reject	On Off	
NextPage	Page 2/2	Press this button to open page 1/2



Operation Steps

1. Enter the signal on CH1 or CH2 or CH3 or CH4.
2. Press the "Auto" button.
3. Press the "Setup" button to open the "Trigger Menu".
4. Press the "Type" button and select "Slope".
5. Press the "Source" button and select "CH1" or "CH2" or "CH3" or "CH4".
6. Press the "Limit Range" button and select the condition: "<", ">", "<>", "><".
7. Press the "Time" button and use the "Universal" knob to adjust the slope duration.
8. Press the "Next Page" button to open page 2/2.
9. Press the "Lower Upper" button to select the level to adjust L1 or L2.
10. Use the "Level" knob to adjust L1 or L2.

Functional Description

III - TRIGGER System (cont'd)

« Window » trigger When the « window » trigger type is enabled, the oscilloscope triggers when the signal exits, the window defined by the two levels L1 and L2, from the top or bottom level.



Window Trigger
page 1



Option	Settings	Description
Type	Window	The window is defined by two voltage levels L1 and L2.
Source	CH1, CH2, CH3, CH4	Select the trigger source CH1 or CH2 or CH3 or CH4
Window type	Absolute	Absolute: the two levels are set independently Relative: we adjust the delta on either side of a central value.
	Relative	
	Lower Upper Center Delta	The trigger window is define by the lower and upper value or by the delta relative to a central value.
Coupling	DC AC LF Reject HF Reject	Trigger source coupling
Noise Reject	ON Off	Enable (On) or Disable(Off) the noise reject

Functional Description

III - TRIGGER System (cont'd)

Interval Trigger

page 1

Option	Settings	Description
Type	Interval	In this mode the trigger event occur on the second edge, when the time interval between two consecutive edges is : < or > or <> or >< to the set value.
Source	CH1, CH2, CH3, CH4	Select the trigger source CH1 or CH2 or CH3 or CH4
Slope		Select the slope (Rising or Falling) that starts the interval
« Limit Range »	< , > <> , ><	Trigger Condition: < Less than > Greater than <> Outside the window >< Inside the window
Duration		Range : 2ns à 4.20s
Next Page	1/2	To open page 2/2





« Interval » Trigger page 2


Option	Settings	Description
Type	Interval	
Coupling	DC - AC - LF Reject - HF Reject	Trigger source coupling.
Noise Reject	On Off	Enable or Disable noise reject
Next page	2/2	open page 1/2

Functional Description

III - TRIGGER System (Cont'd)

« DropOut »
trigger
page 1

Option	Settings	Description
Type	DropOut	A trigger event occurs if the signal disappears for a time longer than the specified « DropOut » duration.
Source	CH1, CH2 CH3, CH4	Select the trigger source CH1 or CH2 or CH3 or CH4
Slope		Select the edge (state) that reset the dropout duration.
Over Time type	Edge State	
Duration		« DropOut » duration range : 2ns to 4.20s
Next Page	1/2	open page 2/2





« DropOut »
page 2

Option	Settings	Description
Type	DropOut	
Coupling	DC AC LF Reject HF Reject	Trigger source coupling.
Noise reject	On Off	Enable or disable noise reject.
Next Page	2/2	Open page 1/2

Functional Description


III - TRIGGER System (cont'd)

« Runt »
Trigger
page 1

Option	Settings	Description
Type	Runt	A trigger event occurs if the pulse (negative or positive) crosses the first level (L1) but not the second level (L2) of the window, before recrossing the (L1) level in a given time.
Source	CH1, CH2, CH3, CH4	Select the trigger source CH1 or CH2 or CH3 or CH4
Polarity		Select the pulse polarity : Positive or Negative
Limit Range	< , > <> , ><	Select the limits for « Runt » < Less than > Greater than <> Outside the window >< Inside the window
Duration		« Runt » duration range : 2ns - 4.20s
Next Page	1/2	Open page 2/2



« Runt »
Trigger
page 2


Option	Settings	Description
Type	Runt	
Time		Use the "Universal" knob to adjust the Runt duration in the range : 2ns to 10s.
Lower - Upper		Use the Level knob to adjust the Lower and Upper levels 'L1' and 'L2'.
Coupling	DC AC LF Rej HF Rej	Trigger source coupling.
Noise Reject	On Off	Enable or disable the « Noise Reject ».
Next Page	2/2	Open page 1/2

Functional Description

III - TRIGGER System (cont'd)


« Pattern »
Trigger
without the
« Digital » option
page 1

Option	Settings	Description
Type	Pattern	Triggers when the «pattern» condition goes from false to true. We can also adjust the time duration of the pattern "true" condition. Note : Input coupling must be : DC.
Inputs CHi	CH1 CH2 CH3 CH4	Select the Pattern inputs and the active level : Low High Invalid
Next Page	Page 1/2	Open page 2/2




Trigger type
« Pattern »
Without the
Digital option
page 2

Option	Settings	Description
Type	Pattern	
Logic	AND, OR NAND, NOR	Fonction
Limit Range	< > <> ><	« True » pattern duration condition limit
Duration	↻	Use the "Universal" knob to adjust the duration of the pattern « true » condition in the range: 2 ns to 4.20s.
HoldOff Time		Setting range : 100ns to 1.50s.
« Next page »	2/2	open page 1/2



« Pattern » with
« Digital » option
page 1/4

Option	Settings	Description
Type	Pattern	Triggering when the «pattern» condition goes from false to true. We can also adjust the time duration of the pattern “true” condition. Note : Input coupling must be : DC.
Inputs CHi	CH1 CH2 CH3 CH4	Select the Pattern inputs and the active level : Low High Invalid
Next Page	Page 1/2	Open page 2/2



We inject on CH4 the « Cal 3V 1kHz » signal and on the 8bit digital bus square waves of frequency 68Hz.

« Pattern » with
« Digital » option
page 2/4

Option	Settings	Description
Type	Pattern	Digital inputs : select the logic type to set automatically the threshold : TTL - CMOS - LVCMOS3.3 - LVCMOS2.5 or Custom
Di Inputs	D0 D1 D2 D3	Select the pattern inputs and the active level: Low High Invalid
Next Page	Page 2/4	Open page 3/4



Pattern with the
Digital option
page 3/4

Option	Valeurs	Instruction
Type	Pattern	Digital inputs : select the logic type to set automatically the threshold : TTL - CMOS - LVCMOS3.3 - LVCMOS2.5 or Custom
Di Inputs	D4 D5 D6 D7	Select the pattern inputs and the active level: Low High Invalid
Next Page	Page 3/4	Open page 4/4



Pattern with the
Digital option
page 4/4





Option	Settings	Description
Type	Pattern	
Logic	AND, OR NAND, NOR	Function
Limit Range	< , > <> , ><	True pattern duration limit
Durée	↻	Use the "Universal" knob to adjust the « true » pattern duration within the range : 2 ns à 4.20s.
HoldOff		Setting range : 100ns to 1.50s.
Next page	4/4	Open page 1/4



More details → § XI - DIGITAL, option.

Functional Description



III - TRIGGER System (cont'd) (*)

Option	Settings	Description	
« Serial1-2 » Trigger	Serial1	I2C	
	Condition	Start - Stop - Restart - No Ack	
	Condition	EEPROM	
		Limit Range	= , > , <
		Data1	0xXX
	Condition	7 Addr & Data	
		Addr, Data 1, Data 2	0xXX, 0xXX, 0xXX
		R/W bit	Write - Read - Dont Care
	Condition	10 Addr & Data	
		Addr, Data1, Data2	0xXX , 0xXX , 0xXX
	R/W bit	Write - Read - Dont Care	
Condition	Data Length		
	Address	7bit 10bit	
	Byte Length	1 to 12 adjustable	

Functional Description

III - TRIGGER System (cont'd) (*)

Trigger
« Serial 2 »




Option	Settings	Description
Serial 2	SPI	SPI is the default setting on Serial 2 
Trigger Setting	SPI Trigger Setting	
	Trigger type	MOSI MISO
	Data Length	4 to 96 adjustable
	Bit Roll	0 to 95
	Bit Value	0 1 X
	All Same	0 1 X
	Bit Order	MSB LSB



Further informations : § DECODE : Decode bus SPI/I2C/UART/LIN/CAN

Functional Description




III - TRIGGER System (cont'd)

<i>Trigger</i> « Serial1-2 »	Option	Settings	Description
	Serial1	UART/RS232	Trigger on UART/RS232 serial bus. 
	Trigger Setting		
		Source Type	RX TX
		Condition	Start - Stop - Data - Parity error
	Bus Configure		
		Baud	600-1200-2400-4800-9600-19200-38400-57600-115200-Custom
		Data Length	5 - 6 - 7 - 8
		Parity Check	None - Odd - Even
		Stop Bit	1 - 1.5 - 2
		Idle Level	Low - High

Functional Description




III - TRIGGER System (cont'd)

Trigger
« Serial 1-2 »

Option	Settings	Description
Serial 1	CAN	Trigger on CAN serial Bus 
Trigger Setting		
	CAN TRIG SET	Start - Remote - ID - ID+DATA - Error
Bus Configure		
	Baud	5kb/s-10kb/s-20kb/s-50kb/s-100kb/s-125kb/s-250kb/s-500kb/s-800kb/s-1Mb/s-Custom

Functional Description

III - TRIGGER System (cont'd)

<i>Trigger</i> « Serial1-2 »	Option	Settings	Description
	Serial1	LIN	Trigger on LIN serial Bus. 
	Trigger Setting		
		Condition	Break - ID - ID+DATA - Data Error
	Bus Configure		
		Bit Rate	600-1200-2400-4800-9600-19200-Custom

Functional Description

III - TRIGGER System (cont'd)

Trigger COUPLING



Use the appropriate coupling to the trigger source signal.

To select the trigger coupling, first press the "**Setup**" button to open the trigger menu and select the trigger type : "Edge", "Pulse", "Video", "Slope", "Window", "Interval", "DropOut" or "Runt" then press the "Coupling" submenu and select the coupling of the trigger source: CH1 or CH2 or CH3 or CH4.

Four types of coupling are available : AC - DC - LF Reject - HF Reject

Horizontal POSITION



The horizontal « **Position** » knob allows to adjust the interval of time between the trigger event  and the screen center. The horizontal "**Position**" knob allows to adjust the display portion of the waveform before or after the trigger event . The horizontal position reference is the center of the screen, the "**Position**" (**Delay :**) is positive on the left side of the screen and negative on the right side.


Trigger Slope & Trigger Level



The "Slope" and "**Level**" control define the trigger point.

The "slope" polarity (Edge trigger type only) determines which signal edge (Rising or Falling or both) causes the trigger.

The **Level** knob controls the vertical position (voltage) of trigger threshold.



Note :

- **Use the SINGLE shot mode to capture a single signal (not repetitive).**
- **The trigger source coupling does not affect the bandwidth of the displayed channel.**


Functional Description

III - TRIGGER System (cont'd)

HOLDOFF

Triggering Inhibition time

Use the « Holdoff » to obtain a stable display in the case of complex signals such as pulse bursts. The "HoldOff" represents the time interval between the detection of a valid trigger event and the moment when the oscilloscope is ready to detect a new trigger event. The oscilloscope will not trigger during the Holdoff time, because the trigger circuit is inhibited. With "pulse bursts", set the Holdoff equal to the burst length, so that the oscilloscope will trigger on the first pulse of the burst masking the other pulses.



Operation Steps

To set the Hold-Off :

1. Press the "Setup" button to open the TRIGGER Menu.
2. Press the "Type" button and select the trigger type.
3. Press the "Holdoff" button and use the "Universal" knob to adjust the Holdoff.
4. Set the HoldOff time to obtain a stable waveform.

Note : *With periodic complex waveforms use the « Holdoff » to stabilize the display.*


Example : We display on CH3 with the option Color « On » a periodic signal (generated by the DOX3304 AWG) having two rising edges separated by $392\mu\text{s}$ (measured with the manual cursors $\Delta T = X2 - X1 = 390\mu\text{s} - (-2\mu\text{s}) = 392\mu\text{s}$).

Color : is « On » (Color grading: Red corresponds to frequent points and Blue to rare points) and the "Edge" trigger type.


If the holdoff is less than $392\mu\text{s}$ we observe double triggers instability : The most frequent triggering is on the first rising edge (Red trace) and rarely on the second rising edge (Blue trace).

If the holdoff is greater than $392\mu\text{s}$ the trigger event is always on the same edge the oscilloscope displays only a red trace.

Holdoff = **355 μ s** < 392 μ s
 the oscilloscope displays two waveforms resulting from a double triggering (Blue and Red waveforms)



Holdoff = **393 μ s** > 392 μ s
 the oscilloscope display only the red waveform
 This holdoff value prevents the double triggering



Functional Description

IV - ACQUISITION System

Acquisition menu « ACQUIRE »

When acquiring an analog signal, the oscilloscope converts it into digital format and displays a waveform. The acquisition mode defines how the signal is digitized. The time base setting multiplied by the number of horizontal divisions of the screen determines the duration of the recording in seconds ("S/div" x 14div), and the elementary step of acquisition is given by the sampling period. The **Memory Depth**, the **Sample Rate** and the **Waveform Recorded Length** are related by the following formula:

$$\text{Memory Depth (Nb Recorded Samples)} = \text{Sampling rate (Samples/sec)} \times \text{Waveform Recorded Length (in sec)}$$

The oscilloscope adjusts the current memory depth according to the the selected time base coefficient :

For example we set the maximum memory depth to "14Mpts" (Menu «Acquire» → Sub-menu « Memory Depth ») and the channel CH1 "On" (all other channels are Off), the oscilloscope will adjust the "Current" memory depth according to the selected Time Base coefficient:


S/div	Sample Rate	Memory depth (Samples)
1ns	2GSPS	28 Samples
2ns	2GSPS	56 Sa
5ns	2GSPS	140 Sa
10ns	2GSPS	280 Sa
20ns	2GSPS	560 Sa
50ns	2GSPS	1.4k Sa
100ns	2GSPS	2.8k Sa
200ns	2GSPS	5.6k Sa
500ns	2GSPS	14k Sa
1µs	2GSPS	28k Sa
2µs	2GSPS	56k Sa
5µs	2GSPS	140k Sa
10µs	2GSPS	280k Sa
20µs	2GSPS	560k Sa
50µs	2GSPS	1.40M Sa
100µs	2GSPS	2.80M Sa
200µs	2GSPS	5.60M Sa
500µs	2GSPS	14.0M Sa
1ms	2GSPS	28.0M Sa
2ms	1GSPS	28.0M Sa
5ms	0.4GSPS	28.0M Sa
10ms	200MSPS	28.0M Sa
20ms	100MSPS	28.0M Sa
50ms	40MSPS	28.0M Sa
100ms	20MSPS	28.0M Sa
200ms	10MSPS	28.0M Sa
500ms	4MSPS	28.0M Sa
1s	2MSPS	28.0M Sa
2s	1MSPS	28.0M Sa
5s	400KSPS	28.0M Sa
10s	200KSPS	28.0M Sa
20s	100KSPS	28.0M Sa
50s	40KSPS	28.0M Sa

Functional Description




IV - ACQUISITION System (cont'd)

« Acquire »

Press the "Acquire" button to open the acquisition menu.



Acquisition Settings

Option	Settings	Description
Acquisition		
	Normal	This mode is used for an accurate sampling and display of most signals.
	Peak Detect	This mode is used to display noise and to reduce aliasing .
	High Res	To increase the vertical resolution and to reduce random noise.
	Average	To reduce the random noise on displayed waveforms. Average: 4, 16, 32, 64,128, 256, 512, 1024
Sinx/x	Sinx X	Sinusoidal Interpolation "Sinx" Linear Interpolation "x"
Sequence		
	Acq Mode	Off Normal Single
	Display Mode	Overlay Waterfall
	Frame Set	Setting range : 1 to 80000 (The max value depends on the time base coefficient "S/div" and the number of active channels)
Mem Depth		
	7k - 14k - 70k - 140k - 700k - 1.4M - 7M - 14M	Select the maximum Memory Depth value

Functional Description

IV - ACQUISITION System (cont'd)


Sampling Modes The oscilloscope has the following sampling modes:

Normal - Peak Detect - Average - High Resolution


Normal The oscilloscope samples the signal at regular intervals to build the digital waveform. In general this mode is a true representation of the signal.

Advantage It is the most common sampling mode. This mode reduces the random noise.

Disadvantage The "Normal" mode does not capture fast signal changes that may occur between to successive samples. An aliasing phenomenon can result and the short pulses may not be detected. In the presence of short pulses (glitch) you must use the Peak Detect mode.




« Peak Detect » The « Peak Detect » mode capture the minimum and maximum values of the signal (**Oversampled waveform**) between two successive samples and displays two Waveforms, one with the **Low** values and the other with the **High** values.



Advantage In this mode, the oscilloscope can capture fine pulses (**glitch**) which have not been detected by the "Normal" mode.

Disadvantage The trace thickness (noise) will be higher in this mode.




Functional Description

IV - ACQUISITION System (cont'd)

Average Mode


In this mode, the oscilloscope performs “**Multiple Waveforms**” acquisitions, average them and displays the resulting “**1 Waveform**”.




Advantage

Use this mode to reduce the random noise.

A noisy sine wave acquire in « Normal » and « Average » (128) modes



High Res mode



High Res

The **High Res** mode uses « on the fly » over-sampling and averaging. Each displayed sample point represents the average value of the samples acquired in the elementary time interval. The «**High Res**» mode increases the effective vertical resolution of the oscilloscope. The High Res mode reduces the signal random noise.

The High Resolution mode can be used even with SINGLE mode because the averaging takes place at each point displayed and not on successive waveforms acquisitions as in the « Average » mode.

Functional Description

IV - ACQUISITION System (cont'd)

Sequence Mode In the **Sequence** mode, the recording memory is segmented. The oscilloscope captures and records a waveform (**Frame**) at each trigger event. When the acquisition sequence is completed, the oscilloscope displays the first 20 acquired waveform segments. In this mode, the “waveform capture speed” can reach up to 300000 waveforms/sec. When a trigger event occurs, the oscilloscope acquires and records a waveform (segment) and then waits for a new trigger event. The oscilloscope “**blind time**” is minimized allowing the capture of certain signal details, that were not visible with other acquisition modes.

For a 14Mpts maximum memory depth and with all four channels activated, the table below shows the maximum number of Frames according to the « Time Base » coefficient :

Time Base Coefficient	Sampling Frequency	Current memory	Maximum Frame Set
1ns/div	1.00GSPS	14pts	80 000
2ns/div	1.00GSPS	28pts	80 000
5ns/div	1.00GSPS	70pts	80 000
10ns/div	1.00GSPS	140pts	80 000
20ns/div	1.00GSPS	280pts	80 000
50ns/div	1.00GSPS	700pts	80 000
100ns/div	1.00GSPS	1.4kpts	63 157
200ns/div	1.00GSPS	2.8kpts	33 519
500ns/div	1.00GSPS	7kpts	16 042
1µs/div	1.00GSPS	14kpts	8 108
2µs/div	1.00GSPS	28kpts	4 067
5µs/div	1.00GSPS	70kpts	1 630
10µs/div	1.00GSPS	140kpts	815
20µs/div	1.00GSPS	280kpts	408
50µs/div	1.00GSPS	700kpts	163
100µs/div	1.00GSPS	1.4Mpts	81
200µs/div	500MSPS	1.4Mpts	74
500µs/div	200MSPS	1.4Mpts	74
1ms/div	100MSPS	1.4Mpts	74
2ms/div	50MSPS	1.4Mpts	74
5ms/div	20MSPS	1.4Mpts	74
10ms/div	10MSPS	1.4Mpts	74
20ms/div	5MSPS	1.4Mpts	74
50ms/div	2MSPS	1.4Mpts	74
100ms/div	1MSPS	1.4Mpts	74
200ms/div	500kSPS	1.4Mpts	74
500ms/div	200kSPS	1.4Mpts	74
1s/div	100kSPS	1.4Mpts	74
2s/div	50kSPS	1.4Mpts	74
5s/div	20kSPS	1.4Mpts	74
10s/div	10kSPS	1.4Mpts	74
20s/div	5kSPS	1.4Mpts	74
50s/div	2kSPS	1.4Mpts	74

Due to display limitations, the oscilloscope can not display more than 20 waveforms at a time (**Overlay** » or « **Waterfall** » display modes) .

Functional Description

IV - ACQUISITION System (cont'd)

Advantage This mode allows you to increase the maximum waveforms recording (in a segmented memory) frequency to 300000 Waveforms/s. It allows us to observe details that rarely occur, because the « blind time » (time without signal acquisitions) is minimized.

Disadvantage The oscilloscope displays the acquired waveforms once the acquisition sequence is completed.

The oscilloscope can not display more than 20 segments (**Frames**) at a time.



Waterfall (3 segments at a time)



Overlay (3 segments at a time)

Using the « Sequence » mode we were allowed to capture a waveform that occurs rarely. We used the two viewing modes « Waterfall » and « Overlay »

Functional Description

IV - ACQUISITION System (cont'd)

Memory Depth


Advantage A deep memory allows to record the signal evolution over a long period of time, and then analyze it in detail with a very fine elementary pitch. For example with a 28Mpoints memory depth we can record the evolution of a signal for 14ms with an elementary pitch of 0.5ns.

Disadvantage We have to search in the long recording memory, the waveform portion to observe in details.

Using the x50000 Zoom mode to display simultaneously the overall waveform and a detail



Using x1000000 Zoom coefficient to analyze in detail the detail



Using a “28Mpoints” memory depth, we were able to record “14ms” of signal evolution at a sampling rate of 2GSPS (=0.5ns elementary pitch). We then used two Zoom factors : x50000 (to display a 280ns portion of 14ms) and x1000000 (to display a 14ns portion of 14ms) to observe an elementary portion of the recorded waveform in “RUN” or “STOP”. We can move the Zoom window in the entire memory depth by using the horizontal « **Position** » knob.

Functional Description

IV - ACQUISITION System (cont'd)

Time Base




The oscilloscope digitizes the waveform by sampling the input signal at a regular time interval. The Time Base coefficient and the Memory Depth set the sampling frequency.

Use the "**S/div**" knob to set the "Time Base" coefficient.

Open the « Acquire » menu to set the suitable memory depth.

Under-Sampling Aliasing

The **aliasing** occurs when the oscilloscope sampling rate is not fast enough to precisely reconstruct the digital waveform. The oscilloscope displays a lower frequency waveform, or an unstable waveform.



Example of «**aliasing**» observed with a 160MHz sinusoidal signal sampled at 100MSa/s : the hardware counter frequency is : « $f = 160.66\text{MHz}$ » the automatic frequency measurement is « $\text{Freq} = 667.8\text{kHz}$ » Comparing the two different frequency values we can highlight the presence of «**aliasing**»



Functional Description

IV - ACQUISITION System (cont'd)

Operation Steps To set sampling

Press the “**Acquire**” button to open the ACQUIRE menu.

Press the « **Acquisition** » button and use the “Universal” knob to select the acquisition mode : “Normal”, “Peak detect”, “High Res” or “Average”.

To set the « Average »


Press the « Averages » button to select the number of averages: “4”, “16”, “32”, “64”, “128”, “256”, “512” or “1024”.

To set the interpolation


Press the “**Sinx/x**” button to select the interpolation: « Sinx » or « x ».

“Sinx” : Sinusoidal interpolation:

*Example:
a 250MHz sine wave displayed using the “Sinx” sinusoidal interpolation*



*Example :
a 250MHz sine wave displayed using the linear interpolation « X »*



Functional Description

IV - ACQUISITION System (cont'd)

SEQUENCE Mode

In the « Sequence » mode, the oscilloscope is ready to display waveforms, once the acquisitions are completed. In this mode, the maximum number of acquisitions per second can reach 300000. For each trigger event, the oscilloscope fills a segment of the recording memory and continues until the memory is completely filled. Once completed, the oscilloscope displays the acquired segments up to 20 segments at a time.


To use the « Sequence » the Horizontal format must be: "YT".

To set the Sequence mode :

- 1° Press the « **Acquire** » button to open the ACQUIRE menu
- 2° Press the "**Sequence**" button to open the SEQUENCE menu
- 3° Press the « **Acq. Mode** » button to disable or enable the Acquisition « **Off - On** » (Off is the default value).
- 4° Press the « **Display Mode** » button to select the display mode :

Overlay - Waterfall

- 5° Press the « **Frame set** » button and use the « Universal" knob to set the displayed « Frame set »
- 6° Press the «**Run/Stop**» button to start recording the sequence
- 7° When the acquisition sequence is completed and the oscilloscope displays the first 20 segments, press the « Run/Stop » button
- 8° Manually scroll the acquired segments using the « **Start** », « **End** » buttons and the « **Universal** » knob
- 9° or Press the « **Operation** » button to automatically scroll the acquired segments.



Functional Description

IV - ACQUISITION System (cont'd)

RUN/STOP
SINGLE
AUTO
NORMAL



Run/Stop Press the "**Run/Stop**" button to start (Run/Stop button is lit in yellow) the signal acquisition, press this button again to Stop (Run/Stop button is lit in red).

Single Press the "**Single**" button to **Arm** the trigger (the oscilloscope is **Ready**, and the "Run/Stop" button is lit in yellow), then when a trigger event is detected a unique acquisition starts, when the acquisition is completed the oscilloscope Stops (Run/Stop button is lit in red).

In **SINGLE** mode when you press the "**Single**" button to start a unique acquisition, the oscilloscope performs the following steps:

1. Acquisition of "Pre-Trigger" samples, which are represented on the screen by the portion of the waveform to the left of the Trigger point.
2. The oscilloscope acquires the « Pre-Trigger » samples continuously and waits for the trigger event.
3. Detection of the trigger event.
4. After the trigger event, the acquisition continues until the recording memory is filled with the « Post-Trig » samples, which are represented on the screen by the portion of the waveform to the right of the trigger point.
5. The oscilloscope displays the waveform and Stops (Run/Stop button is lit in red). Press again the « **Single** » button to start a new single acquisition .

Auto Press the « **Auto** » button to enable the **Auto** mode. In this mode, acquisitions occur in the presence or absence of a trigger event.


Normal Press the « **Normal** » button to enable the « Normal » mode.
In this mode, acquisitions occur only when a trigger event is detected.

Functional Description

V - DISPLAY System


Display Menu Press the "Display" button to open the DISPLAY menu.

MENU pad



Display page 1







Option	Settings	Description
Type	Vectors	Two adjacent points (samples) are connected by a straight segment.
	Points	Points (samples) are not connected together .
Color	ON	Allows to switch the SPO display from the "color palette" type to the "intensity grading" type. If « Color : On » the SPO «color palette» is active.
	OFF	If « Color : Off » the SPO « intensity grading » is active.
Persistence	Off	To set the persistence duration.
	1 sec	
	5 sec	
	10 sec	
	30 sec	
Infinite		
Clear Pers		Dump the Persistence
Clear Display		Dump the Display
Next Page	Page1/2	Open page 2/2



Functional Description

V - DISPLAY (cont'd)

«Display» Menu
page 2

Option	Settings	Description
Grid	  	Display the grid and the axes. Display the axis. Grid and axis are not displayed.
Intensity		Sets the trace intensity.
Brightness		Sets the Grid intensity.
Transparence		Set the transparence.
Next Page	Page 2/2	Press this button to open page 1/2.

SPO




Two SPO display modes:

Color On : Display with a « Color palette »

Color Off : Display with an « intensity grading »

Color "On"

The SPO « **Color palette** » is « On ». The point (sample) color depends on the occurrence : the Red color corresponding to the most frequent points (samples) and the purple color to rare points. All channel waveforms use the same "palette".




Color "Off"

The SPO display uses an « intensity grading » (256 levels). Each channel has its own color but the intensity of the points change according to their occurrence.

Rare

very frequent



Functional Description

V - DISPLAY System (cont'd)

Operation Steps

1. To set the **display type**
 - 1) Press the "**Display**" button to open the DISPLAY menu.
 - 2) Press the "**Type**" button and select "Vectors" or "Points".
2. To set the **Color**

Press the "**Color**" button and set "**ON**" or "**Off**" :

Off : Each Channel is displayed with its own color and an intensity grading : CH1 yellow, CH2 red, CH3 blue and CH4 green




ON : All channels are displayed using the same « color palette » (Red Yellow Green Blue Purple)
3. To set the **Persistence**

Press the "**Persistence**" button and select "Off", "1 Sec", "5 Sec", "10 Sec", "30 Sec", or "Infinite". This option is used to view, for example, the drift of a signal over time.
4. «**Clear**» Persistence

Press this button to dump the persistence
5. «**Clear**» Display

Press this button to dump the Display
6. **Next page** button

Press this button to open page 2/2
7. To set the **Grid**

Press the "**Grid**" button and select the grid type "  ", "  " or "  "
8. To set the Intensity


Press the "**Intensity**" button and use the "Universal" knob to set the trace Intensity.
9. To set the « **Brightness** »

Press the "**Brightness**" button and use the "Universal" knob to set the grid **Brightness**.
10. To set the **transparence**

Press the "**Transparence**" button and use the « **Universal** » knob to set the transparence.
11. Next Page

Press this button to open page 1/2.

Caution in XY mode, the «Persistence» and the «Color» are «Off» and the "Dots" display type is imposed



Functional Description


V - DISPLAY System (cont'd)

X-Y Format

The XY format is used to analyze the phase difference between signals using the Lissajous figures. In « XY » mode, channel CH1 (CH3) is the X axis and channel CH2 (CH4) the Y axis. The oscilloscope uses an acquisition mode without trigger and displays XY datas in the form of points, each XY point corresponds to a simultaneous acquisition on CH1(X) and CH2(Y) : X= CH1 sample (or CH3), Y= CH2 sample (or CH4).

The "XY" mode accepts sampling frequencies from 20Sa/s to 1GSa/s (1-2-5 sequence).


If we visualize, in XY mode, two sinusoidal signals with the same frequency but phase shifted by an angle θ :




We will have :

$$\sin(\theta) = A/B \text{ or } C/D \rightarrow \theta = \pm \arcsin(A/B) \text{ or } \pm \arcsin(C/D)$$

Two sine waves with same frequency but phase shifted by 40° :





Operation Steps

- Channel CH1 (or CH3) **X axis**, the corresponding “**V/div**” and vertical “**Position**” knobs allows to adjust the horizontal scale and position.
- Channel CH2 (or CH4) **Y axis**, The corresponding “**V/div**” and vertical “**Position**” knobs allows to adjust the vertical scale and position.
- Turn the “**S/div**” knob to set the sampling rate
- The following functions are not available in “XY” mode:
 - XY between a Real waveform and a Math waveform
 - Cursor
 - Trigger Control
 - Horizontal position knob
 - Vector display type

Note : The « Auto setup » function resets automatically to YT format.

Functional Description

VI - MEASURE System

MEASUREMENTS

The oscilloscope displays the waveform, that is to say the variation of the signal amplitude (voltage or current) as a function of time.

The oscilloscope displays : the vertical and horizontal scales and the automatic and cursors measurements values.

The oscilloscope has a « hardware » frequency counter on the signal of the active trigger source channel.

Scale measurements

This method allows a quick visual estimate of the amplitude or the period of the signal. For example, you can observe the signal amplitude and roughly determine it is slightly higher than 100 mV. You can estimate the amplitude by simple measurements by counting the number of major and minor divisions and multiplying by the vertical sensitivity. For example, if you count five major divisions between the minimum and maximum values of a signal, and if the vertical sensitivity is 100mV/div, then it is easy to calculate the peak-to-peak amplitude:

$$5 \text{ div} \times 100 \text{ mV/div} = 500 \text{ mV.}$$

Cursors measurements

Three modes : **Manual**, **Track** (cursors attached to the trace) and **Off**
 Press the "**Cursors**" button to open the cursors menu.



1. Manual Cursors

Option	Settings	Description
Mode	Manual	For measurements using manual cursors.
Type	Voltage Time	Use the cursors to measure the signal amplitude : voltage ΔV . Use the cursors to measure the period (or the frequency) of the signal : ΔT et $1/\Delta T$.
Source	CH1 - CH2 CH3 - CH4 MATH REFA - REFB REFC - REFD	Select the reference source for measurements.
Cur X1 ↻		Select X1 cursor and use the " Universal " knob to adjust.
Cur X2 ↻		Select X2 cursor and use the " Universal " knob to adjust.
Cur X1-X2 ↻		Select X1-X2 cursors pair and use the " Universal " knob to adjust.
Cur Y1 ↻		Select Y1 cursor and use the " Universal " knob to adjust.
Cur Y2 ↻		Select Y2 cursor and use the " Universal " knob to adjust.
Cur Y1-Y2 ↻		Select Y1-Y2 cursors pair and use the " Universal " knob to adjust.


Functional Description

VI - MEASURE System (cont'd)

When the « **Manual Cursors** » are active, the display shows two horizontal or vertical parallel cursors to measure voltage (Y cursors) or time (X cursors). Use the "Universal" knob to move the cursors. Select the appropriated reference source for cursors measurements.

- **Voltage cursor (Y cursors)** : The voltage cursors materialized on the screen in the form of horizontal lines. The cursor position is in Volt.
- **Time Cursor (X cursors)** : The time cursors materialized on the screen in the form of vertical lines. The cursor position is in second.
- **Moving the cursors** : Select the cursor (X or Y) and use the "**Universal**" knob to move it. When you move the cursor the value corresponding to the vertical and(or) horizontal position of the cursor is displayed in the top left of the screen.

Examples :
Use of X and Y cursors to measure the period (or frequency) and the amplitude of a sine wave




Functional Description

VI - MEASURE System (cont'd)

Operation Steps

1. Press the "Cursors" button to open the CURSORS menu.
2. Press the "Mode" button and select "Manual".
3. Press the "Type" button and select : "X1" or "X2" or "X1-X2" or "Y1" or "Y2" or "Y1-Y2".
4. Press the "Source" button and selectet : "CH1", "CH2", "CH3", "CH4", "MATH", " REFA", "REFB", " REFC", " REFD", as the source reference for measurements.
5. Select "X1" and use the "Universal" knob to set X1.
6. Select "X2" and use the "Universal" knob to set X2.
7. Select "Y1" and use the "Universal" knob to set Y1.
8. Select "Y2" and use the "Universal" knob to set Y2.
9. The measurements values are displayed on the top left of the screen:
 - The voltage difference (in Volts) between Cursor Y1 and Cursor Y2: ΔV
 - The time difference (in Seconds) between Cursor X1 and Cursor X2: ΔT
 - The inverse of ΔT : $1/\Delta T$ is in Hz



Track Mode

Option	Settings	Description
Cursor Mode	Track	"Track" mode allows to measure with cursors attached to the waveform.
Cursor X1	CH1 - CH2 CH3 - CH4	Select the channel attached to cursor X1.
Cursor X2	CH1 - CH2 CH3 - CH4	Select the channel attached to cursor X2.
Cur X1 ↻		Select the cursor X1 and use the "Universal" knob to adjust.
Cur X2 ↻		Select the cursor X2 and use the "Universal" knob to adjust.
X1-X2 ↻		Select the X1-X2 cursors pair and use the "Universal" knob to adjust.


The « **Track** » mode displays two cross cursors attached to the trace. With the “**Universal**” knob, you can only adjust the horizontal position of the selected cross cursor. The oscilloscope displays the ΔV and ΔT values.



Operation Steps

1. Press the "**Cursors**" button to open the CURSORS menu.
2. Press the "**Mode**" button and select "**Track**".
3. Press the "**X1 source**" button and select the attached channel.
4. Press the "**X2 source**" button and select the attached channel.
5. Select "**X1**" and use the "**Universal**" knob to move horizontally the **X1** cross cursor.
6. Select "**X2**" and use the "**Universal**" knob to move horizontally the **X2** cross cursor.
7. The measured values are displayed on the top left of the screen:
 - X1→T: **The horizontal position of X1 Cursor (Time Cursor).**
 - Y1→V: **The vertical position of Y1 Cursor (Voltage Cursor).**
 - X2→T: **The horizontal position of X2 Cursor (Time Cursor).**
 - Y2→V: **The vertical position of Y2 Cursor (Voltage Cursor).**
 - ΔT : **The time interval between X1 and X2 cursors.**
 - $1/\Delta T$: **The inverse of the time interval between X1 and X2 cursors in Hz.**
 - ΔV : **The voltage difference between Y1 and Y2 cursors.**

Example :
Measuring the amplitude and the frequency of a 1MHz square wave




Functional Description

VI - MEASURE System (cont'd)

Automatic Measurements Menu
Menu Pad

Press the "Measure" button to open the MEASURE menu :




Three types of automatic measurements :

- Voltage measurements
- Time measurements
- Delay measurements


Of the 32 automatic measurements available, 23 of them (14 voltage and 9 time) can be displayed individually with or without their statistics.

In the example below we have chosen to display the frequency :



Measure menu

Press the « Measure » button to open the MEASURE menu :



We can select :

- * The channel reference for measurements : CH1 or CH2 or CH3 or CH4
- * The type of measurement of the 23 available : Vpp - Vmax - Vmin - Vamp - Vtop - Vbase - Vmean - Mean - Vrms - Crms - FOV - FPFE - ROV - RPFE - Period - Freq - +Wid - -Wid - Rise Time - Fall Time - Bwid - +Dut - -Dut
- * Press the « Add » button to display the selected measurement
- * Press the « Clear » button to clear the displayed measurements
- * Press the « Statistics » button to display the statistics on the measurements displayed.
- * Press the « All Measure » button to display a table with all the voltage (or time, or delay) measurements.

Functional Description

VI - MEASURE System (cont'd)

Statistics Press the «Statistics» button to open the «Statistics» sub-menu:



We can then view statistics of the displayed measurements, the oscilloscope displays the following values:

Average, Min, Max, **Standard Deviation** and the Number of measurements.

All Measures

Option	Description
1. SOURCE	The reference channel for measurements : CH1 CH2 CH3 CH4
2. VOLTAGE	Press this button to display the 14 voltage measurements.
3. TIME	Press this button to display the 9 time measurements.
4. DELAY SOURCE	Press this button to select the channel pair for the delay measurement : CH1-CH2, CH1-CH3, CH1-CH4, CH2-CH3, CH2-CH4, CH3-CH4
5. DELAY	Press this button to display the 9 delay measurements.

Example :
 displaying the 32 automatic measurements available: Voltage, Time, Delay

CH1 is the reference channel for the voltage and time measurements


For the delay measurements the reference is the channel pair : CH1-CH2




Functional Description

VI - MEASURE System (cont'd)

1. Automatic Voltage Measurements




Option	Settings	Description
Source	CH1 CH2 CH3 CH4	Select the reference channel for voltage measurements.
Type	Vmax, Vmin, Vpp, Vamp, Vtop, Vbase, Cycle Mean, Mean, Cycle Vrms, Vrms, ROVShoot, FOVShoot, RPREShoot, FPREShoot	Press the " Type " button and use the " Universal " knob to select the voltage measurement type. ROVShoot = Rise Overshoot FOVShoot = Fall Overshoot RPREShoot= Rise Preshoot FPREShoot= Fall Preshoot



2. Automatic Time Measurements

Option	Settings	Description
Source	CH1 CH2 CH3 CH4	Select the reference channel for time measurements
Type	Rise Time, Fall Time, Freq, Period, Bwidth, +Width, -Width, +Duty, -Duty	Press the " Type " button and use the " Universal " knob to select the time measurement type.



3. Automatic Delay Measurements

Option	Settings	Description
Source	CH1-CH2 CH1-CH3 CH1-CH4 CH2-CH3 CH2-CH4 CH3-CH4	Reference channel pair for Delay measurements.
Type	Phase, FRR, FRF, FFR, FFF, LRR, LRF, LFR, LFF	Press the " Delay " button « On » or « Off » to display or not the delay measurements.































4. All measures

Option	Settings	Description
Source	CH1, CH2 CH3, CH4	Select the reference channel for measurements.
Voltage	On Off	Enable « All Voltage measurements ». Disable « All Voltage measurements ».
Time	On Off	Enable « All Time measurements ». Disable « All Time measurements ».
Delay	On Off	Enable « All Delay measurements ». Disable « All Delay measurements ».
Return		Press the « Up » button to return to the MEASURE menu.

Functional Description

VI - MEASURE System (cont'd)

*Description
of the type of
measure*

Type of measure	Description
 Vmax	Waveform maximum peak voltage.
 Vmin	Waveform minimum peak voltage.
 Vpp	Absolute difference value between maximum and minimum peak voltage of the entire waveform
 Vtop	Upper level most common voltage value of the waveform.
 Vbase	Lower level most common voltage value of the waveform
 Vamp	Voltage difference between Vtop and Vbase.
 Vavg	Arithmetic mean over the first cycle of the waveform.
 Mean	Arithmetic mean over the entire waveform.
 Crms	The true RMS voltage value over the first cycle of the signal.
 Vrms	The true RMS voltage value over the entire waveform.
 ROVShoot	« Rise Over Shoot » : Defined as $(V_{max}-V_{top})/V_{amp}$ after a positive edge.
 FOVShoot	« Fall Over Shoot » : Defined as $(V_{min}-V_{base})/V_{amp}$ after a negative edge.
 RPREshoot	« Rise PRE shoot »: Defined as $(V_{min}-V_{base})/V_{amp}$ before a rising edge.
 FPRESHOOT	« Fall PRE shoot »: Defined as $(V_{max}-V_{top})/V_{amp}$ before a falling edge.
 Rise Time	« Rise Time »: the interval of time between 10% and 90% of the first rising edge.
 Fall Time	« Fall Time »: the interval of time between 90% and 10% of the first falling edge.
 BWid	« Burst Width »: The duration of a pulse burst over the entire waveform.
 + Wid	+ Width : interval of time between the first rising edge and the next falling edge at 50% of Vamp.
 - Wid	-Width : interval of time between the first falling edge and the next rising edge at 50% of Vamp.
 + Duty	+ Duty is the ratio between the positive pulse width and period.
 - Duty	- Duty is the ratio between the negative pulse width and period.
 Phase	The amount one waveform leads or lags another in time. Expressed in degrees, where 360 degrees comprise one waveform cycle.
 FRR	The interval of time between the first rising edge of CHi source and the first rising edge of CHj source
 FRF	The interval of time between the first rising edge of CHi source and the first falling edge of CHj source
 FFR	The interval of time between the first falling edge of CHi source and the first rising edge of CHj source
 FFF	The interval of time between the first falling edge of CHi source and the first falling edge of CHj source
 LRR	The interval of time between the first rising edge of CHi source and the last rising edge of CHj source
 LRF	The interval of time between the first rising edge of CHi source and the last falling edge of CHj source
 LFR	The interval of time between the first falling edge of CHi source and the last rising edge of CHj source
 LFF	The interval of time between the first falling edge of CHi source and the last falling edge of CHj source

Functional Description

VI - MEASURE System (cont'd)

Operation Steps Voltage measurements

To display a particular voltage measurement :

1. Press the "Measure" button to open the "MEASURE" menu.
2. Press the "Source" button to select the channel source for measurements: "CH1", "CH2", "CH3", "CH4".
3. Press the "Type" button to select the measurement type to display.
4. Press the « Add » button to display the selected measurement
5. Press the « Clear » button to clear the displayed measurements
6. Press the « Statistics » button to display the measurement statistics

To display all voltage measurements

7. Press the « All measure » button to open the ALL MEASURE menu.
8. Press the "Voltage" button (On, Off) to display all voltage measurements.
9. Press the "Up" button to return to the « MEASURE » menu.

Note: You can display up to five automatic measurements at a time.

Note : To display all the available measurements (Voltage, Time, Delay) you have to activate them from the « All Measure » submenu.

Example :
 Displaying 5 automatic measurements, their statistics and the 32 available measurements



Functional Description

VI - MEASURE System (cont'd)

Operation Steps Time measurements

To display a particular time measurement :

1. Press the **"Measure"** button to open the **"MEASURE"** menu
2. Press the **"Source"** button to select the channel source for measurements: **"CH1"**, **"CH2"**, **"CH3"**, **"CH4"**.
3. Press the **"Type"** button to select the measurement type to display.
4. Press the **« Add »** button to display the selected measurement
5. Press the **« Clear »** button to clear the displayed measurements
6. Press the **« Statistics »** button to display the measurement statistics

To display all time measurements

7. Press the **« All measure »** button to open the **ALL MEASURE** menu.
8. Press the **"Time"** button (On, Off) to display all time measurements.
9. Press the **"Up"** button to return to the **« MEASURE »** menu.




Functional Description


VII - SAVE/RECALL System

Save/Recall

Press the **“Save/Recall”** button to open the SAVE/RECALL menu. This menu allows to Save/Recall : **Setups, Waveforms, Picture, .CSV files.**



4 data types can be saved :
 - Setups - Waveforms - Pictures - .CSV files



The «Setups» files can be saved in internal (the oscilloscope) or external (USB memory device plugged in the “USB host” front panel connector) memories. You can save up to 20 Setups in the internal memory.

The Waveforms, the Pictures, and the .CSV files must be saved in external memories.

The setups and the waveforms can be recalled and displayed on the oscilloscope.

The pictures and the .CSV files can not be recalled or displayed on the oscilloscope, this files can be open on a PC.


Functional Description

VII - SAVE/RECALL System


1. SAVE/RECALL Menu

Press the « **Save/Recall** » button to open the "SAVE/RECALL" menu :

You can save « Setups » in internal or external memory



You can save Waveforms, Pictures and .CSV files only in external memory



Functional Description

VII - SAVE/RECALL System (cont'd)

Saving « Setups » in Internal or External memory

To save a «Setup» file in the oscilloscope internal memory :

- 1° Press the « **Save/Recall** » button to open the SAVE/RECALL menu.
- 2° Press the « **Type** » button and select « **Setups** »
- 3° Select **Save to « Internal »**
- 4° Select a **Setup N°** location among the 20 available
- 5° Press the «**Save**» button to save the current **Setup**

To save a setup file in an external memory (USB memory device plugged in the « USB host » front panel connector) :

- 1° Press the « **Save/Recall** » button to open the SAVE/RECALL menu
- 2° Press the « **Type** » button and select « **Setups** »
- 3° Select **Save to « External »**
- 4° Plug the **USB device** in the « USB host » front panel connector and wait for the **USB** icon appears and the following “Popup” message : « **USB Flash Drive Plugged in !** » is displayed.
- 5° Press the « **Save** » button and set the « save » function, wait for the file directory of the “USB memory device” is displayed.

Note : If the USB device is not plugged in and we press the «**Save**» button, the following message is displayed : « **USB Flash Drive isn’t connected !** »


- 6° Press the « **New** » button, to enter from the keyboard (**shift to keyboard**) the name of the new setup file to save, the maximum width allowed is 8 characters

Example : To enter the name « **dox3302s** » select one by one the characters (using the Universal knob or the buttons “→” and “←”) and press the « **Enter** » button for each selected character.



- 7° Press the «**Switch to keyboard**» button to switch to «**Switch to Name**»

- 8° Press the « **Enter** » button to save the **Setup file: “dox3302S”**



9° The Setup file « **dox3302s** » is saved in the USB memory device as **dox3302s.SET**

To Recall a Setup file
To Recall a Setup file from an internal or external memory

We can « recall » a setup file from an internal or an external memory.


To Recall a Setup file from the oscilloscope internal memory

- 1° Press the « **Save/Recall** » button to open the SAVE/RECALL menu.
- 2° Press the « **Type** » button and select « **Setups** »
- 3° Select **Save to «Internal»**
- 4° Select a **Setup N°** location among the 20 available
- 5° Press the « **Recall** » button to recall the selected Setup file;

wait for the message «**Read Data success**»

Note : If the selected « setup N° » corresponds to an empty location the following message is displayed : « **Location Empty !** »


To Recall a Setup file from an external memory (USB memory device plugged in the « USB host » front panel connector) :

- 1° Press the « **Save/Recall** » button to open the SAVE/RECALL menu
- 2° Press the « **Type** » button and select « **Setups** »
- 3° Select **Save to « External »**
- 4° Plug the **USB** memory device in the **USB host** connector and wait for the USB device icon  and the Popup message « **USB Flash Drive Plugged in !** ».
- 5° Press the « **Recall** » button and wait for the file directory of the “USB memory device” is displayed.
- 6° Use the Universal knob to select the **.SET** file to recall
- 7° Press the « **Load** » button to recall the selected setup file and wait for the message «**Read Data success**» .


Functional Description

VII - SAVE/RECALL System (cont'd)

Rename We can Rename an existing Setup file

- 1° Press the « **Save/Recall** » button to open the SAVE/RECALL menu
- 2° Press the « **Type** » button and select « **Setups** »
- 3° Select **Save to** « **External** »
- 4° Plug the **USB** memory device in the **USB host** connector and wait for the USB device icon  and the Popup message « **USB Flash Drive Plugged in !** ».
- 5° Press the « **Recall** » button and wait for the file directory of the “USB memory device” is displayed
- 6° Select the file to **Rename**
- 7° Press « **Next Page** » button
- 8° Press the « **Rename** » button
- 9° Modify the file name using the buttons and the Universal knob: « **Switch to Name** », « **Universal knob**», « **Delete** », « **switch to keyboard** », « **Universal knob** », « **Enter** », « **Switch to Name** », « **Enter** », « **Confirm** » or « **Cancel** »

Delete We can delete a file in a directory:

- 1° Press the « **Save/Recall** » button to open the SAVE/RECALL menu
- 2° Press the « **Type** » button and select « **Setups** »
- 3° Select **Save to** « **External** »
- 4° Plug the **USB** memory device in the **USB host** connector and wait for the USB device icon  and the Popup message « **USB Flash Drive Plugged in !** ».
- 5° Press the « **Recall** » button and wait for the file directory of the “USB memory device” is displayed
- 6° Select the file to **Delete**
- 7° Press the **Delete** button
- 8° Press the « **Confirm** » or « **Cancel** » button to delete or not the selected file.


Functional Description

VII - SAVE/RECALL System (cont'd)

2. Save/Recall Waveforms

Waveforms are saved only in external memory, therefore before saving or recalling a waveform plug the USB memory device in the "USB host" front panel connector of the oscilloscope.

You can save a « waveform » only in an external memory.
The saved waveform can be recalled and displayed on the oscilloscope screen.



To « SAVE or RECALL » a « Waveform » you need an USB memory device.

Option	Settings	Description
Type	Waveform	Menu de « Sauvegarde/Restauration » des Traces
Save	External memory	Save waveforms in an external memory (USB memory device plugged in the USB host connector of the oscilloscope).
Recall	External memory	Recall saved waveforms .DAV files

2.1 Saving / Recalling Waveforms

Press the **Save** or **Recall** buttons to open the submenus « **Save** » or « **Recall** » waveforms.


Both submenus have the same functionality :

- 1° You are able to modify a « **File** » or a « **Directory** ».
- 2° You are able to save waveforms in a **New** file
- 3° You can **Delete** a selected file.
- 4° You are able to **Load** a waveform file (.DAV) from an USB device
- 5° You can **Rename** a file.

Notes :

Waveforms are saved in .DAV files

When a waveform is saved or recalled the acquisition is stopped.



Press the « Save » or « Load » buttons to open the SAVE or RECALL sub-menus, both submenus have the same functionality :

Option	Settings	Description
Modify	Files Directory	to modify files or directories
New		Press the “New” button to enter the file name using the “Universal” knob or the buttons “→” and “←”.
Delete		To delete the selected file.
Load		To load and display the selected file.
Next Page	1/2	To open page 2/2
Rename		To rename an existing file
Return		To return to the main Save/Recall menu
Next Page	2/2	To open page 1/2

Functional Description

VII - SAVE/RECALL System (cont'd)

Save a Picture

The oscilloscope can save a screen copy (« Picture ») in an external memory. The oscilloscope can't recall a picture file (.BMP) .

Saving a screen copy « Picture »

To save a screen copy (« Picture ») as a .BMP file



1. Press the **"Save/Recall"** button to open the SAVE/RECALL menu.
2. Press the **"Type"** button and select "Picture"
3. Press the **"Save"** button to open the Save sub-menu.
4. Press the « **New** » button and enter the picture file name .BMP using the Universal knob or the buttons "→" and "←".
5. Confirm the Name to save the picture.

Notes :

1° A Picture must be saved in an external memory.

2° A Picture file (.BMP) can't be open by the oscilloscope, use for example the "Paint" PC software to open it.

Picture save and recall menu



Functional Description

VII - SAVE/RECALL System (cont'd)

2.2 Saving a screen copy (Picture)


To save a screen copy in an external memory :

Open the SAVE/RECALL menu and select the **Picture** type, press the «Save» button to open the Save submenu to save a screen copy .BMP.

Option	Settings	Description
Type	Picture	Save a « Picture» file.
Save		Press the « Save » button to open the save menu.

Submenu « Save » « Picture »

Option	Settings	Description
Modify	File Directory	To modify a file or a directory
New		To create a new screen copy (picture) file press the « New » button to open the New file submenu. Enter the file name (.BMP) using the Universal knob or the buttons “→” and “←”.
Delete		Press this button to delete the selected file
Next page	1/2	Press this button to open page 2/2
Rename		Press this button to rename an existing file
Return		To return to the main menu
Next Page	2/2	To open page ½



To enter the picture file name first press the « **Switch to Keyboard** » button (to “switch to name”) and then press the “**Enter**” button

Functional Description


VII - SAVE/RECALL System (cont'd)

Saving CSV files

The CSV files must be saved in external memory.

The CSV files can't be opened in the oscilloscope.

The CSV files can be opened in table software "EXCEL".

1. Open the "SAVE/RECALL" menu and select the file type: "CSV" .
2. Plug the USB memory device in the «USB host» connector and wait for the USB device icon  and the Popup message « **USB Flash Drive Plugged in** ».
3. Press the « **Para Save** » button to set : "On" or "Off".
4. Press the "**Save**" button to open the « Save .CSV file » submenu.
5. Press the « **Modify** » button and select: "File" or "Directory"
6. Press the « **New** » button to enter the file name using the Universal knob or the buttons "→" and "←".
7. Press the « **Delete** » button to delete the selected file.
8. Press the « **Next Page** » button
9. Press the « **Rename** » button to modify the name of the selected file or directory.
10. Press the « **Return** » Button to return to the main menu.


Notes:

1° The .CSV files can't be opened in the oscilloscope.

2° The .CSV files can be opened in EXCEL

Warning : The .CSV files generated by the DOX3000, can exceed the size limit allowed by the version of EXCEL (eg limits : 65536 lines for "EXCEL 2003" and 1048576 lines for "EXCEL 2007"). To be able to open the complete file, set the maximum memory depth of the oscilloscope less than the limit of the EXCEL version (examples : 14kpts for "EXCEL 2003" or 700kpts for "EXCEL 2007").

If the file exceeds the limit, the following « PopUp » message appears :




Click « OK » to display the lines allowed by the EXCEL version, starting from line N°1 to the imposed limit value:

Functional Description

1	A	B	C	D	E	F	G	H	I	J	K	L
2	Source	CH1	CH2									
3	Second	Volt	Volt									
4	-0.0014	-0.248	-0.1									
5	-0.0014	-0.252	-0.1									
6	-0.0014	-0.248	-0.1									
7	-0.0014	-0.248	-0.1									
8	-0.0014	-0.248	-0.08									
9	-0.00139999	-0.248	-0.1									
10	-0.00139999	-0.252	-0.1									
11	-0.00139999	-0.248	-0.1									
12	-0.00139999	-0.252	-0.1									
13	-0.00139999	-0.248	-0.1									
14	-0.00139999	-0.248	-0.1									
15	-0.00139999	-0.248	-0.1									
16	-0.00139999	-0.252	-0.1									
17	-0.00139999	-0.248	-0.1									
18	-0.00139998	-0.252	-0.1									
19	-0.00139998	-0.248	-0.1									
20	-0.00139998	-0.252	-0.1									
21	-0.00139998	-0.248	-0.08									
22	-0.00139998	-0.252	-0.1									
23	-0.00139998	-0.248	-0.1									
24	-0.00139998	-0.252	-0.1									
25	-0.00139998	-0.248	-0.1									
26	-0.00139998	-0.248	-0.1									
27	-0.00139998	-0.248	-0.1									

Menu Save
Type CSV



Submenu
« Save » « New »
.CSV file



Functional Description

VII - SAVE/RECALL System (cont'd)


Restoring the «Factory Settings» (Default Setup)

Press the « **Default** » button to restore the « Default Setup » :



Display obtained after restoring the « default setup »:
Channel CH1


Sensitivity: 1V/div,
Probe factor: 1X,
Impedance: 1MΩ,
Coupling: DC, BW
Limit : Full Time Base:
1μs/div



Restoring Waveforms

Waveform files must be saved in external memory (USB memory device).

To restore a waveform plug first the USB device in the « USB host » connector of the oscilloscope front panel

- 1° Plug the USB memory device in the «USB host» connector and wait for the USB device icon  and the Popup message « **USB Flash Drive Plugged in** ».
- 2° Press the « **Save/Recall** » button to open the SAVE/RECALL menu
- 3° Press the « **type** » button and select **Waveforms**
- 4° Press the « **Recall** » button and wait for the contents of the « USB memory device » is displayed on the screen
- 5° Use the **Universal** knob to select the waveform file « **.DAV** » to be displayed on the screen
- 6° Press the « **Load** » button to restore the selected waveform file
- 7° Wait until the selected waveform is displayed on the screen

Notes :

- 1° When the saved waveform is displayed the acquisition stops. The displayed values of the time base coefficient, the sampling rate, and the memory depth correspond to the restored waveform. To refresh the display of vertical

parameters of the restored waveform you must press the corresponding “Chi” button.

2° We can perform automatic or cursors measurements.

3° If we « Run » new acquisitions by pressing the « Run/Stop » button, the restored waveform is cleared and replaced with the new acquire waveform.
Warning : The new acquisitions are done with the settings corresponding to the restored waveform.


In the example below we provide :

1° The initial configuration of the oscilloscope before restoring the saved waveform.

2° The configuration corresponding to the restored waveform

3° The configuration after « Running » new acquisitions

*Initial Configuration :
Channels CH1 and CH2 actives,
Sensitivity 1V/div,
BdT 1.0µs/div*



*The restored waveform on CH3 :
the S/div coefficient = 20µs/div is automatically refreshed but not the vertical parameters of the restored waveform*



To refresh the vertical parameters of the restored (CH3) waveform you must press a « CHi » button.



If we « Run » new acquisitions by pressing the « Run/Stop » button, the restored waveform is cleared and replaced with the new acquire waveform. The new acquisitions are done with the settings corresponding to the restored waveform.
(The initial configuration is lost)



Functional Description




VIII - UTILITY

UTILITY
MENU Pad


Press the "Utility" button to open the UTILITY menu.



Utility Menu
page 1/3

Option	Settings	Description
System Status		Displays the hardware and software configurations of the oscilloscope.
Do Self Cal		To start the self-calibration of the oscilloscope
History		Allows to access the HISTORY of acquired waveforms in SEQUENCE mode.
Sound	 	Sound is "On". Sound is "Off".
Language	English Français Deutsch Español Italiana	 Select the working language :
Next Page	Page 1/3	To open page 2/3.

« Utility »
choosing the
Language



UTILITY
submenu "I/O
SET"



UTILITY do self Cal


Press "Single" to begin



When "Do self Call" ends "Press Run/Stop to Exit"






UTILITY submenu System Status



Functional Description

VIII - UTILITY (cont'd)

« Utility »
page 2/3

Option	Valeurs	Instructions
Pass/Fail		To open the Pass-Fail menu
I/O	USB LAN Aux Output	To set the Input/Output interfaces
Power Analyze		To enable the « Power Analyzer » option, when the option is installed. Otherwise the following message appears : 
Print Setup	Ink Saver Layout Paper Size Image Size ID Print Print Key	To set up printer
Quick Cal	ON OFF	If « Quick-Cal » is « ON » and the vertical sensitivity is set to 2mV or 5mV/div, a quick-cal routine starts automatically when the oscilloscope is switched "On" or when the ambient temperature varies by more than 2°C.
Next Page	2/3	To open page 3/3
USB Device (Back USB)	Printer	The « Printer » is connected to the oscilloscope with an USB cable. Before printing, select the "Printer" option. The Printer icon is displayed on the top right of the screen. 
	USBTMC (PC)	The oscilloscope is connected to the PC with an USB cable. When working with "EasyScopeX" PC software select " USBTMC ". The PC icon is displayed on the top right of the screen. 




Submenu **Pass/Fail** page 1/2



Submenu **Pass/Fail** page 2/2



Submenu **History**



Submenu **Print Setup**



Functional Description

VIII - UTILITY (cont'd)

« Utility »
page 3/3

Option	Settings	Description
Update		You can update the firmware or the oscilloscope configuration from an external USB memory device.
Do Self Test		Press this button to run the « Self Test » program : Screen, Keyboard and front panel LEDs.
Screen Saver		Press this button to set the “screen saver” duration.
Options		Press this button to open the submenu options: Arbitrary Waveform Generator, Decode, Digital and Power Analyzer.
Date/Time		Press this button to open the submenu DATE/TIME
Next Page	Page 3/3	Press this button to open page 1/3



Submenu « Update »




Submenu « Self Test »



Submenu « Screen Saver »



Submenu « Options »



Submenu « Date/Time »



Functional Description

VIII - UTILITY (cont'd)

« Utility »

Option	Settings	Description
Screen Saver	1 min 5 min 10 min 30 min 1 hour Off	To set the time delay before switching to screen saver



Functional Description

VIII - UTILITY (cont'd)

« **System Status** » Press the « **System Status** » button to display the hardware and software configurations of the oscilloscope.

System Status



Option	Description
Number of “Power on” (StartupTimes)	Displays the number of “power-on” of the device.
Software Version	Displays the firmware version.
FPGA Version	Displays the FPGA version
Hardware Version	Displays the oscilloscope hardware version.
Product Type	Displays the model name.
Serial No.	Displays the serial number.
Scope ID	The oscilloscope ID number

Languages

User manual in 5 languages :

Français - Anglais - Deutsch - Italiana - Español

Press the « **Utility** » button → submenu “**Language**” and select the working language.



Functional Description

VIII - UTILITY (cont'd)


- « **Print Setup** » Set the « USB device » interface to « Printer » (Utility submenu « I/O ») and connect a "Pict Bridge" printer to the "USB Device" connector of the rear panel of the oscilloscope.

Open the submenu « Print Setup » submenu to setup the printer.

Press the « Print » button to print.

Printer Settings

Option	Settings	Instructions
Ink Saver	On Off	To print a screen copy on a white background. To print the screen copy as it is.
Layout	Portrait Landscape	To select the desired layout.
Paper Size	Default, A4, Letter	Displays the available settings with your compatible USB "PictBridge" printer.
Image Size	Default, A4, Letter	
ID Print	ON OFF	To print the oscilloscope ID
Print Key	Print Picture Save Picture	Select the option « Print Picture » when the oscilloscope is connected to a Printer. Select " Save Picture " to save the screen copy in a USB memory device.



Functional Description

VIII - UTILITY (cont'd)

Print Setup

To Setup the USB « Pictbridge » printer interface.



Note :

- 1. The printer will modify your selection for best fit.**
- 2. If your selection is not supported by the printer, the oscilloscope will use the default settings.**
- 3. The oscilloscope was designed to print to any "PictBridge" compatible printer . Refer to the product documentation to determine if the printer is USB "PictBridge" compatible.**

Functional Description

VIII - UTILITY (cont'd)

Print a screen copy

Operation Steps

1. To connect the oscilloscope to a "PictBridge" compatible printer .


- 1) Plug the USB cable in the "USB Device" connector of the oscilloscope.
- 2) Plug the other end of the USB cable in the printer "USB Pictbridge" connector.

2. To print a screen copy

- 1) Power on the oscilloscope and the printer. (The printer recognizes the oscilloscope only when the printer is powered on).
- 2) Press the "Utility" button to open the "UTILITY" menu.
- 3) Press the "I/O" button to set the "USB Device" interface.
- 4) Press the "USB Device" button to select "Printer"
- 5) Press the « Next Page 1/3 » button to open the page 2/3
- 6) Press the « Print Setup » button to open the « Print setup » menu.
- 7) Set up the print setup according to your need . The oscilloscope queries the printer, and only displays options and values that the printer supports.

If you are not sure which setting to choose, select "Default" for each option.

- 8) Press the « Print Key » button to select "Print Picture".
- 9) Press the "Print" button to print a screen copy.



Note : If the «Pictbridge» printer is not connected the following message is displayed : « **Printer isn't connected** »

Functional Description

VIII - UTILITY (cont'd)

SELF CAL

« Do Self Cal »

The « Self Calibration » procedure optimizes the channel (CH1 CH2 CH3 CH4) accuracy. You can run this procedure at any time. If the ambient temperature changes by more than 5° C, or the unit runs more than thirty minutes, you should do the self cal.

Before starting the “Self Calibration” procedure you must disconnect all cables and probes from the BNC inputs. Then press the "Utility" button and select "Do Self Cal" to start the self-calibration procedure, then follow the instructions on the screen.

Press the « Single » button to start “Do Self Cal”



Press the « Run/Stop » button to exit Self-calibration



« Do Self Test »



- Steps**
- « Screen Test » Select "Screen Test" to perform the LCD test. The following message “Press ‘SINGLE’ Key to continue, ‘Press ‘RUN/STOP’ Key to exit’ is displayed, press the “Single” button to display the three basic colors of the LCD (Red, Green, Blue) and check if there are missing pixels.



Functional Description

VIII - UTILITY (cont'd)


«Keyboard Test»

Select " Keyboard Test" to enter the key test interface. The rectangle shapes represent the front panel keys and the circle shapes the knobs :

The 14 circles with an arrow on both sides represent the front panel knobs. For each knob can be tested : the direction of rotation (clockwise or counterclockwise) and the integrated switch.


Note :

- When the « Keyboard test » starts, the color of all buttons and knobs is grey on a black background..
- As the test proceeds the buttons and knobs tested change from grey to blue.
- According to the displayed message "Press ' RUN/STOP' key three times to exit", press the "RUN/STOP" button three times to exit the « Keyboard test ».



«LED Test»

Select the "LED Test" to enter the front panel LED test. The following message is displayed: "Press 'SINGLE' key to continue, Press RUN/STOP key to exit". Press repeatedly the "Single" button to test sequentially the button backlight LEDs. When a button is lit, the corresponding rectangle is colored in blue.




Functional Description

VIII - UTILITY (cont'd)


«Firmware Update»

Update the « Firmware » from a USB memory device.

The embedded software of the oscilloscope can be updated directly from a USB memory device.



Operation Steps

1. Plug the **USB memory device** with the new « firmware » version in the **USB host** connector of the oscilloscope front panel and wait for the **USB**  is displayed on the top right of the screen.
2. Press the «**Utility**» button to open the **UTILITY** menu.
3. Press the "**Next Page**" button to enter the page 3/3 of the UTILITY menu.
4. Press the « **Update** » button and select the firmware update procedure .
5. Press the "**Single**" button to start updating the embedded software, follow the instructions displayed on the screen.
6. Turn « off » the oscilloscope and back « on » and make sure the « **firmware** » has been updated. After updating the firmware you must perform a "Do Self Cal".

Note : Don't cut off the power while the oscilloscope is updating.


« Pass/Fail »

The "Pass/Fail" function allows to compare the evolution of the real-time signal to a mask. Within the mask limits, the real-time signal « Pass » the test, outside the mask limits the test "Fail".

Utility Pass/Fail



PASS/FAIL page 1/2





PASS/FAIL page 2/2



Pass/Fail Menu
page 1



Option	Settings	Description
Enable Test	On	Enable the Pass/Fail test
	Off	Disable the Pass/Fail test
Source	CH1 CH2 CH3 CH4	Select the channel Source for pass Pass/Fail test.
Operation	▶	Press to run the Pass/Fail test.
	■	Press to stop the Pass/Fail test.
Msg Display	On	Enable the display of the number of tests that Pass or Fail .
	Off	Disable the display of the number of Pass/Fail tests.
Mask Setting		To set the mask limits
Next Page	Page 1/2	Press this button to open page 2/2.




Functional Description

VIII - UTILITY (cont'd)



Pass/Fail menu
page 2

Option	Settings	Description
Fail to Stop	On Off	The Pass/Fail test stop when real-time signal is outside the mask. The Pass/Fail don't stop on « Fail ».
Output	 	Sound On Sound Off
Next Page	Page 2/2	Press to open the page 1/2.



Mask Setting

Pass/Fail mask setting

Mask Setting		
Option	Settings	Description
Mask X  xdiv		Use the "Universal" knob to set the allowed horizontal range : from 0,04div to 4,00div.
Mask Y  ydiv		Use the "Universal" knob to set the allowed vertical range : from 0,04div to 4,00div.
Create Mask		Create the "Pass/Fail" mask.
Location	Internal External	Select the storage location for the mask, in the internal memory (oscilloscope) or the external memory (USB device).
Save		Save the Pass/Fail mask in the selected memory location
Load		To restore a saved mask


X Mask set




Y Mask set



Create Mask



To save the created Mask in the external memory select the **External Location**:



Plug the USB device, press the « **Save** » button and wait for the oscilloscope displays the contents of the USB memory device :




Press the « **New** » button to enter the name of the mask file (Example dox3304m) :




Press the « **Switch to Keyboard** » button to switch to « **Switch to Name** »

Functional Description



Press the « **Enter** » button to save the mask file in the USB memory device, file « dox3304m.RGU » :






The “**Load**” function allows to recall a saved Mask file (.RGU)

Functional Description

VIII - UTILITY (cont'd)

Perform Pass/Fail test

Option	Valeurs	Instruction
Enable Test	On Off	On : Enable the « Pass/Fail » test once the Mask was created
Msg Display	On Off	On : Enable the display of the Pass/Fail test results
Operation		 To run the Pass/Fail test with the active mask



Once the « Pass/Fail » test is validated and launched, the oscilloscope displays (Msg Display : On) : The number of tests that « Fail », the number of tests that « Pass » and the total number of tests .

Pass /Fail Test Operation Steps

1. Press the « **Utility** » button to open the “ UTILITY ” menu.
2. Press the « **Next Page 1/3** » button.
3. Press the "**Pass/Fail**" button to open the "PASS/FAIL" menu.
4. Press the "**Enable Test**" button to select "On"
5. Press the "**Source**" button to select the signal source for the Pass/Fail test.
6. Press the "**Mask Setting**" button to open the Mask Setting menu.
7. Press the "**X Mask**" button and use the “Universal” knob to set the allowed horizontal range.
8. Press the "**Y Mask**" button and use the “Universal” knob to set the allowed vertical range.
9. Press the "**Create Mask**" button to create the mask. You can also restore a saved mask (**Load**).
10. Press « **Next Page** » to open page 2/2 . Press the "**Output**" button to set the « **Sound** » output.
11. Press « **Next Page** » to open page 1/2. Press "**Operate**" ► to run the Pass/Fail test.

Functional Description

VIII - UTILITY (cont'd)

« History »

The « History » function allows to record and display a history of the last waveforms corresponding to the channels: CH1 CH2 CH3 CH4.

In « RUN » the oscilloscope continuously records the signals present at the inputs of the channels : CH1 CH2 CH3 CH4, in the form of a sequence of memory segments « Frames ». When the recording memory is full (ie the number maximum of segments is reached) the oscilloscope continues recording by replacing the frames previously recorded by the new segments.

The oscilloscope stores the « History » of the last recorded frames.

Open the submenu « History » and select « View On » to display the « History », the acquisition automatically stops, allowing to scroll the history of the latest recorded segments.


The maximum number of recorded frames and the segment size depends on the sample rate and the current memory depth :








« Sample Rate »	Current memory depth (pts)	Maximum Number of « Frames »	
2GSa/s	< ou = 560	> 50000	
	1,4k	48000	
	2,8k	32432	
	5,6k	16997	
	14k	8075	
	28k	4067	
	56k	2037	
	140k	815	
	280k	408	
	560k	204	
	1,4M	81	
< ou = 2GSa/s	2,8M	40	
	5,6M	18	
	14M	7	
	28M	3	
	1GSa/s	< ou = 700	80000
		1,4k	63157
		2,8k	36585
7k		16043	
14k		8108	
28k		4067	
70k		1630	
140k		815	
280k		408	
700k		163	
1,4M		81	
< ou = 1GSa/s	2,8M	37	
	7M	14	
	14M	7	


The « History » function can be used in the following modes :
Normal, Sequence,
and Pass/Fail






Example : A Fail test using the Pass/Fail function



Option	Settings	Description
Mode	« History »	History of the latest recorded frames. When the history View is « On » the acquisition automatically stops. This function allows to view the « History » segment by segment.
View	On Off	To enable or disable the « History » view.
List	On Off	To display the « History » list, indicating for each segment : the number, the acquisition time and the size. 
Frame		Use the « Universal » knob to select the frame to display 
To Scroll automatically the frames	  	Down scrolling. Up scrolling Stop scrolling 



Operation Steps

1. Press the «Utility» button to open the “UTILITY” menu.
2. Press the "Next Page" button to open page 2/2.
3. Press the “History” button to open the “HISTORY” submenu.
4. Press the “View Off” button to set the “View On”, the acquisitions are stopped to allow to view the “History”.
5. Press the "List" button to display (On) or not (Off) the frames list of the “History”.
6. Press the « Frame » button and use the Universal knob to select the frame to display.
7. Press the  button to automatically scroll down the frames of the history
8. Press the  button to stop scrolling
9. Press the  button to automatically scroll up the frames of the history.

Notes :


- 1° The automatic up scrolling stops when the maximum frame number “N°” is reached.
- 2° The automatic down scrolling stops when the frame N°1 is reached

Functional Description

VIII - UTILITY (cont'd)

« Options »


The « Options » submenu allows to manage the oscilloscope options: DECODE - ARBITRARY WAVEFORM GENERATOR - MSO LOGIC ANALYZER - POWER ANALYZER



For each option the oscilloscope indicates whether it is installed or not and the type of license.



If the hardware does not allow the installation of the « MSO Logic Analyzer », this option is not present in the « Information » window and can not be installed.

If the option can be installed, such as « PAS » option, press the « Install » button and enter the code :



Functional Description

VIII - UTILITY (cont'd)


Option	Description															
<p>« Options »</p> <p>Options</p>	<p>The « Options » submenu allows to manage the oscilloscope options</p>															
<p>Type</p>	<p>4 options types are available :</p> <p>The are 3 software options: (DECODE - WAVE GENERATOR integrated) - PAS (contact us)</p> <p>The « Digital » option needs a software and a special hardware « MSO-DOX3LA » (Logic Analyzer Probe). If the hardware is not suitable, it is not possible to install the « MSO » option when pressing the “Install” button.</p> 															
<p>Install</p> <p>Installed</p>	<p>«Install» : Press the « Install » button and enter the code to install the option.</p> <p>«Installed» : indicates that the option is already installed.</p>															
<p>Information</p>	<p>Press this button to access information about the options : Name, License type and remaining time</p>  <table border="1" data-bbox="868 1043 1310 1267"> <thead> <tr> <th>Option Name</th> <th>Licence Type</th> <th>Remaining Time</th> </tr> </thead> <tbody> <tr> <td>AWG</td> <td>Permanent</td> <td>xx</td> </tr> <tr> <td>Decode</td> <td>Permanent</td> <td>xx</td> </tr> <tr> <td>MSC</td> <td>Trial Version</td> <td>23</td> </tr> <tr> <td>PAS</td> <td>Trial Version</td> <td>30</td> </tr> </tbody> </table>	Option Name	Licence Type	Remaining Time	AWG	Permanent	xx	Decode	Permanent	xx	MSC	Trial Version	23	PAS	Trial Version	30
Option Name	Licence Type	Remaining Time														
AWG	Permanent	xx														
Decode	Permanent	xx														
MSC	Trial Version	23														
PAS	Trial Version	30														

Functional Description


VIII - UTILITY (cont'd)

« Date/Time » submenu

The oscilloscope display the time and date in the bottom right of the screen.



To set the time and date open the « Date/Time » submenu.



« Date/Time »

Option	Settings	Description
Date/Time		To set the time and date open the «Date/Time» submenu
Year		Press this button and use the «Universal» knob to set the year
Month/Day	Month	Press this button to highlighth the « Month » and use the Universel knob to adjust
	Day	Press this button to highlighth the « Day » and use the Universel knob to adjust.
Hour/Minute	Hour	Press this button to highlighth the « Hour » and use the Universel knob to adjust.
	Minute	Press this button to highlighth the « Minute » and use the Universel knob to adjust
Display	On Off	To enable (On) or not (Off) the display of the Time and Date
Confirm		Press this button to confirm the settings



Operation Steps to set the time and date

1. Press the « **Utility** » button to open the “UTILITY” menu.
2. Press the “**Next Page**” button to open page 3/3.
3. Press the “**Date/Time**” button to open the DATE/TIME submenu.
4. Set the Time and Date using the buttons « **Year** », « **Month/Day** », « **Hour/minute** » and the Universal knob.
5. Press the « **Display** » button to enable (On) or not (Off) the display of the Time and Date
6. Press the « **Confirm** » button to confirm the settings

Functional Description

VIII - UTILITY (cont'd)

« I/O »

The oscilloscope has rear panel interfaces « USB Device » and « Ethernet ». Open the “I/O” submenu (page 1/3 of UTILITY menu) to set these interfaces :



The « I/O » submenu allows to set the interfaces « USB Device » and « Ethernet » and also the Aux Output.



« I/O » submenu

Option	Settings	Description
I/O		The I/O submenu allows to set the interfaces «USB Device» and «LAN - Ethernet» and also the Aux Output.
USB Device	USBTMC PRINTER	Press the button to set « USB Device » interface : « USBTMC » for PC remote control « PRINTER » for a Pictbridge Printer
LAN	DHCP IP Address Subnet Mask Gate Way Mac Address	«DHCP Enable» dynamic assignment of an IP address from the network server. «DHCP Disable» IP address assigned by the user Oscilloscope IP address Subnet Mask « Gate Way » IP address Oscilloscope Mac Address : it is unique and not modifiable by the user.
Aux Output	Trig Out Pass/Fail	« Trig Out » : The BNC output (on the rear panel) delivers a square wave whose frequency reflects the number of waveforms captured per second. The maximum number is 110000 Waveforms/s « Pass/Fail » : For each “Failed” test the oscilloscope delivers a negative pulse : the « Pass/Fail » output falls from +3V to 0V, stays at 0V for 2µs, and then rises again to +3V.



IX - « Arbitrary Waveform Generator » (AWG) option

The DOX3000 oscilloscope series come with an Arbitrary Waveform Generators (AWG) that can generate 10 types of pre-defined waveforms (Sine, Square, Ramp, Pulse, DC, Noise, Cardiac, Gauss Pulse, Exponential Rise and Exponential Fall) and 4 arbitrary user defined waveforms (Arb 1, Arb 2, Arb 3, Arb 4).

To set the waveform parameters :

1° Press the « **WaveGen** » button to open the WAVEFORM menu to set the Waveform Generator (the « **Wave Gen** » button is lit).

2° Press the « **Wave Type** » button and use the « Universal » knob to select the waveform type to generate, then press the “**Confirm**” button.

3° Press the « **Frequency** » button and use the « Universal » knob to adjust the signal frequency

4° Press the « **Amplitude** » button and use the « Universal » knob to adjust the signal amplitude

5° Press the « **Offset** » button and use the « Universal » knob to adjust the signal offset

« Wave Type »	« Frequency Range »	Peak to Peak Amplitude Range Vpp « High-Z »	Offset range « High-Z »
Sine	1µHz to 25MHz	4mV to 6V	± 3V
Square	1µHz to 10MHz	4mV to 6V	± 3V
Ramp	1µHz to 300kHz	4mV to 6V	± 3V
Pulse	1µHz to 10MHz	4mV to 6V	± 3V
DC			± 3V
Noise			
Cardiac Pulse	1µHz to 5MHz	4mV to 6V	± 3V
Gauss Pulse	1µHz to 5MHz	4mV to 6V	± 3V
Exponential Rise	1µHz to 5MHz	4mV to 6V	± 3V
Exponential Fall	1µHz to 5MHz	4mV to 6V	± 3V
Arb 1, 2, 3, 4			

Notes:


1° The total amplitude (Peak to Peak amplitude + offset) of the waveform provided by the AWG can not exceed +3V or -3V, for example when programming a 6Vpp sine wave the offset is automatically set to 0V.

2° When the generator output is loaded by a “**50Ω**” instead of a “**High-Z**” impedance the signal amplitude is divided by two.


IX - « Arbitrary Waveform Generator » (AWG) option (cont'd)

Create an arbitrary waveform with the « EasyWave » software and load it into the l'oscilloscope AWG (Arbitrary Waveform Generator)

- 1° Press the « **Wave Gen** » button to open the WAVEFORM generator menu
- 2° Connect the DOX3000 oscilloscope to a PC (USB cable plug in the rear panel « USB Device » connector) where the « EasyWave » software is installed
- 3° Run « EasyWave »
- 4° Create an arbitrary waveform or Select an already created waveform file :




- 5° Click the « **Send wave** » button, select the “Store Location” and click the “**Send**” button to send it to the oscilloscope




Click the « **Send** » button to transfer the waveform « wave1 » from the PC to the “Arb 2” location of the Oscilloscope Arbitrary Waveform Generator.

IX - « Arbitrary Waveform Generator » (AWG) option (cont'd)

6° To verify that the waveform WAVE1 is saved in the location Arb 2, we use the « **Read Wave** » function and select on the « Wave list » the WAVE1 waveform:



Then click the « **Read wave** » button to display, on the PC screen, the “WAVE1” waveform stored in the “Arb2” location :



IX - « Arbitrary Waveform Generator » (AWG) option (cont'd)

Automatic Calibration of the « Arbitrary Waveform Generator »

If the ambient temperature varies by more than 5°C and the instrument was left « On » for more than 30 minutes you can start an automatic calibration of the generator output.

- 1° Press the « **Wave Gen** » button to open the WAVEFORM menu
- 2° Press the « **Setting** » button to open the SETTING submenu
- 3° Press the « **AWG Self Cal** » button to launch the automatic calibration.



- 4° Press the « **Run/Stop** » button to exit the AWG self Cal

We can also set the generator output impedance (Output Load) : **High-Z** or **50Ω**

To set the generator default values (Sine, 1kHz, 4Vpp, 0Vdc) press the « **Default** » button.

X - DECODE Option Serial Bus decoder

The DOX3000 oscilloscope series come with serial bus Trigger and Decode option for :
I2C - SPI - UART/RS232 - CAN - LIN

I2C serial bus

To analyse an I2C serial bus, we need to connect to the inputs of the oscilloscope the two I2C signals « **Serial Data SDA** » and « **Serial Clock SCL** », and to set the logic threshold (in Volts) that defines the “Low” and “High” levels.

Setting up the oscilloscope to capture and decode the I2C serial bus signals:

- 1° Press the « **Decode** » button on the front panel to open the “**DECODE**” menu
- 2° Press the « **Serial** » button and select: “**Serial 1**” or “**Serial 2**”
- 3° Press the « **Decode** » button and select “**I2C**”



- 4° Press the « **Signal** » button to open the I2C “**SIGNAL**” submenu
- 5° Press the « **SCL** » button and assign a channel “**CHi**” to the “**SCL**” signal :



- 6° Press the « **Threshold** » button and use the Universal knob to set the logic threshold for the SCL signal:



- 7° Press the « **SDA** » button and assign a channel “**CHj**” to the “**SDA**” signal
- 8° Press the « **Threshold** » button and use the Universel knob to set the logic threshold for the SDA signal

Notes :

The decoding process uses the « logic threshold voltage » to determine the « Low » and « High » levels of the SCL and SDA signals, the logic threshold will become the channel trigger level.

The data should be stable throughout the duration of the « SCL » clock signal high level, a transition of the « SDA » signal while « SCL » is “High” may be interpreted as a **Start** (if SDA changes from « 1 » to « 0 ») or a **Stop** (if SDA changes from « 0 » to « 1 ») condition.

X - DECODE I2C Serial Bus Decode (cont'd)

Trigger conditions on an I2C bus can be :

A « **Start/Stop** » condition, a « **Restart** », a missing «**Acknowledge**», an **EEPROM data read**, a « **Read/Write** » frame with a specific device address and data value or a “**Data Length**”.

Setting the I2C bus trigger

1° Press the « **Setup** » button to open the “TRIGGER” menu.

2° Press the « **Type** » button and use the Universal knob to select « **Serial 1 or Serial 2** »

3° Press the « **Condition** » button and use the universal knob to select the trigger condition: Start, Stop, Restart, No Ack, EEPROM, 7 Addr&Data, 10 Addr&Data, Data Length:




Start Condition:

The oscilloscope triggers when the « SDA » signal changes from « 1 » to « 0 » while SCL is « 1 ».

Note : for the trigger a « Restart » is equivalent to a « Start » condition

Stop Condition:

The oscilloscope triggers when the « SDA » signal changes from « 0 » to « 1 » while SCL is « 1 ».



ReStart:

The oscilloscope triggers if: after a « **Start condition** », a new « **Start Condition** » occurs before a « **Stop Condition** ».


Missing Acknowledge :

The oscilloscope triggers if « SDA » is « high » during any “Ack SCL” clock bit.

X - DECODE I2C Serial Bus Decode (cont'd)


EEPROM Data Read :

The trigger looks for an « **EEPROM control byte** » value « **1010xxx** » on the SDA line, followed by a « **Read bit** » and a SCL « **Ack bit** ». It then looks for the occurrence of the programmed « **Data1** » value and the « **Limit Range** » to trigger on the rising edge of the « **Ack bit** » after « **Data1** ».



7-bit Address & Data Condition :


In 7-bit addressing mode, the oscilloscope triggers on a read or write frame, on the 17th or the 26th “SCL” clock edge if all bits in the « **Pattern** » match (Addr, Data1, Data2, Read/Write):



10-bit Address&Data Condition :

The oscilloscope triggers on a 10-bit addressing read or write frame, on the 26th (or the 34th) clock edge if all bits in the pattern match (Address, Data1, Data2).

X - DECODE I2C Serial Bus Decode (cont'd)



The 26th clock edge front trigger occurs for the following frame format :

(Start :Address byte 1 :Write :Address byte 2 : Ack : Data)

Data2 set to « **0xXX** »

The 34th clock edge trigger occurs for the following frame format :

(Start :Address byte 1 :Write :Address byte 2 : Ack : Data: Ack: Data)

Data2 must have a value other than « 0xXX », such as « **0x02** »

Data Length :

The oscilloscope triggers when the data length is equal to the set « **Byte Length** » value:



4° If you have selected the « **EEPROM Data Read** » condition :

Press the « **Limit Range** » button to set the oscilloscope to trigger when data is = (equal), < (less than), or > (greater than) the « Data1 » value.

5° If you have selected the « **7-bit Address&Data** » or « **10-bit Address&Data** » condition:

a) Press the « **Address** » button and use the « Universal » knob to select the device address length range : 7-bit (from 0x00 to 0x7F hexadecimal) or 10-bit (from 0x00 to 0x3FF). The oscilloscope will trigger on a Write or Read frame if the set frame [Start, Address, Read/Write, Acknowledge and Data] occurs.

Note : If don't care is selected 0xXX (7-bit Address) or 0xFFFF (10-bit Address), the address will be ignored. The trigger will always occur on the 17th clock edge (7-bit Address) or the 26th clock edge (10-bit Address).

b) Press the « **Data1** » or « **Data2** » button and use the « Universal » knob to set the 8-bit data byte value (from 0x00 to 0xFF). The oscilloscope will trigger if the set frame [**Start, Address, Read/Write, Acknowledge and Data**] occurs.

c) If don't care « 0xXX » is selected, the data will be ignored. The trigger will always occur on the 17th clock edge (7-bit Address) or the 26th clock edge (10-bit Address).

X - DECODE I2C Serial Bus Decode (cont'd)

Note : If you have selected a 3 bytes trigger, press the « **Data2** » button and use the Universal knob to set the 8-bit value.

6° If you have selected the « **Data Length** » condition :

Press the « **Address** » button to select the address length: 7-bit or 10-bit

Press the « **Byte Length** » button and use the Universal knob to set the byte length value (1 to 12).

Setting the I2C Bus Decode


1° Press the « **Decode** » button to open the « DECODE » menu.



2° Press the « **Address** » button to select the address length: 7-bit or 10-bit

3° Press the « **Display** » button to set Display « **On** » to display the decode lines.

4° Press the « **List** » button to open the LIST menu



5° Press the « **Display** » button to set display « **On** » to display the list

6° Press the « **Scroll** » and the « **Lines** » buttons and use the Universal knob to set the cursor position and the number of lines (from 1 to 7).



X - DECODE I2C Serial Bus Decode (cont'd)

Interpreting I2C Decode line



1° The transition lines indicate an active bus (inside a packet/frame)

2° Mid-level blue lines indicate an idle bus

3° Decoded hexadecimal data:

Address values appear at the start of a frame

Write addresses are displayed in « **dark green** » along with the « **W** » character

Read addresses are displayed in « **yellow** » along with the « **R** » character


Data values are displayed in « **white** »

« **A** » indicates Ack (low) et « **-A** » indicates No Ack (high)

Decoded text is truncated at the end of the associated frame when the space within frame boundaries is insufficient.

4° The blue vertical bars indicate that you need to expand the “S/div” horizontal scale (and run again) to see the decode information

5° The red dots in the decode line indicate that more data can be displayed. Scroll or expand the horizontal scale to view the data.



Interpreting the decoded List

The « **List** » display includes the following columns :

No - Frame number from left to right

Time - Standard Time

Address - colored « **blue** » for Writes and « **yellow** » for Reads

R/W - yellow « **R** » for Reads, dark green « **W** » for Writes, and “X” for Missing

Data - data bytes

X - DECODE SPI Serial Bus Decode

SPI Serial Bus

Setting up the oscilloscope to capture SPI bus signals

To analyse the SPI bus (Serial Peripheral Interface), we need to connect the inputs of the oscilloscope to the following SPI signals :

Clock - MOSI data - MISO data - Framing

And to set for each signal the logic threshold that defines the « Low » and « High » levels.

Setting up the oscilloscope to capture and analyse the SPI bus signals:

1° Press the front panel « **Decode** » button to open the DECODE menu

2° Press the « **Serial** » button and select “Serial 1” or “Serial 2”

3° Press the « **Decode** » button and use the « **Universal** » knob to select « **SPI** »


Note : The default value are “I2C” for Serial 1 and “SPI” for Serial 2.



4° Press the « **Signal** » button to open the SPI « SIGNAL » submenu



5° Press the « **CLK** » button to open the SPI “CLK” submenu



- Press the « **CLK** » button and use the « Universal » knob to assign a channel to the SPI « CLK » signal
- Press the « **Threshold** » button and use the « Universal » knob to set the threshold value.
- Press the « **Edge** » button to set the rising or the falling edge, the selected edge is used by the oscilloscope to « **latch** » the serial data.

6° Press the « **UP** » button to return to SPI “SIGNAL” submenu

7° Press the « **MISO** » button to open the “MISO” submenu




- Press the « **MISO** » button and use the « Universal » knob to assign a channel to the MISO signal
- Press the « **Threshold** » button and use the Universal knob to set the threshold

X - DECODE SPI Serial Bus Decode (cont'd)

8° Press the « **UP** » button to return to the SPI “SIGNAL” submenu

9° Press the « **MOSI** » button to open the « MOSI » submenu :



- a) Press the « **MOSI** » button and use the « Universal » knob to assign a channel to the SPI “MOSI” signal
- b) Press the « **Threshold** » button and use the « Universal » knob to adjust the threshold.

10° Press the « **UP** » button to return to the SPI « SIGNAL » menu.

11° Press the « **CS** » (**Chip Select**) button to open the SPI « CS » submenu:



- a) Press the « **Cs Type** » button to select a framing signal that the oscilloscope will use for determining which clock edge is the first clock edge in the serial stream. You can set the oscilloscope to trigger during a high chip select (CS) or a low chip select (~CS), or after a « **Timeout** » period during which the **clock** signal has been idle.

If the framing signal is set to « **CS** » (or ~CS), the first clock edge (rising or falling as set), seen after a « **CS** » (or ~CS) transition from low to high (or high to low) is the first clock in the serial stream.

Press « **CS** » (or ~CS) button and use the « Universal » knob to assign a channel to the SPI “CS” signal . The « **data pattern** » and the clock transition must occur during the lapse of time the framing signal is valid. The framing signal must be valid for the entire data pattern.

If the framing signal is set to « **Timeout** », the oscilloscope generates its own internal framing signal after it sees inactivity on the serial « **clock** » line.

« **CLK Timeout** » Press the « **Cs Type** » button and select « **Clock Timeout** », then press the « **Limit** » button and use the « **Universal** » knob to set the minimum time that the “Clock” signal must be idle (not transitioning) in the range: 100ns to 1s.



- b) Press the « **Threshold** » button and use the Universal knob to adjust the threshold

12° Press the « **Idle Level** » button and select « **High** » or « **Low** ».

13° Press the « **Bit Order** » button and select « **LSB** » or « **MSB** »

X - DECODE SPI Serial Bus Decode (cont'd)

Setting the SPI Trigger

Setting up the oscilloscope to capture SPI signals, and to trigger on a « **Pattern** » that occurs at the start of a frame. The serial data string length can be set from 4 to 96 bits.

- 1° Press the front panel « **Setup** » button to open the “TRIGGER” menu
- 2° Press the « **Type** » button and use the « **Universal** » knob to select « **Serial 1** » or « **Serial 2** ».
- 3° Press the « **Trigger Setting** » button to open the “SPI TRIG SET” menu
- 4° Press the « **Trigger Type** » button to select the trigger signal source :

MISO DATA (Master-In, Slave-Out)

MOSI DATA (Master-Out, Slave-In)

5° Press the « **Data Length** » button and use the « **Universal** » knob to set the number of bits in the serial data string: from 4 to 96 bits.

6° For each bit in the MISO/MOSI string:

- a) Press the « **Bit Roll** » button and use the « **Universal** » knob to select the bit to set
- b) Press the « **Bit Value** » button to set the selected bit :

0 (low), **1** (high) or **X** (don't care)



7° Press the « **All Same** » button to set at once all bits in the data string to :

0 (low), **1** (high) or **X** (don't care)

8° Press the « **Bit Order** » button to set the bit order to: **LSB (Least Significant Bit first)** or **MSB (Most Significant Bit first)**.



X - DECODE SPI Serial Bus Decode (cont'd)

SPI Serial Bus Decode

Setting the SPI Serial Bus Decode :

- 1° Press the front panel « **Decode** » button to open the DECODE menu and select Decode SPI
- 2° Press the « **Data Length** » button and use the « Universal » knob to set the number of bits of the SPI decode datas
- 3° Press the « **Display** » button and set « **On** » to display the decode line.
- 4° Press the « **List** » button to open the “**LIST**” submenu
- 5° Press the « **Display** » button and set « **On** » to display the list
- 6° Press the « **Scroll** » and « **Lines** » buttons and use the « Universal » knob to set the cursor and the number of lines of the list from 1 to 7.



X - DECODE SPI Serial Bus Decode (cont'd)

Interpreting SPI Decode

Transition lines indicate an active bus

Mid-level blue lines indicate an iddle bus

The number of clocks in a frame are displayed in lighth-blue above the frame on the right

Decoded hexadecimal values are displayed in « White »

Decoded text is truncated at the end of the associated frame when the space between the frame boundaries is insufficient.

Pink vertical bars indicate that you need to expand the horizontal scale (and Run again) to see the decode information.

Red dots indicate that there is data not been displayed.

Aliased bus values (undersampled or indeterminate) are drawn in pink

Unknown bus values (undefined or error conditions) are drawn in red

Interpreting the SPI List

The SPI List has the following columns :

No - Frame Number from left to right

MISO - Datas for MISO decode

MOSI - Datas for MOSI decode

X - DECODE UART/RS232 Serial Bus Decode

Setting up the oscilloscope to capture UART/RS232 signals


1° Press the front panel « **Decode** » button to open the « DECODE » menu.



2° Press the « **Serial** » button and select “Serial 1” or “Serial 2”

3° Press the « **Decode** » button and use the « Universal » knob to select **UART/RS232**

4° Press the « **Signal** » button to open the “SIGNAL” submenu



5° For both the « RX » and « TX » signals :

- Connect the « RX » and « TX » signals of the UART/RS232 serial bus to the oscilloscope inputs
- Press the « RX » and « TX » buttons to assign a channel to the signal
- Press the corresponding « **Threshold** » button and use the « Universal » knob to set the threshold

6° Press the « **UP** » button to return to the “DECODE” menu

7° Press the « **Configure** » button to open the « BUS CONFIG » menu.



Setting the bus parameters :

Baud - Press the « **Baud** » button and use the « Universal » knob to select the « **Baud rate** » of the UART serial bus. Setting a custom baud rate: select “Custom”, press the « **Custom** » button and use the Universal knob to set the custom baud rate value

Parity Check - Choose : « **odd** », « **even** » or « **none** »

Stop Bit - Set the number of Stop bits

Data Length - Set the number of bits of words : from 5 to 8 bits.

X - DECODE UART/RS232 Serial Bus Decode (cont'd)

Setting up the UART/RS232 Trigger

To trigger on a UART (**Universal Asynchronous Receiver/Transmitter**) signal, connect the oscilloscope channels to the « RX » and « TX » lines and set up a trigger condition. RS232 (**Recommended Standard 232**) is one example of UART protocols.

1° Press the front panel « **Setup** » button to open the “TRIGGER” menu.



2° Press the « **Type** » button and use the « Universal » knob to select Serial 1 (or Serial 2) according with the Decode selection.

3° Press the « **Trigger Setting** » button to open the « UART TRIG SET » submenu :



4° Press the « **Condition** » button and select the trigger condition:

Start - The oscilloscope triggers when a « **Start bit** » occurs

Stop - The oscilloscope triggers when a « **Stop bit** » occurs

Data - The oscilloscope triggers when a set « **data byte** » occurs.

a) Press the « **Compare type** » button and set the « **qualifier** » condition :

You can choose one of the following 3 conditions : = (equal), > (greater than) or < (less than)

b) Press the « **Value** » button and set the « **qualifier** » value in the range: 0x00 to 0xff

X - DECODE UART/RS232 Serial Bus Decode (cont'd)



X - DECODE UART/RS232 Serial Bus Decode (cont'd)

Setting the UART/RS232 serial bus Decode

1° Press the front panel « **Decode** » button to open the “DECODE” menu.




2° Press the « **Display** » button to set the display of the decode line « **On** »

3° Press the « **List** » button to open the “LIST” submenu

4° Press the « **Display** » button to set the display of the list « **On** »

5° Press the « **Scroll** » and the « **Lines** » button and use the Universal knob to set the cursor position and the number of lines displayed from 1 to 7.



X - DECODE UART/RS232 Serial Bus Decode (cont'd)

Interpreting the UART/RS232 Decode

The transition lines indicate an active bus (inside a packet/frame)

The mid-level blue lines indicate an iddle bus

The mid-level red lines indicate that the idle level is wrong

The decoded data are displayed in white

The decoded text is truncated at the end of the associated frame when the space between the frame boundaries is insufficient

The vertical blue bars indicate that you need to expand the horizontal scale (and run again) to see the decode data

When the horizontal scale setting (**S/div**) does not allow to display all available decode data, red dots will appear to mark the location of hidden decoded data. Expand the horizontal scale to display them.

An unknown (undefined) bus is shown in red

Interpreting the UART/RS232 List

The "UART/RS232" List has the following columns :

No - Line number

Time -

RX - Receive Data

TX - Transmit Data

Rx err - Parity error or unknown error in the Received data

Tx err - Parity error or unknown error in the Transmitted data

X - DECODE CAN Serial Bus Decode

Setting up the oscilloscope to capture the CAN bus signals

To capture and analyse the CAN bus connect the CAN-H and CAN-L bus signals to the oscilloscope inputs and open the CAN bus “SIGNAL” and “Configure” submenus to set the : decode Source, Threshold, Baud rate.

- 1° Press the front panel « **Decode** » button to open the DECODE menu.
- 2° Press the « **Serial** » button and select “Serial 1” or “Serial 2”
- 3° Press the « **Decode** » button and use the « Universal » knob to select « **CAN** »



- 4° Press the « **Signal** » button to open the “SIGNAL” submenu



- 5° Press the « **CAN-H** » (or « **CAN-L** ») button to assign a channel to this signal.
- 6° Press the « **Threshold** » button and use the « Universal » knob to set the threshold.
- 7° Press the « **UP** » button to return to the DECODE menu

- 8° Press the « **Configure** » button to open the « BUS CONFIG » submenu



- 9° Press the « **Baud** » button and use the « Universal » knob to select the « **baud rate** » (500kb/s for the CAN High Speed) from 5kb/s to 1Mb/s or “**Custom**” from 1b/s to 1Mb/s.

- 10° Press the « **Decode Source** » button to select the CAN decode source :

CAN_H - source is the CAN_H signal of the differential CAN bus

CAN_L - source is the CAN_L signal of the differential CAN bus


CAN_H - CAN_L - source is the differential signal: CAN_H-CAN_L. Use a differential probe to capture the CAN differential signal (CAN-H on positive lead and CAN-L on negative lead)

X - DECODE CAN Serial Bus Decode (cont'd)

Triggering on ID 0x0105



Triggering on ID 0x0108



X - DECODE CAN Serial Bus Decode (cont'd)


The oscilloscope displays the following CAN signals :


CAN_H on CH1, yellow trace

CAN_L on CH2, red trace

CAN_H-CAN_L on CH3, blue trace

Note : We use a MX9030 (1/20) differential probe to capture the CAN_H-CAN_L

Acquisition « STOP », we expand the horizontal scale to $2\mu\text{s}/\text{div}$ to view the CAN datas around the trigger event (ID 0x0108) the horizontal trigger position is indicated by the symbol :



In « STOP » we expand the horizontal scale to view the CAN frame details and to measure with cursors a bit width for a CAN HS (High Speed) 500kb/s :

We measure : $\Delta T = X1 - X2 = 2\mu\text{s}$ and $1/\Delta T = 500\text{kb/s}$

We can also measure the amplitude of the CAN_H HS and CAN_L HS (**CAN High Speed signals**) :

The CAN_H HS varies from 2.5V to 3.76V, its amplitude is :

$$\Delta V = Y2 - Y1 = 1.26\text{V}$$


The CAN_L HS varies from 2.5V to 1.40V, its amplitude is:

$$\Delta V = Y2 - Y1 = 1.10\text{V}$$


X - DECODE CAN Serial Bus Decode (cont'd)

Example : Measuring the amplitude of CAN HS with cursors .

Amplitude of CAN_H HS signal:



Amplitude of CAN_L HS signal:



Automatic measurements : amplitude, rise and fall times :

Expanding the horizontal scale we can display the following automatic measurements on CAN_H and CAN_L HS signals (**CAN High Speed**): amplitude, rise and fall times:


We notice that the amplitude ΔV is approximately 1V and the rise time of CAN_H and the fall time of CAN_L are almost identical and near 30ns:

X - DECODE CAN Serial Bus Decode (cont'd)

In our example, the measured amplitude of the CAN_H and CAN_L signals is 1.12V, close to the 1V nominal value of the “CAN High Speed”:



CAN High Speed Nominal bus levels



CAN HS nominal values

CAN_H HS varies from 2.5V to 3.5V → amplitude 1V

CAN_L HS varies from 1.5V to 2.5V → amplitude 1V

CAN_H - CAN_L varies from 0V (Recessive) to 2V (Dominant)

X - DECODE CAN Serial Bus Decode (cont'd)

Setting the CAN Trigger

- 1° Press the front panel « **Setup** » button to open the “TRIGGER” menu
- 2° Press the « **Type** » button and use the « Universal » knob to select Serial 1 or Serial 2
- 3° Press the « **Trigger Setting** » button to open the “CAN TRIG SET” submenu
- 4° Press the « **Condition** » button and use « Universal » knob to select the condition :

START The oscilloscope triggers at the **Start** of the frame

REMOTE The oscilloscope triggers on « **Remote Frame** » with the specified « ID » :



- a) Press the « **ID Bits** » button to set the number of bits of the « ID »: 11 or 29 bits
- b) Press the « **Curr ID Byte** » button and use the « Universal » knob to select the « **Byte** » to set
- c) Press the « **ID** » button and use the « Universal » knob to set the « **Byte** » selected

ID The oscilloscope will trigger on the « **Remote Frame** » or « **Data Frame** » matching the specified ID :



- a) Press the « **ID Bits** » button to set the number of bits of the ID : 11 or 29 bits
- b) Press the « **Curr ID Byte** » button and use the « Universal » knob to select the « **Byte** » to set
- c) Press the « **ID** » button and use the « Universal » knob to set the selected « **Byte** »

ID+DATA The oscilloscope will trigger on data frames matching the specified ID + DATA




- a) Press the « **ID Bits** » button to select the number of bits of the ID : 11 or 29 bits
- b) Press the « **Curr ID Byte** » button and use the « Universal » knob to select the « **Byte** » to set
- c) Press the « **ID** » button and use the « Universal » knob to set the selected « **Byte** »
- d) Press the « **Data1** » button and use the « Universal » knob to set the first data « **Byte** »
- e) Press the « **Data 2** » button and use the « Universal » knob to set the second data « **Byte** »


ERROR The oscilloscope will trigger when an error occurs

X - DECODE CAN Serial Bus Decode (cont'd)

Triggering on a bus « CAN Low Speed » 125kb/s on the IDentifier 0x03b6 :




We stop the acquisition and expand the horizontal scale to view in detail the « CAN Low Speed » (125kb/s) data flow, we use the cursors to determine the bit width :




The « CAN Low Speed » signals (CAN_H varies from 0V to 3.6V and CAN_L varies from 5V to 1.4V)

$$\Delta V_{can} = V_{can_H} - V_{can_L} \text{ varies from } -5V \text{ to } +2.2V$$



X - DECODE CAN Serial Bus Decode (cont'd)


Set the List display « Off » :



We measure : $\Delta T = X1 - X2 = 8\mu s$ to $1/\Delta T = 125 kb/s$

Measuring the amplitude of the CAN LS signals

Amplitude of the CAN_H LS (CAN Low Speed) :



The « CAN_H LS » signal varies from 0 to 4V, with the cursors we measure


$$\Delta V = Y2 - Y1 = 4.04V$$

X - DECODE CAN Serial Bus Decode (cont'd)


Amplitude the CAN_L LS (125kb/s) signal :

The « CAN_L LS » signal varies from 1V to 5V and its amplitude is :

$$\Delta V = Y2 - Y1 = 4.06V$$



Automatic measurement of the amplitude and the rise time of the CAN LS signals



In our example of « CAN Low Speed » bus the ΔV_{CAN} différential value is :

$$\Delta V_{CAN} = CAN_H - CAN_L = 0V - 5V = -5V \text{ or } 4V - 1V = +3V$$

Note : To restart decoding the CAN bus, you must first « Clear » the automatic measurements

X - DECODE CAN Serial Bus Decode (cont'd)


Setting the CAN Bus DECODE

1° Press the front panel « **Decode** » button to open the “DECODE” menu



2° Press the « **Display** » button to set the display of the decoded line « **On** »

3° Press the « **List** » button to open the LIST submenu



4° Press the « **Display** » button to set the display of the List « **On** »

5° Press the « **Scroll** » and « **Lines** » buttons and use the « Universal » knob to set the cursor position and the number of lines displayed.



X - DECODE CAN Serial Bus Decode (cont'd)

Interpreting the CAN Decode

CAN Decode line

The hex data bytes are displayed in white

The hex CRC (**Cyclic Redundancy Check**) are displayed in **blue** when **valid**, or in **red** to indicate that the oscilloscope calculated **CRC is different** from the incoming CRC data stream.

The transition lines indicate an active bus

The mid-level blue lines indicate an **Idle** bus

The decoded text is truncated at the end of the associated frame when the space between the frame boundaries is insufficient

The pink vertical bars indicate that you need to expand the horizontal scale (S/div) to view the decoded data

The red dots in the decode line indicate that there is data that is not being displayed, scroll or expand the horizontal scale to view the information

Aliased bus values (undersampled or indeterminate) are displayed in pink

CAN Decode List

The CAN decode list has the following columns :

No Frame number from left to right

Time

Type **R** indicate a « **Remote Frame** » and **D** a « **Data Frame** »


ID Frame identifier

Length "Data Length"

Data Data for CAN decode

CRC Cyclic Redundancy Check

Ack « Acknowledge »



X - DECODE LIN Serial Bus Decode

Setting up the oscilloscope to capture the LIN bus signals

To capture the LIN (**Local Interconnect Network**) signal :

Connect the LIN signal to the oscilloscope input

Assign a channel to the LIN signal

Set the threshold, the baud rate, the « sample point » and other parameters

1° Press the front panel « **Decode** » button to open the “DECODE” menu

2° Press the « **Serial** » button and select: Serial 1 or Serial 2

3° Press the « **Decode** » button and use the « Universal » knob to select LIN



4° Press the « **Signal** » button to open the SIGNAL submenu



5° Press the « **Source** » button to assign a channel to the LIN signal


6° Press the « **Threshold** » button and use the « Universal » knob to set the threshold

7° Press the « **UP** » button to return to the “DECODE” menu

8° Press the « **Configure** » button to open the BUS CONFIG submenu



9° Press the « **Baud** » button and use the « Universal » knob to set the « Baud Rate » in the range: 600b/s to 19200b/s or “Custom” from 1b/s to 20kb/s.




X - DECODE LIN Serial Bus Decode (cont'd)

Setting the LIN Trigger

The LIN trigger allows to trigger on the rising edge of the « **Sync Break** » signal (at the start of the message frame), the frame identifier « ID » or the « ID+Data ».

1° Press the front panel « **Setup** » button to open the TRIGGER menu



2° Press the « **Type** » button and use the « Universal » to select Serial 1 or Serial 2 according to Decode

3° Press the « **Trigger Setting** » button to open the “LIN TRIG SET” submenu




Break The oscilloscope triggers on a « **Sync Break exit** » (start of frame)

ID The oscilloscope triggers on a specified frame ID

ID+Data The oscilloscope triggers on a specified IDentifier and « Data »

Data Error The oscilloscope triggers on a data error



X - DECODE LIN Serial Bus Decode (cont'd)

Setting the LIN Serial Bus Decode

- 1° Press the front panel « **Decode** » button to open the DECODE menu
- 2° Press the « **Display** » button to set the decode line display « **On** »
- 3° Press the « **List** » button to open the “LIST” submenu
- 4° Press the « **Display** » button to set the list display « **On** »
- 5° Press the « **Scroll** » and « **Lines** » buttons and use the « **Universal** » knob to set the cursor position and the number of lines



Automatic measurement of the amplitude, the Top and Base voltages, the rising and falling times of LIN signal: Vamp, Vtop, Vbase, Rise Time et Fall Time



X - DECODE LIN Serial Bus Decode (cont'd)

Interpreting the LIN decode line

The transition lines indicate an active bus

The mid-level blue lines indicate an **Idle** bus

The identifier ID (hexadecimal) and the parity bit (if enabled) are in **yellow** or in **red** if a parity error is detected.

The decoded hex data values are in **white**

The decoded text is truncated at the end of the associated frame when the space between the frame boundaries is insufficient

The **pink** vertical bars indicate that you need to expand the horizontal scale to see the decoded information

The **red dots** indicate that there is data that is not being displayed . **Scroll** or Expand the horizontal scale to display them

The unknown bus values (undefined or error conditions) are displayed in red

Interpreting the LIN decode List

The LIN decode list has the following columns :

No Frame number from left to right

Time

ID Frame Identifier


Data Data bytes

Data Length Length of data

ID Check ID parity error

Data Check data error check

LIN Message Frame :




XI - Logic Analyzer « Digital » option (Contact us)

The **DOX-MSO3LA** option (including a « Digital Analysis » software and an eighth-channel digital probe) transforms the DOX3000 into a **Mixed Signal Oscilloscope (MSO)** with “4 analog” and “8 digital” inputs.

To start up the « Logic Analyzer » option requires to:

- 1° Load the license code of the « DIGITAL » option
- 2° Plug the « DOX-MSO3LA » digital probe into the front panel connector of the oscilloscope :




3° Connect the digital probe to the circuit under test:

Turn **off** the circuit under test

Connect the probe ground wire to the reference of the circuit under test

Connect the other probe inputs to the circuit under test

Turn **on** the circuit under test



4° Press the front panel « **Digital** » button to open the DIGITAL menu.

XI - Logic Analyzer « Digital » option (cont'd)




Press the « **Channel High** » button to select the display type, to vertically expand (High) or compress (Low) the 8 digital channels display.

Press the « **Channel Control** » button and use the Universal knob to select the digital channel

Press the « **Di** » button to switch “On” or “Off” the selected channel

Press the « **D0-D7** » button to switch “On” or “Off” all the digital channels :



Press the « **Threshold** » button to open the THRESHOLD menu

Press the “D0-D7” button and use the Universal knob to select a logic family : **TTL - CMOS - LVCMOS3.3 - LVCMOS2.5 - Autodéfini**



Logic Family	Threshold Voltage
TTL	1.5V
CMOS	1.65V
LVCMOS3.3	1.65V
LVCMOS2.5	1.25V
Custom	Variable from -3V to +3V

Note : The selected threshold applies to all digital channels

Select « **Custom** » and use the Universal knob to adjust the threshold voltage in the range: -3V to +3V



Press the « **Digital Bus** » button to open the DIGITAL BUS menu to set the Bus 1 or 2 :

Bus width : 1 to 8bits

Bus format : Hexadecimal or Binary

Display : « On » or « Off »

XI - Logic Analyzer « Digital » option (cont'd)




With Display « On » :

Use the « **Position** » knob to select a digital channel (red) and use the “**Variable**” knob to position the channel vertically.

With Bus 1 (Binary) and Bus 2 (Hexadecimal) “On”:

The oscilloscope displays simultaneously the 8 bit data bus value in “Binary” and “Hexadecimal” formats:



For example, the « Digital » option of the DOX3304 will allow us to test the Analog/Digital/Analog interfaces such as :

- Analog to Digital Converters « ADC »
- Digital to Analog Converters « DAC »
- Analog/Digital Sensors or Digital/Analog Actuators .

The oscilloscope can display simultaneously :

- 4 analog waveforms (inputs CH1 , CH2 , CH3 , CH4) and
- 8 digital channels (bus data format hexadecimal or binary) :

Display example : analog waveform on channel CH1 and CH4
and 8-bit digital bus D0 to D7

XI - Logic Analyzer « Digital » option (cont'd)




The DOX3304 will allow us to make:


1° Cursor measurements (Voltage, Time) on all channels CH1 CH2 CH3 CH4

2° Automatic measurements on all analog channels CH1 - CH2 - CH3 - CH4 and on the 8 digital channels D0 to D7 :

XI - Logic Analyzer « Digital » option (cont'd)




The DOX3304 will display statistics on the active measurements (our example 5 active measurements on: D0, CH1 and CH4) :




The DOX3304 also displays all « Time » and « Voltage » measurements on a channel CH1 :

XI - Logic Analyzer « Digital » option (cont'd)



The DOX3304 allows to trigger on a « **Pattern** » that includes the analog channels (CH1 to CH4) and the digital channels (D0 to D7). In our example we set the following “AND” pattern : CH1 High (>900mV), CH2=CH3= X (**don't care**), CH4 High (>1V) and D0=Low D1=D2=High and D3=D4=D5=D6=D7= X (**don't care**). The duration of the AND condition is >182µs and the Holdoff =13ms:



XII - « Power Analysis » Option (Contact us)

The PAS (**Power Analysis Software**) option is a tool for analysing the reliability and efficiency of **Switching Power Supply**.

The « PAS » option allows characterization of :

The **Power Factor**, the **True Power**, the **Apparent Power**, the **Current Harmonics**, the **Switching Loss**, the **di/dt** and **dV/dt Slew Rate**, the **Output Ripple**, the **Transient Response**, the **Efficiency Analysis**, the **Inrush Current** etc...

The conducted emission can be characterize using a wide bandwidth current probe.

Conduction and Switching losses determine the efficiency of switching power supplies. The PAS option helps to characterize the switching and conduction losses on a **Switching Cycle**.

To determine the efficiency of the switching power supply it is necessary to measure the losses for dynamic load changes.

Highlighting switching and/or conduction losses peaks helps to improve the switching power supply reliability.

We give in the following a few examples of measurements on a switching power supply.

Ex 1 Current Harmonic Analysis :




XII - « Power Analysis » Option (cont'd)

Ex 2 Inrush current :




Ex 3 Output Ripple (Input coupling DC) :



XII - « Power Analysis » option (cont'd)

Ex 4 Output Ripple (input coupling AC) :



Ex 5 Switching Analysis:



XII - « Power Analysis » option (cont'd)

Ex 6 Slew Rate Analysis :




Ex 7 Power Quality Analysis :




XII - « Power Analysis » option (cont'd)

Ex 8 Turn On Analysis :



Ex 9 Turn Off Analysis :



XIII - Remote Control of the Oscilloscope



Remote Control

There are two methods to remotely control the oscilloscope:
 using SCPI commands or
 using the specialized PC software « EasyScopeX »

User-defined programming

User can control the oscilloscope by programming through standard SCPI (**Standard Commands for Programmable Instruments**) commands. For more details about commands and programming, please refer to the « Programming Manual ».

User can remotely control the oscilloscope through the specialized PC software « **EasyScopeX** ».

Using the PC software « EasyScopeX »

The oscilloscope can communicate with a PC through its « USB Device » port (USB B connector) or through its « LAN Ethernet » interface (RJ45 connector). These connectors are located on the rear panel of the unit.

This section describes how to use the « EasyScopeX » PC software to remotely control a DOX3000 oscilloscope through its USB or LAN interface.

Control through USB


Use a USB cable to connect the oscilloscope (**USB Device connector**) to a PC (**USB host connector**) with **EasyScopeX** installed.


Installing the USBTMC interface in the DOX3000

Through the I/O submenu of the UTILITY menu set the « **USB Device** » interface to **USBTMC**. If you have installed the EasyScopeX software, the PC will display pop-up dialogue boxes when you connect the oscilloscope to the PC for the first time. Please follow the prompting messages to install the "USB Test and Measurement Device" . Below are the steps:




XIII - Remote Control (cont'd)







Connecting Devices

Open « **EasyScopeX** » software, click "Add Device" to start the search, the following dialog box appears:




Click the communication interface to use USBTMC (USB) or VXI11 (Ethernet).


If the instrument is connected through USBTMC interface, select the instrument to open and click the « Add » button :



If the active communication interface is VXI11, the following window appears:




Enter the oscilloscope IP address (example 14.3.212.25) and click OK to remotely control the oscilloscope through « Ethernet ».



Check Instrument Resource


The informations about the instrument « added » are displayed. See the examples below. The device “Serial Number” and the informations about the USB communication interface (or Ethernet) are displayed.



Testing the communication interface

- Send Command

Click "Send Command" button and enter (keyboard) the SCPI command : « *IDN? », press the « Enter » button to send the command. The « EasyScopeX » software sends the command to the oscilloscope, accepts the instrument datas and displays the instrument identification:




- Send Command

To send SCPI commands to the oscilloscope

Traces


- WaveTrace

To retrieve the waveforms from the oscilloscope (all acquired samples)



• **Screen Capture**

To perform a screen capture (displayed waveforms)




• **Scope Configuration**

To Control the oscilloscope through a virtual panel

Virtual Panel

By activating the virtual panel it is possible to remotely control the oscilloscope by acting on the softkeys and virtual knobs of the « Virtual Panel ». The “virtual screen” will react interactively to the actions on the “Virtual Panel”:



For more details, please consult the « EasyScopeX » help file.

Messages / Help

« Help »


The oscilloscope has an embedded help function that supplies multi-language Help information (**English** , **French**, **German**). To access help:

Press the front panel "Help" button to activate the help, then press every button to display the corresponding help information.

Note : *To display the help information corresponding to the « Single » or « Run/Stop » buttons, press these buttons immediately after you press the « Help » button. Otherwise the « Single » button is used to display the next page of the displayed help and the "Run/Stop" button the previous page, when the help information exceeds one page.*

All submenus of every main menus have their own help information.

Note : If you want to display help information of next page submenus, first press the « Help » button to exit the help status and switch to next page menu then press the « Help » button to enter the help status again and press the submenu option buttons to display the corresponding help information.



Messages (cont'd)

Messages

- **Trig level at limit!** : Indicates that the adjustable trigger level is at its limit.
- **Horizon position at limit!** : Indicates that the adjustable horizontal position is at its limit.
- **Volts/Div at limit!** : Indicates that the vertical scale “V/div” has reached the minimum “2mV/div” or the maximum “10V/div”.
- **Volts position at limit!** : Indicates that the vertical position is at its limit.
- **Sec/Div at limit!** : Indicates that the Time Base coefficient “S/div” is at its limit.
- **Hold-off time at limit!** : Indicates that the adjustable « Holdoff » is at its limit.
- **Function isn't useable!** : Indicates that the function is not compatible with the operating mode.
- **No signal!** : This message is output by the Autoset in the absence of signal.
- **Adjust at limit!** : This message is displayed when the pulse width adjustment (Universal knob) reaches the limits min “2,0ns” or max “10,0s”.
- **Location Empty!** : This message is displayed when you press the « Recall » button and the location is empty (no waveform or setup).
- **USB Flash Drive Plug In!** : This message is displayed when you plug a USB Flash Drive in the USB host connector.
- **USB Flash Drive Pull Out!** : This message is displayed when you pull out the USB flash drive.
- **Store Data Success!** : This message indicates a « Successfull Save » of the Setup, the Waveform or the Picture in the internal memory of the oscilloscope or the USB flash drive.
- **Read Data Success!** : This message indicates a « Successfull Recall » of the Setup or the Waveform from the internal memory of the oscilloscope or the USB flash drive.
- **Please set Back USB to printer!** : This message is displayed if you press the front panel “Print” button with the “Back USB connector” set to “USBTMC”.
- **USB Flash Drive isn't connected!** : This message is displayed when the USB flash drive is not plugged in the « USB host connector » and you press the “Save” button to save a “File” or to “Print” a “Picture” in the external memory.
- **Record Wave Success!**: This message is displayed when a waveform is successfully saved.

Messages (cont'd)

Troubleshooting

Operation Steps 1. *After the oscilloscope is powered "ON", the LCD screen remains dark, please proceed as follow:*

- Check the power cord connection.
- Check the Power On button backlighth ("On/Off" button lighting is variable).
- Ensure the power On/Off switch is turned On ("On/Off" button lighting is fixed On) .
- After the inspections above, restart the oscilloscope.
- If the oscilloscope is still not usable after the checking, contact METRIX division CHAUVIN-ARNOUX (**support area**).

2. *If the oscilloscope does not display any waveform with signals on input channels:*

- (1) Check the input probe.
- (2) Check the input cable.
- (3) Check the probe with the front panel « **Cal 3V 1kHz** » output.
- (4) Check that the unit under test generates the signal or not.
- (5) Press the « Auto setup » button.

3. *The displayed voltage value is 10 times higher/lower than the real one, please proceed as follow :*

Check that the channel probe factor matches the probe attenuation coefficient.

4. *The displayed signal is unstable :*

- (1) Check that the selected trigger source matches the displayed signal channel.
- (2) Check that the selected trigger mode is well suited to the type of signal displayed (ie for video signal use the "Video" trigger mode).
- (3) Set the « **HF reject** » or « **LF reject** » trigger coupling, to suppress the high/low frequency noise that eventually disturbs the trigger .
- (4) Use the "**Noise Reject**" option, to prevent signal noise to disturb the trigger

5. *You press the "Run/Stop" button but nothing is displayed.*

Check whether the trigger mode is set to "Normal" or "Single", and check that the trigger level is within the max and min peaks of the signal. Press the « Level » knob to set the « Level to **50%** » , or press « **Auto** » button to set the Auto Trig mode or press the "**Auto Setup**" button to perform an automatic set up.

6. *The waveform refreshes slowly after setting the acquire "Average" mode or the "The display Persistence time" is set too long.*

It is normal with this settings

7. *The signal is displayed as a « ladder like » waveform*

- (1) This phenomenon is normal. If the Time Base is too slow, turn the "S/div" knob to improve the display.
- (2) If the display type is set to "Vectors", set it to "**Dots**".

Technical Specifications

The oscilloscope must have been operating continuously for thirty minutes within the specified temperature. You must perform the « Do Self Cal » operation through the "Utility" menu, if the operating temperature changes by more than 5°C. The oscilloscope must be within the calibration interval. All specifications are guaranteed unless note "typical"

Inputs	DOX3104	DOX3304
Channels	4	4
Input Coupling	AC, DC, GND	
Input Impedance	1 MΩ ± 2 % 20 pF ± 4 pF or 50 Ω ± 2 %	
Maximum input voltage	300 V (DC+AC Pk = 300 Vmax) CATI (1 MΩ) or ≤5Vrms (50 Ω)	
Channel to Channel isolation (Same sensitivity V/div on both channels)	> 100:1 at 50 MHz	> 100:1 at 150 MHz
Probe Attenuation	1X, 10X	
Probe compensation factor	.1X, .2X, .5X, 1X, 2X, 5X, 10X, 20X, 50X, 100X, 200X, 500X, 1000X, 2000X, 5000X, 10000X	

Vertical System	DOX3104	DOX3304
Vertical Sensitivity	2 mV/div to 10V/div (sequence 1-2-5)	
Vertical Position Range	2mV/div to 100mV/div : ± 1V 102 mV/div to 1V/div : ± 1V 1.02V/div to 10V/div : ± 100V	
Vertical Resolution	8 bit	
Number of Channels	4	4
Analog Bandwidth	100 MHz	300 MHz
Single Shot Bandwidth	100 MHz	300 MHz
Bandwidth Flatness at BNC input	DC - 10 % of nominal Bandwidth : ± 1 dB 10 % - 50 % of nominal Bandwidth: ± 2 dB 50 % - 100 % of nominal Bandwidth: + 2 dB / - 3 dB	
Low frequency cutoff (-3dB) AC input coupling	≤ 10 Hz	
Noise: Pk-Pk	≤ 0,6 div. 10 Pk-Pk values average, calibres 2mV to 10V/div ≤ 1,0 div. 10 Pk-Pk values average, (152mV/div ~ 198mV/div, 1.52V/div ~1,98V/div) ≤ 0,7 div. 10 Pk-Pk values average, fine vertical sensitivity adjust	
SFDR including harmonics (measure with FFT)	≥ 35 dB (≥ 10mV/div) ; ≥ 30 dB (< 10mV /div)	
DC gain precision for a 6 div amplitude signal.	± 3.0 % : 5 mV/div. to 10 V/div. Fixe sensitivities ± 4.0 % : 2 mV/div. Fine adjust sensitivity	
DC measurements precision all Sensitivities : ≤ 100mV/div.	± [3 % * (measure + offset) + 1 % * offset + 0,2 div. + 2 mV]	
DC measurements precision all sensitivities : >100mV/div.	± [3 % * (mesure + offset) + 1 % * offset + 0,2 div. + 100 mV]	
Rise Time	< 3.5ns	< 1.2ns
Overshoot (Typical) (pulse tr = 500ps)	< 10 % (with 50 Ohm internal input impedance)	
Skew between channels (same sensitivity V/div)	< 200ps	< 200ps
Math	+, -, *, /, FFT, d/dt, ∫dt, √	
FFT	Window Type : Hanning, Hamming, Blackman, Rectangular	
	Number of samples : 1024	
Bandwidth Limit	20 MHz ± 40 % (Note : The Bandwidth limit is less than 10 MHz when using a X1 probe)	

Technical Specifications (cont'd)

Horizontal and Sampling system	DOX3104	DOX3304
Real time sampling frequency	Dual Channel [CH1 CH3] or [CH2 CH4] : 2GSa/s 3 or 4 Channel : 1GSa/s (For Time Base coefficients faster than 1ms/div and 14Mpts memory depth)	Dual Channel [CH1 CH3] or [CH2 CH4]: 2GSa/s 3 or 4 Channel: 1GSa/s (For Time Base coefficients faster than 1ms/div and 14Mpts memory depth)
Memory depth	14Mpts max per channel Adjustable: 7kpts 14kpts 70kpts 140kpts 700kpts 1.4Mpts 7Mpts	14Mpts max per channel Adjustable: 7kpts 14kpts 70kpts 140kpts 700kpts 1.4Mpts 7Mpts
Acquisition	Normal, Peak Detect, Average, High Resolution	
"Averages"	4, 16, 32, 64, 128, 256, 512, 1024	
Time base accuracy	± 25 ppm	
Time Base coefficients range	1ns/div. - 50s/div.	1ns/div. - 50s/div.
Maximum number of capture waveforms per second	110000 Waveforms/s	
SPO Intensity grading	256 levels	
Display Format	Y(t), Zoom, Roll, X-Y	
Roll mode	Roll : 100ms/div. - 50s/div. (sequence 1-2-5)	

Trigger System	
Trigger	Digital Trigger on CH1, CH2, CH3 and CH4 sources
Trigger Types	Edge, Pulse, Video, Slope, Window, Interval, Dropout, Runt, Pattern, Serial Trigger
Trigger Sources	CH1, CH2, CH3, CH4, EXT, EXT/5, AC Line
Trigger Modes	Auto, Normal, Single-Shot « Roll » Mode for Time Base coefficients : from 100ms/div to 50s/div
Trigger Coupling	AC, DC, LF rej, HF rej DC: All components of the signal passes AC : Blocks the DC component and attenuates low frequency signals <5.8Hz LF rej : Blocks the DC component and attenuates low frequency signals <2.08MHz HF rej : Attenuates high frequency signals >1.27MHz
Holdoff	Adjustement range : 100ns - 1,5s
Trigger level range	CH1, CH2, CH3, CH4: ± 4.5 divisions from the center of the screen EXT : ± 1,2V EXT/5 : ± 6V
Trigger position	Pre-trigger : 7 divisions Post trigger Max : 10s to 1000000000s depending on the Time Base coefficient.
Trigger Level accuracy (Typical)	± 0,2 div
Trigger Sensitivity	CH1 CH2 CH3 CH4 (2mV to 10V/div sequence 1-2-5) : 0.5 div EXT : 200mVpp DC - 10 MHz 300mVpp 10MHz - max. BW EXT/5 : 1Vpp DC - 10 MHz 1,5Vpp 10MHz - max. BW
« Edge » Trigger	Pente : Positive, Negative, Positive&Negative Source : CH1 CH2 CH3 CH4 EXT EXT/5 Line
« Slope » Trigger	Slope : Rising, Falling Limit : <, >, <>, >< Source : CH1 CH2 CH3 CH4 Adjustement range: 2ns to 4,2s Resolution : 1ns

Characteristics

<p>« Pulse Trigger »</p>	<p>Polarity : +wid, -wid Limit : <, >, <>, >< Source : CH1 CH2 CH3 CH4 Adjustement Range: 2ns to 4,2s Resolution : 1ns</p>
<p>« Window Trigger»</p>	<p>Window Type : Absolute, Relative Source : CH1 CH2 CH3 CH4</p>
<p>« Video Trigger »</p>	<p>Supported Standards : PAL/SECAM, NTSC, 720p/50, 720p/60, 1080p/50, 1080p/60, 1080i/50, 1080i/60, Custom Source : CH1 CH2 CH3 CH4 Sync: All, Selection</p>
<p>“Interval Trigger”</p>	<p>Slope : Rising, Falling Limit : <, >, <>, >< Source : CH1 CH2 CH3 CH4 Adjustement range : 2ns to 4,2s Resolution : 1ns</p>
<p>« Dropout Trigger »</p>	<p>Timeout type : Edge, State Source : CH1 CH2 CH3 CH4 Slope : Rising, Falling Adjustement range : 2ns to 4,2s Resolution : 1ns</p>
<p>« Runt Trigger »</p>	<p>Polarity : +wid -wid Limit : <, >, <>, >< Source : CH1 CH2 CH3 CH4 Adjustement Range : 2ns to 4,2s Resolution : 1ns</p>
<p>Serial Bus Trigger</p> <p>« I2C Trigger »</p> <p>« SPI Trigger »</p> <p>« RS232/UART Trigger»</p> <p>“CAN Trigger”</p> <p>“LIN Trigger”</p>	<p>State : don't care, Low, High Logic : AND, OR, NAND, NOR Source : CH1 CH2 CH3 CH4 Limit: <, >, <>, >< Adjustement Range : 2ns to 4,2s Resolution : 1ns</p>
	<p>Condition : Start, Stop, Restart, No Ack, EEPROM, 7bits Address&Data</p>
	<p>Trigger Source : MOSI, MISO Data length: 4 to 96bits Value: 0, 1, X Bit Order: LSB, MSB</p>
	<p>“Trigger Setting” Trigger Source: RX, TX Condition: Start, Stop, Data, Check Error</p> <p>“Bus Configure” Baud: 600/1200/2400/4800/9600/19200/38400/57600/115200/Custom Data Length: 5bits, 6bits, 7bits, 8bits Parity Check: No, Odd, Even Idle Level: Low, High</p>
	<p>“Trigger Setting” Condition: Start, Remote Frame, Data Frame, ID&DATA</p> <p>“Bus Configure” Baud: 5kb/s, 10kb/s, 20kb/s, 50kb/s, 100kb/s, 125kb/s, 250kb/s, 500kb/s, 800kb/s, 1Mb/s, Custom</p>
	<p>“Trigger Setting” Condition: Start, ID, ID&DATA, Error</p> <p>“Bus Configure” Baud: 600/1200/2400/4800/9600/19200/Custom</p>

“Serial Decode”	
Bus I2C	Signal : SCL, SDA Address : 7bits, 10bits List : 1 to 7 lines
SPI bus	Signal : CLK, MISO, MOSI, CS Slope select : Rising, Falling Idle Level : Low, High Ordre des Bits : MSB, LSB Data Length : 4 to 96bits Liste : 1 to 7 lines
RS232/UART Bus	Signal : RX, TX Configuration Baud : 600/1200/2400/4800/9600/19200/38400/57600/115200/Custom “Parity Check” : No, Odd, Even Bit Stop : 1, 1.5 , 2 Idle Level : Low, High Data Length : 5bits, 6bits, 7bits, 8bits List : 1 to 7 lines
CAN bus	Signal : CAN_H, CAN_L Configure Baud : 5kb/s, 10kb/s, 20kb/s, 50kb/s, 100kb/s, 125kb/s, 250kb/s, 500kb/s, 800kb/s, 1Mb/s, Custom Decode Source : CAN_H, CAN_L, CAN_H - CAN_L List : 1 to 7 lines
LIN Bus	Configure Baud : Baud : 600/1200/2400/4800/9600/19200/Custom List : 1 to 7 lines

X-Y Format	
X-Y Inputs	[CH1 (X) CH2 (Y)] or/and [CH3(X) CH4(Y)]
Phase Error	± 3 degrees
XY Sampling frequency range	XY mode Sampling frequency range : 20Sa/s to 1GSa/s

Hardware Frequency Counter	
Reading Resolution	6 Digits
Precision	± 0,01% @ 1kHz
Frequency range	DC Input coupling : frequency measurement range from 10Hz to the maximum bandwidth frequency .
Signal Type	All the source signals that generate a trigger event.

Measurement system	
Automatic Measurements (32 Types)	Vpp, Vmax, Vmin, Vamp, Vtop, Vbase, Vavg, Mean, Crms, Vrms, ROVShoot, FOVShoot, RPRESshoot, FPRESshoot, Rise time, Fall time, Freq, Period, +Wid, -Wid, +Dut, -Dut, BWid, Phase, FRR, FRF, FFR, FFF, LRR, LRF, LFR, LFF
Cursor Measurements	Modes : Manual, Track Time : (X1,X2), (X1X2) Voltage : (Y1, Y2), (Y1Y2)
Statistics	Current, Mean, Min, Max, Std-Dev, Count

Interfaces Entrée/Sortie I/O	
Ports Standards	USB Host, USB Device, LAN, Pass/Fail, Sortie Trigger
Bon/Mauvais (Pass/Fail)	3.3V TTL Output

Waveform Arbitrary Generator	
<i>Channels</i>	1
<i>Maximum Frequency</i>	25MHz
<i>Sampling Frequency</i>	125Msa/s
<i>Number of points</i>	16kpts
<i>Frequency Resolution</i>	1µHz
<i>Vertical Resolution</i>	14 bits
<i>Amplitude Range</i>	2mVpp to 3Vpp (50Ω) 4mVpp to 6Vpp (High-z)
Signal Sinusoidal	
<i>Frequency</i>	1µHz to 25MHz
<i>Precision (100kHz)</i>	± (0,3dB of set value + 1mV)
<i>Amplitude « Flatness » (100kHz, 5Vpp)</i>	± 0,3dB
<i>SFDR</i>	DC to 1MHz -60dBc 1MHz to 5MHz -53dBc 5MHz to 25MHz -35dBc
Square/Pulse Signal	
<i>Frequency</i>	1µHz to 10MHz
<i>Duty Cycle</i>	20% to 80%
<i>Rise/Fall Time</i>	< 24ns (10% to 90%)
<i>Overshoot</i>	< 5% (1kHz, 1Vpp, Typical)
<i>Pulse Width</i>	48ns to 1ms
<i>Jitter</i>	8ns
Ramp Signal	
<i>Frequency</i>	1µHz to 300kHz
<i>Linearity</i>	< 0,1% of Peak to Peak value
<i>Symetry</i>	0% to 100%
DC (Offset)	
<i>Adjustement Range</i>	± 1,5V (50Ω) ± 3V (High-z)
<i>Precision</i>	± (set value *1%+3mV)
Noise	
<i>Bandwidth Limit</i>	> 20MHz (-3dB)
Cardiac	
<i>Frequency</i>	1µHz to 5MHz
Gauss Pulse	
<i>Frequency</i>	1µHz to 5MHz
Exponential Rise	
<i>Frequency</i>	1µHz to 5MHz
Exponential Fall	
<i>Frequency</i>	1µHz to 5MHz
Arbitrary Waveform	
<i>Arb1</i>	To set with « EasyWave » software
<i>Arb2</i>	To set with « EasyWave » software
<i>Arb3</i>	To set with « EasyWave » software
<i>Arb4</i>	To set with « EasyWave » software

Technical Specifications (cont'd)

Display System	
LCD screen	8 inch TFT Color LCD (203,2 mm diagonal)
Resolution	800 pixels (horizontal) x 480 pixels (vertical)
Colors	24 bit
Display Contrast	500:1 (typical)
Backligh Intensity	300nit (typical)
Waveform display	8 x 14 div.
Display Modes	Points, Vectors
Persistence	Off, 1 sec, 5 sec, 10 sec, 30s, Infinite
Screen Saver	Off, 1mn, 5mn, 10mn, 30mn, 1h
Interpolation	Sin(x) , x
SPO color Mode	On , Off
Language	English, Français, Deutsch, Español, Italiana

Environment	
Temperature Range	Reference : 18°C to 28°C Operating : 0°C to +40°C Non-operating : -20°C to +60°C For indoor use
Cooling	Fan
Humidity	Operating : < 80 % HR, up to 31°C Non-operating : < 80 % HR, up to 31°C
Altitude	Operating : < 2000 m Non-operating : < 12.000 m

Power Supply	
Input voltage range	nominal 100 - 240 VAC Auto selection
Frequency	50 Hz to 400 Hz
Power Consumption	80W max.
Fuse	T 1,25 A / 250 V 5x20mm
Power Cord	Removable

Security	Compliant with NF EN 61010-1
Insulation	Classe 1
Pollution Index	2
Power Supply Surge Category	300V CATII
Inputs surge Category	300V CATI

Technical Specifications (cont'd)

EMC	
	The appliance has been designed in compliance with the applicable EMC standards and its compatibility has been tested in compliance with standard NF EN 61326-1.

European Directives CE	
	The CE marking indicates compliance with « Low Voltage », "EMC", "DEEE" and "RoHS" European Directives.


Mechanical	
Dimensions	Length 352 mm
	Width 112 mm
	Height 224 mm
Weight	3,6 kg DOX3104 & DOX3304 models
Materials	ABS VO (auto extinguishing)
Sealing	IP20


Packaging	
Dimensions	430 x 240 x 365 mm

Parts Accessories	
Shipped	<ul style="list-style-type: none"> • User Manual on USB memory device • « EasyScopeX » PC software • « Easywave » PC software • Getting started guide • Safety instructions • Power supply cord • USB A/B cable • 4 Probes (DOX3104, DOX3304)
options	<ul style="list-style-type: none"> • Differential Probes : <ul style="list-style-type: none"> - single MX 9030 - dual MTX 1032 (consult us)

Remote Programming	
Manual	Contact us.

Appendix : Default Setup

Menu or system		Default setup
Horizontal	T/div	1 μ s/div
	Delay	0 s
	Zoom	Off
	Format	Y(t)
Vertical	Channel On/Off	CH1
	V/div	1V/div
	Vertical Position	0V
	Input Coupling	DC
	BW Limit	Full
	V/div adjust	Coarse 1 2 5
	Probe Factor	X1
	Input Impedance	1M Ω
	Vertical Unit	V
	Invert	Off
	Acquisition « Acquire »	Acquisition mode
SinX/X		X
Memory Depth		14Mpts
« Trigger »	Type	Edge
	Source	CH1
	Slope	Rising
	Holdoff	Fixed (Close)
	Coupling	DC
	Noise Reject	Off
	Mode	Auto
« Display »	Type	Vectors
	Color	Off
	Persistence	Off
	Grid	
	Intensity	50%
	Brightness	40%
	Transparence	50%
« Cursors »	Mode	Off
	Type	X1
	Source	CH1
	X1	-3,5 μ s
	X2	3,5 μ s
« Save/Recall »	Type	Setups
« UTILITY »	I/O Set	

	USB Device	USBTMC
	Aux Output	Trig Out
	Sound	
	Sound	On
	Pass/Fail	
	Enable Test	Off
	Source	CH1
	Operate	Off
	Mes Display	Off
	X Mask	0,2
	Y Mask	0,2
	Location	Internal
	Fail to Stop	Off
	Output	
	System Setup	
	Quick-Cal	Off
	Screen Saver	30mn
MATH	Operate	Off
	+	
	Source A	CH1
	Source B	CH1
	Invert	Off
	V/div	1V/div
	Vertical Position	0V
	-	
	Source A	CH1
	Source B	CH1
	Invert	Off
	V/div	1V/div
	Vertical Position	0V
	*	
	Source A	CH1
	Source B	CH1
	Invert	Off
	V/div	1V ² /div
	Vertical Position	0V ²
	/	
	Source A	CH1
	Source B	CH1
	Invert	Off

	V/div	1V/div
	Vertical Position	0
	FFT	
	Source	CH1
	Window	Hanning
	FFT Zoom	1X
	Vertical Scale	20dBVrms
	Display	Split
	Horizontal Scale	100MHz
	d/dt (dy/dx)	
	Source	CH1
	Vertical Scale	(1MV/s)/div = (1V/μs)/div
	Vertical position	0
	dx	0.2div
	∫dt	
	Source	CH1
	offset	0
	Vertical Scale	1μVs/div
	Vertical position	0
	√	
	Source	CH1
	Vertical Scale	1V½div
	Vertical position	0
REF	Source	CH1
	Location	REF A
	Display	Off
DECODE	Serial 1	
	Serial	I2C
	Display	Off
	List	Off
	Serial 2	
	Serial	SPI
	Display	Off
	List	Off
	I2C	
	SCK	CH1
	Threshold	1,6V
	SDK	CH2
	Threshold	1,6V
	Adresse (Address)	7 bit
SPI		

Characteristics

	CLK	CH1
	Threshold	1,6V
	Edge Select	Rising
	MISO	CH2
	Threshold	1,6V
	MOSI	CH3
	Threshold	1,6V
	CS Type	CS
	CS	CH4
	Idle Level	Low
	Bit Order	LSB
	Data Length	8
	UART/RS232	
	RX	CH1
	Threshold	1,6V
	TX	CH2
	Threshold	1,6V
	Baud	9600
	Parity Check	None
	Stop Bit	1
	Idle Level	Low
	CAN	
	CAN-H	CH1
	Threshold	1,6V
	CAN-L	CH2
	Threshold	1,6V
	Baud	100kb/s
	Decode Source	CAN-H
	LIN	
	Source	CH1
	Threshold	1,6V
	Baud	2400
WAVE GEN	Function	Off
	Wave Type	Sine
	Output Load	High-z
	Sine	
	Frequency	1kHz
	Amplitude	4Vpp
	Offset	0Vdc
	Square	
	Frequency	1kHz

Amplitude	4Vpp
Offset	0Vdc
Duty Cycle	50%
Ramp	
Frequency	1kHz
Amplitude	4Vpp
Offset	0Vdc
Symmetry	50%
Pulse	
Frequency	1kHz
Amplitude	4Vpp
Offset	0Vdc
Width	200µs
DC	
Offset	0mVdc
Noise	
St dev	300mV
Mean	0mV
Cardiac	
Frequency	1kHz
Amplitude	4Vpp
Offset	0Vdc
Gauss Pulse	
Frequency	1kHz
Amplitude	4Vpp
Offset	0Vdc
Exponential Rise	
Frequency	1kHz
Amplitude	4Vpp
Offset	0Vdc
Exponential Fall	
Frequency	1kHz
Amplitude	4Vpp
Offset	0Vdc



07 - 2015

X04249A02 - Ed. 01

DEUTSCHLAND - Chauvin Arnoux GmbH

Straßburger Str. 34 - 77694 Kehl / Rhein
Tel: (07851) 99 26-0 - Fax: (07851) 99 26-60

SCHWEIZ - Chauvin Arnoux AG

Moosacherstrasse 15 - 8804 AU / ZH
Tel: 044 727 75 55 - Fax: 044 727 75 56

UNITED KINGDOM - Chauvin Arnoux Ltd

Unit 1 Nelson Ct - Flagship Sq - Shaw Cross Business Pk
Dewsbury, West Yorkshire - WF12 7TH
Tel: 01924 460 494 - Fax: 01924 455 328

CHINA - Shanghai Pujiang Enerdis Instruments Co. Ltd

3 Floor, Building 1 - N° 381 Xiang De Road
Hongkou District - 200081 SHANGHAI
Tel: +86 21 65 21 51 96 - Fax: +86 21 65 21 61 07

中国 - 上海浦江埃纳迪斯仪表有限公司

上海市虹口区祥德路381号3号楼3楼
Tel: +86 21 65 21 51 96 - Fax: +86 21 65 21 61 07

ITALIA - Amra SpA

Via Sant'Ambrogio, 23/25 - 20846 Macherio (MB)
Tel: 039 245 75 45 - Fax: 039 481 561

ESPAÑA - Chauvin Arnoux Ibérica S.A.

C/ Roger de Flor, 293 - 1a Planta - 08025 Barcelona
Tel: 902 20 22 26 - Fax: 934 89 14 43

ÖSTERREICH - Chauvin Arnoux Ges.m.b.H

Slamastrasse 29/2/4 - 1230 Wien
Tel: 01 61 61 9 61-0 - Fax: 01 61 61 9 61-61

MIDDLE EAST - Chauvin Arnoux Middle East

P.O. BOX 60-154 - 1241 2020 JAL EL DIB (Beirut) - LEBANON
Tel: (01) 890 425 - Fax: (01) 890 424

SCANDINAVIA - CA Mätssystem AB

Sjöflygvägen 35 - SE 18304 TÄBY
Tel: +46 8 50 52 68 00 - Fax: +46 8 50 52 68 10

USA - Chauvin Arnoux Inc - d.b.a AEMC Instruments

200 Foxborough Blvd. - Foxborough - MA 02035
Tel: (508) 698-2115 - Fax: (508) 698-2118

<http://www.chauvin-arnoux.com>

190, rue Championnet - 75876 PARIS Cedex 18 - FRANCE

Tél. : +33 1 44 85 44 85 - Fax : +33 1 46 27 73 89 - info@chauvin-arnoux.fr

Export : Tél. : +33 1 44 85 44 38 - Fax : +33 1 46 27 95 59 - export@chauvin-arnoux.fr