# Megger.

# **BVM** Battery Voltage Monitor



- Automates battery voltage measurement during capacity tests
- "Daisy-chain" design allows expandability up to 120 units
- High accuracy and stability for precise data collection
- Integrates with TORKEL Win and PowerDB Test Data Management software
- Wide voltage range
- Easy set-up

#### Description

The Megger BVM is a battery voltage measurement device that is used for the capacity testing of large, industrial battery banks commonly found in electrical power sub-stations, telecom facilities and computer data center UPS systems. When used in conjunction with a load device, such as the TORKEL unit, and test data management software, such as PowerDB and TORKEL Win, the BVM enables to perform a completely automated battery bank capacity test, according to IEC test method. The test also meet NERC/FERC requirements. The BVM is designed in modular form where one BVM device is used for each battery or "jar" in the string to be tested. One BVM for each battery connects to the next in a "daisy-chain" fashion, thereby providing easy and economical expandability to meet the testing requirements for small-to-large battery bank systems.


The included dolphin clip can be easily removed and exchanged with different styles of standard banana plug clamps and/or extension cables to accommodate any battery connection requirement.

Setup is fast and easy using the BVM. Each BVM is identical and can be connected in any battery test position, thus providing maximum flexibility and interchangeability of the BVMs. Up to 120 BVMs can be daisychained in a single battery bank under test. The BVM "Auto Discovery" feature enables the host device to automatically determine the number of batteries under test and provide sequential identification of each BVM in the test string.

#### **Application**

Each BVM is identical and can be connected in any battery test position. Up to 120 BVMs can be daisy-chained in a single battery bank under test.

A single cable connects the first BVM in the string to a Power & signal connector. The laptop or other data acquisition device is connected via an Ethernet cable to the Power & signal connector.



The last dolphin clip (red) in the chain should be connected to the positive battery pole of the last battery in the bank. When used together with TORKEL the voltage will be logged through the complete discharge test.

# Megger.

### **Additional equipment**

For complete information on additional products see appropriate data sheets.

## TORKEL 820/840/860

Testing can be carried out without disconnecting the battery from the equipment it serves.



#### **TORKEL Win**

TORKEL Win PC software Shows the complete voltage curve Last recorded time, voltage, current and discharged capacity Remote control of TORKEL

#### **PowerDB**

Windows-based PC software available in four versions Interfaces to instruments via either Serial RS232, Ethernet, or USB flash drive (depending on instrument) Set up test routines in advance of testing Merge test results between field and office databases

### **BVM Cal Kit**

Calibration system for BVM units





#### Battery Voltage Monitor Battery Voltage Monitor

#### **Specifications**

Specifications are valid at an ambient temperature of +25°C, (77°F). Specifications are subject to change without notice.

#### **Environment**

Application field

The instrument is intended for use in medium-voltage substations and industrial environments. Altitude <2000 m (6500 ft) above sea level.

Temperature

Operating Storage & transport Humidity

## **CE-marking**

LVD

EMC

### General

Mains voltage Power consumption (max) Protection

Dimensions BVM unit

Carrying case

Weight BVM unit With accessories and carrying case

#### **Measurement section**

# Maximum number of channels

Voltage ranges0-5 VResolution1.00 rInaccuracy< 0.19</td>Battery string voltage300 VMeasurement input<br/>impedance1 MΩ

5°C to +50°C (41°F to +122°F) 0°C to +60°C (32°F to +140°F)

5% – 95% RH, non-condensing

2006/95/EC 2004/108/EC

100/240 V AC, 50/60 Hz 50 VA Over voltage, reverse voltage, voltage transients, ESD

75 x 64 x 25 mm (3" x 2.5" x 1") 575 x 470 x 205 mm (22.6" x 18.5" x 8.1")

0.07 kg (0.15 lbs) BVM system of 31 units 8.8 kg (19 lbs) BVM system of 61 units 12.5 kg (27 lbs)

120 0-5 V DC and 0-20 V DC 1.00 mV both ranges < 0.1% of full scale ±0.01 V DC 300 V DC (max)



Ordering information	
Item	Art. No.
BVM	
Including:	
Dolphin clips, Power & signal connector,	
Power supply, Connection cables and Carrying case	
BVM150	
With TORKEL Win software	CI 50000
System of 16 BVM units	CJ-59092
BVM300 With TORKEL Win software	
System of 31 BVM units	CJ-59093
,	C1-J3033
BVM600 With TORKEL Win software	
System of 61 BVM units	CJ-59096
	0,0000
BVM150 With PowerDB software	
System of 16 BVM units	CJ-59192
BVM300	0 55152
With PowerDB software	
System of 31 BVM units	CJ-59193
BVM600	
With PowerDB software	
System of 61 BVM units	CJ-59196
BVM	
Single unit	CJ-59090
Optional accessories	
Extension cable	
Extension lead for connecting BVM unit to battery,	
0.5 m (1.6 ft)	04-30050
BVM Cal Kit	
Calibration system for BVM units	CJ-90070
· · · · · · · · · · · · · · · · · · ·	

 Postal address
 Visiting address

 Megger Sweden AB
 Megger Sweden AB

 Box 724
 Rinkebyvägen 19

 SE-182 17 DANDERYD
 SE-182 36 DANDERYD

 SWEDEN
 SWEDEN

 T
 +46 8 510 195 00
 seinfo@megger.com

 F
 +46 8 510 195 95
 www.megger.com

Registered to ISO 9001 and 14001 Megger is a registered trademark

Printed matter: Art.No. ZI-CJ01E • Doc.CJ0062EE • 2015 BVM\_DS\_en\_V05 Subject to change without notice.