# **Easyloc**


## **Line location system**

## **Benefits:**

- Make optimum preparations for your building work, quickly and reliably
- Avoid cable damage and help to minimise costly accidents and inconvenient delays
- Quick and simple to operate
- Locate your metallic pipes & cables quickly and reliably
- Depth measurement at the push of a button, even without a transmitter
- ▶ 33 kHz compatible with other location systems
- Large display with automatic backlight
- High-performance 0.5 W transmitter for connecting to and tracing pipes and cables and induction method for searching unknown metallic utilities
- Transmitter with mains voltage-proof output no separating filter necessary
- Automatic sensitivity control
- Self calibration check routine saves annual maintenance costs



Rx receiver (Standard / Basic)		
Frequency ranges Radio Power network Easyloc Tx / Probe	15 kHz 23 kHz 50 Hz 250 Hz 33 kHz	
Location depth (probe)	0.3 7 m	
Location depth (cable)	0.3 5 m	
Operating time	> 40 hours	
Power supply	10 x IEC R6 1.5 V	
Temperature range	-20 °C +55 °C (operation) -40 °C +70 °C (storage)	
Weight	2.5 kg	
Dimensions (W x H x D)	max. 10 x 67 x 26 cm	
Protection class	IP 56	



Transmitted power 0.1 W / 0.5 W (switchable)

Frequency 33 kHz

Type of signal pulsed / continuous signal

(switchable)

Operating time > 40 hours

Power supply 6 x IEC R20 1.5 V

Temperature range -20 °C ... +55 °C (operation) -40 °C ... +70 °C (storage)

- - .

Weight 2.6 kg

Dimensions (W x H x D) 14 x 26 x 25.5 cm

## **Optional accessories**

- Headphones
  - For use of the equipment even in a loud environment
- Pipeline transmitter
  - For locating non-metallic pipes
- ► Transmitter clamp 100 mm
  - For putting a transmission signal onto cables under power
- **▶** House connection set
  - Comprising connection leads for direct connection for power supply, cable TV and telephone lines





## **Scope of delivery**

- ► Complete Easyloc set
  - Easyloc Rx Standard receiver, Easyloc Tx transmitter, earthing kit, earthing spike, carrying bag, operating instructions
- Easyloc Rx Standard receiver set
- Easyloc Rx Standard receiver, operating instructions
- Easyloc Rx Basic receiver set
  - Easyloc Rx Basic receiver, operating instructions
- ► Easyloc Tx transmitter set
  - Easyloc Tx transmitter, earthing kit, earthing spike, operating instructions



