

B046R03 / R13

Mobile vacuum pump unit

For evacuation of air or nitrogen

B046R03

Mobile vacuum pump unit

B046R13

Mobile vacuum pump unit with solenoid valve instead of ball valve

This version is equipped with a solenoid valve instead of a ball valve. Therefore, operating errors are avoided since the valve is closed automatically in case of function end or interruption of circuit.

The mobile vacuum pump unit is convincing by its easy handling. The unit serves for evacuation of air or nitrogen from switchgear. The 40 m³/h vacuum pump enables a final vacuum of < 1 mbar. Thus it is guaranteed that no air / gas mixture is generated and the good insulation properties of SF₆ are retained.



- Steerable and fixing rollers allow comfortable transportation
- Use of self-closing couplings DN20
- Different performances are available (see options)
- Adapters for other nominal widths are available
- Protection of the vacuum pump against overpressure by a solenoid valve
- Digital vacuum indication in mbar

B046R03 / R13**Mobile vacuum pump unit**

B046R03 / B046R13

Mobile vacuum pump unit**Technical data:**

Dimensions: L 910 mm, W 535 mm, H 1,075 mm
Weight: 115 kg
Operating voltage: 208 - 240 V / 380 - 460 V / 50 - 60 Hz alternating current

Standard equipment:

40 m ³ /h vacuum pump for air, final vacuum < 1 mbar
Vacuum indication in mbar
Ball valve DN20
5 m long hose DN20
DILO coupling tongue part DN20
Electric control
Fixing and steerable rollers
Different wrenches
Paint: orange (RAL 2004)
2 operating manuals in German, English or French

Optional equipment (mounted) at an extra charge:

63 m ³ /h vacuum pump, final vacuum < 1mbar	6-0005-R050
100 m ³ /h vacuum pump, final vacuum < 1mbar	6-0005-R051
40 m ³ /h two-stage vacuum pump, final vacuum < 2 x 10 ⁻³ mbar	6-0005-R028
65 m ³ /h two-stage vacuum pump, final vacuum < 2 x 10 ⁻³ mbar	6-0005-R101
Additional price for electrical special voltage	6-0005-R039

Optional accessories at an extra charge:

SF ₆ gas refilling device	3-393-R001
Frame with crane eyelets and plastic cover	B089R04
Additional operating manual on CD-ROM	6-0004-R213

Spare parts kits:

Maintenance package for standard vacuum pump (40 m ³)	6-1048-R112
Maintenance package for 6-0005-R050 / R051 vacuum pump (63 / 100 m ³)	6-1048-R113
Maintenance package for two-stage 6-0005-R028 / R101 vacuum pump (40 / 65 m ³)	6-1048-R114

Packing:

Packing for B046R03 / B046R13	3-748-R001-C
-------------------------------	---------------------